
OICQIEI POP 4S

QUICK START GUIDE

LED indicator





 Removing or installing the back cover.









- ③ Inserting or removing the SIM card.
- ⑤ Installing or removing the microSD card.

5095B

50951

User guide and FAQ are available online www.alcatelonetouch.com

