
## olcotel POP4

## QUICK START GUIDE





- 1. Inserting or removing the microSD card.
- Installing or removing the SIM card (only for 5056D,5056E, 5056J,5056T).
- 3. Installing or removing the SIM card.

5056A 5056A

User guide and FAQ are available online PAPER PAPER PAPER Www.alcatel-mobile.com SAVE PAPER PAPE