## **User Manual**

Model No.: HHRGB14

Transmitter Model No.: HHRGB14 is RF remoter control transmit device, it has eleven key with control signal, use the following:

## 1. Specification

Operational frequency: 433.92MHz

Modulation type: OOK

Rated Voltage: DC 3V

Rated current: 27MA

Operation temperature: -10°C-+70°C

- 2. Turn on transmitter shell behind the battery lid, put in a DC 3 voltage battery, attention to the positive and negative polarity, and to ensure good contact.
- 3. Select and press a transmit key, then the select control signal is transmitting, and the LED indicator is shined, the transmitter cease transmission after the key is released.
- 4. Please check the battery and replacement a new battery when the transmission distance too short and can't meet requirement.