Sound Oasis Bluetooth Speaker System BST-100

Revision: R1.0 Product Specification

Issue Date: June 05, 2013
Prepared By: Rudy Vandenbelt

Revision Modification Tracking:

1.0 - Initial Release


1. Standards:

1.1. The unit must meet the specific requirements listed below as compared to documentation provided and/or identified and approved samples. Documentation shall include any and all correspondence with Headwaters (USA) Inc., Headwaters Research & Development (Canada) Inc. regarding product specification and/or details.

2. Product Design & Details:

- 2.1. The unit shape details and finish must meet the approved standards as documented in the Industrial Design specifications. The final version of the Industrial Design specifications shall be mutually agreed upon by The MANUFACTURER and HEADWATERS in writing prior to the start of tooling and production.
- 2.2. Any deviation from the Industrial Design specifications shall require the written approval of Headwaters or its designated agent(s) prior to the implementation of the design. Headwaters shall not unreasonably withhold such approvals. Generally such changes will be related directly to mechanical design and /or manufacturability requirements.
- 2.3. All plastics shall be of the specified colors and shall not obviously deviate from the median of any sample. The plastic colors will be specified using supplied samples OR the PANTONETM color specification system. Headwaters will provide actual plastic color samples where possible and appropriate. The color of all molded parts shall be pre-approved by Headwaters prior to production. (The MANUFACTURER will supply plastic color proof sample for approvals when required.)
- 2.4. Headwaters will provide custom artwork for pad / hot stamp printing and product information tool inserts for specific customer requirements. A change of artwork and product color will require a minimum order of 2500 units (one time order) and 1500 pcs. (recurring orders.) Headwaters will incur film and set up charges for any changes in artwork or printing method.
- 2.5. The rights to the product Industrial Design and all related details shall remain the sole and exclusive property of Headwaters Research & Development (Canada) Inc. Use of the design or any of its specific elements requires the written authorization of Headwaters.

Figure 4.1 BST-100 Views



FRONT VIEW

Buttons L to R: Power – Select Back – Play/Pause – Select Forward – Vol. Down – Vol. Up – Mode Select



LEFT REAR VIEW

L to R: Headphone out - Micro USB - Audio Signal Input - Micro SD Card Slot



RIGHT REAR VIEW

L to R: Mode LED Bluetooth (Blue) - Mode LED SD Card (Amber) - Mode LED USB / Charging (Red) - Microphone

5. FUNCTIONS

5.1. Operating Modes

- 5.1.1. BLUETOOTH Playback from external device.
- 5.1.2. SD CARD Playback from SD Card
- 5.1.3. USB INPUT Playback from device via. USB (PC Speaker mode)

5.2. Auxiliary Input & Battery Charging

- 5.2.1. Auxiliary Input will have a mechanical switched over-ride of ALL other inputs to the amplifier circuit. The unit can be in ANY mode when the auxiliary input is being used.
 - 5.2.1.1. LED mode status light does not change when AUX input is plugged in (当输入线插入时,LED 不 会变颜色)
- 5.2.2. Charging of the battery will happen in any mode when a powered USB cord is plugged into the device.

5.3. Bluetooth Confirmation

- 5.3.1. Standard IC confirmation tone on Bluetooth connect.
- 5.3.2. Bluetooth Name on device = "Sound Oasis"

5.4. Start-Up (FACTORY) Default Settings

- 5.4.1. All sound output is off.
- 5.4.2. Volume Level = 1/3 of total range
- 5.4.3. SD Card installed
- 5.4.4. Battery Fully Charged

5.5. Initial Setup

- 5.5.1. Initial Startup: Plug in USB power cable and charge the battery.
- 5.5.2. Unit is OFF.
- 5.5.3. Battery is charging

6. OPERATION

6.1. On - Off

- 6.1.1 Press and hold (1 sec.) [On-Off] to turn the unit on. (standard IC power function) (按住 ON/OFF 键开关)
- 6.1.1. BLUETOOTH Mode is the default. The device will automatically connect to Bluetooth (solid blue LED) OR Bluetooth LED will flash and audio connect prompt signal will activate. (默认是蓝牙模式)
- 6.1.2. Press and hold (1 sec.) [On-Off] to turn the unit off. (standard IC power function)

6.2 Mode Function

- 6.2.1 Default = Bluetooth Mode
- 6.2.2 From any mode setting press [MODE] to select the next mode.
 - 6.2.2.1 Sequence Bluetooth (default) [MODE] SD Card [MODE] USB [MODE] Bluetooth
 - Bluetooth LED = Blue Color
 - SD Card LED = Amber Color
 - USB LED = Red Color. (same as charging)

6.3 Adjust Volume

- 6.3.1 Default volume setting = 1/3 total.
- 6.3.2 Press once [VOL DN] or [VOL UP] to reduce or increase volume one increment.
- 6.3.3 Press and hold **[VOL DN]** or **[VOL UP]** to reduce or increase volume continuously. (rate same as current sample ~ 3 steps per second.)
- 6.3.4 Minimum volume = barely audible in quiet room
- 6.3.5 Max volume per sample provided.

6.4 Playback

Same as sample provided.

END OF OPERATIONAL DESCRIPTION

Federal Communications Commission (FCC) Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by HEADWATERS INC. may void the FCC authorization to operate this device.

Note: The manufacturer is not responsible for any radio or tv interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.