

FCC TEST REPORT Report No.: EMC-FCC-R0175

User Manual





KI POP

Personal Loss-Prevention Kit

Quick Start Manual

WELCOME!

KI POP will protect your precious with following action.



If the smart device out of range, you'll get alarm from POP and smart device.


Up to 5 simultaneous connection

What you need

To use KI POP, you need:


- · Smartphone with Bluetooth enabled
- POP APP → Download from Google Play store or Apple APP Store (Search "KI POP" then POP app will appear on the list)
- · KI POP and CR2032 Battery(Battery Included with package)

KI POP overview



1. Battery Replacement





Remove Battery Holder Screw

Pull out Battery

Remove Used Battery and insert new battery.

(If you done it, The led will blinking)

Insert Battery Holder and fix the screw.

*CAUTION

Risk of explosion in battery is replaced by an incorrect type.

Dispose of used batteries according to the instructions.


*Environment

Product name (Model)	BlueTooth Anti-Loss Device (KI POP)
Operating Temperature	0 c°~60 c°
Battery	CR2032 Coin Battery

2. Pairing



Run App





Push the button on 'POP' Device 3 seconds at Sleep Mode, POP will go to pairing mode. → Tab Connect (If device is not shown, retry Scan Device)



Enter New Name




3. Change Alarming Distance



At Oevice information screen, you can change the distance.

4. Slip mode and reconnect



· Slip mode

Push and hold the button 5 seconds. Then you can hear short beep sound. LED go off.

· Reconnect

Tab Button : Reconnection Ready, If there are paired smartphone device it will automatically connect.

*If you Push the button 2 seconds, POP will go to pairing mode.

5. Remove POP and Re-Pairing

· Remove POP

For android >> swipe device name right, then delete button appears. Push will remove POP. For I phone >> swipe device name right, then delete button appears. Push will remove POP, Also you should delete POP in I phone follow this. I phone settings > general > bluetooth > remove POP

Re-Pairing
 After Remove POP, Follow 2. Pairing for Re-Pairing





<Swipe then delete button appears>

6. Trouble Shooting

· For I Phone

Remove All Device on POP application.

I phone Settings > general > bluetooth > remove all POP Pairing device.

· For Android

**Turn Off Wifi when pairing POP

Pop slip mode -> Exit APP then run -> remove registered device -> Follow 2. Pairing or

Pop slip mode -> reboot smart phone -> Exit APP then run -> remove registered device -> Follow 2. Pairing

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Caution: Any changes or modifications to the equipment not expressly approved by the party responsible for compliance could void user's authority to operate the equipment.