

Plug Load Controller Label Locations




Figure 5-1: Plug Load Controller – CCO Label Location





Figure 5-2 Plug Load Controller – Serial Number and SmartCast Version Labels Location












Figure 5-3 Plug Load Controller – Product Label Location