#### Play from an external device

If the music player does not supply the Bluetooth function, you can also listen to an external audio device through this speaker using audio 3.5mm cable ( not included )

- cable ( not included ).

  1. First connect the 3.5mm audio plug to the 3.5mm AUDIO output or earphone jack on an MP3 player, plug another 3.5mm jack to the AUX IN socket on your speaker.

  2. Speaker will switch to Line In mode automatically.

- Operate with switch of Life III mode automateurs.
   If you want to adjust the volume level of your speaker, only adjust the volume control on the connected MP3 player.
   If you want to Play/pause the music play, just control the native buttons on your MP3 player.

Note: In power on mode, the AUX in function is effective if the AUX in cable is connected although the Bluetooth indicator lights continually; the Buletooth function is effective if the AUX in cable is disconnected.



#### Care and maintenance Instructions:

When cleaning the unit, you should first unplug it from the power supply. Use When cleaning the unit, you should first unplug it from the power supply. Use only a dry soft cloth to wipe the unit. Never allow water or any other liquids to get inside the unit while cleaning. Do not use any cleaning agents containing alcohol, ammonia, benzene, or abrasives as this may harm the set. Unplug the unit if you are not using it for an extended period of time. This product is not intended for commercial use. Household use only. Trouble Shooting

Symptom	Possible problem and solution
Cannot pair successfully	Check whether the speaker is in power on and searching mode. Check whether there are too many Bluetooth receivers around your Bluetooth device. Turn them off to avoid any disturbance. And pair again.
The sound is small or distorted	Check the volume setting on your Bluetooth device and adjust the volume to a suitable level.
Cannot play properly, the music is intermittently	Check whether the distannce between the speaker and your Bluetooth device is out of its working distance 10m, or whether there are some obstacles blocking the communication between the speaker and the Bluetooth device. Move the speaker or the Bluetooth again to get the best position.
No sound from the speaker when playing music via bluetooth	Check the bluetooth is connected and the volume setting on your Bluetooth device. Check the AUX-IN cable is unpluged.

#### **Technical Specifications**

Model : BOOM DC power input : DC 9V 2A Speaker size : Dia 3" X 2

Bluetooth A2DP function
3.5mm Aux jack for connection to other MP3, CD, Laptop

Audio Output Power: 8W X 2 Working Distance in open air : < 30'

NOTE: As a result of continual improvements, the design and specifications of the product within may differ slightly to the unit illustrated on the packaging.

FCC ID: 2ACUH-BOOM

First device complies with part 15 of the FCC Rules. Operation is subject to the following two condition (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment operates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation if this equipment does cause harmful interference to radio or thevision reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

— Recrient or relocate the receiving aritema.

— Increase the separation between the equipment and receiver.

— Connect the equipment into a routlet on a circuit different from that to which the receiver is connected.

— Consult the dealer or an experienced radio TV technician for help.

Changes or Modifications not expressly approved by the party responsible could void the user's authority to operate this device

BOOM Wooden Bluetooth Speaker





# Bluetooth®

# Instruction Manual

Read this instruction manual before operating the appliance: and save it for further reference.

Congratulations on your purchase of this Bluetooth speaker for your iPod/ iPhone/iPad or mobile phone. You can enjoy audio from the compatible Bluetooth device or other audio devices. To get the most from your speaker system, please take a few minutes to read these instructions.

# Safety instruction

- Heed all warnings. \* Follow all instructions
- \* Do not use this device near water; clean only using a dry or slightly moist cloth.
- \* The appliance shall not be exposed to dripping or splashing and no
- objects filled with liquids, such as vases, shall be placed near the product.
- \* Do not place speaker on any wet surface.
- \* Do not allow children to play with the product.
- \* Do not cover the unit with any table-cloths, curtains, etc. Place the unit
- where there is good air circulation.

  \* No naked flames sources, such as candles, should be placed on the
- product. \* Press the player's buttons gently. Pressing them too hard can damage
- the player. \* Do not use the player in an extremely dry environment, as this can lead
- to static discharge which can damage the player.

  \* Do not expose product to temperatures above 35C; keep it out of direct
- sunlight.
  This product has no user-serviceable parts. Do not attempt to repair this
- product yourself. Only qualified service personnel should perform servicing.
- \* Care required with the use of this apparatus in tropical and/or moderate
- \* Do not subject the product to harsh impacts. Do not drop the appliance. This may result in damage to the product.
- ' Use a slightly damp, lint-free cloth to clean this appliance.
- This product is not intended for commercial use. This product is intended for indoor. Do not mount this product on a wall or ceiling.
- \* Do not place unit near TV, speakers, wireless telephones and other
- objects that generate strong magnetic fields. When the unit is affected by a strong electromagnet field or by other
- interference simply turn off to reset the speakers, it will return to normal
- \* Do not use this product inside hospital or next to any medical instrument

#### The standard accessories

Unpack the unit carefully. We recommend that you save the box and packing materials, in case you wish to store the unit.

Before setting up the unit, verify that the following accessories are present








3/ Instruction Manual

#### Features





FCC ID: 2ACUH-BOOM

AUX IN

AUX IN

DC IN

- 2. Press and hold the power switch to turn on the speaker. The blue LED
- 2. Press and note in epower swinch to turn on the speaker. The blue LED indicator will be flashing shows Bluetooth pairing.
  3. The Speaker starts searching for Bluetooth device.
  4. Turn on your Bluetooth device (iPod/iPhone, mobile phone or compatible device). Refer to the device user manual to activate the Bluetooth function and pair with the Bluetooth device.
- For Apple iPhone select Settings, General, Bluetooth and wait for the iPhone to search for the device
   Select the "BOOM" device from Bluetooth list, Tap the "Not Connected"

3

to pair the device.
7. Once paired the LED indicator will stop the flash.





- When paired successfully both the speaker and your Bluetooth device will store the device. Now you can play music from your iPod/iPhone or mobile phone through the Bluetooth speaker.

  When it is not being used for a long period time, please turn off the speaker.

# Listening to Bluetooth device

You can listen to a Bluetooth device through this speaker.

Note: the effective operation range between the speaker and your Bluetooth

- device is approximately 10 meters in open air.

  1. Switch on to turn on Bluetooth function. Activate the Bluetooth function in your Bluetooth device. Play music from your Bluetooth device and enjoy it on your Bluetooth speaker.
- To adjust speaker volume by touch and slide on the Bluetooth Speaker.
- To Pause and resume play of the music track, press the Play/Pause on the Bluetooth Speaker.

If the device has already been paired to the speaker before, then just select GROOVE and it will pair again.

2