Manual for Bluetooth speaker

This mini audio box can be deemed as perfect combination of classic and modern performance, New aluminum vibration film loud speaker, which has clear alt and pure woof. that you can take with your enjoy anywhere.

FEATURES:

- 1. Portable speaker for your smartphone, tablet, laptop, or MP3 Player.
- 2. Lightweight, small in size, but incredible sound.
- 3. Metal housing provides protection and great sound.
- 4. Up to 3-5 hours playback time, once a full charge.

COMPONENTS INCLUDED

- 1.Mini speaker
- 2.3.5mm Audio + Micro USB charging combination cable
- 3.User Manual
- 4.lanyard

SPECIFICATIONS:

Power supply:	DC5V
Output power:	3W
Frequency:	200Hz20KHz
Signal&noise ratio	≥75dB
Impedance:	4 OHM(Ω)
Output:	3.7V~4.2V+0.05V
Input:	5V
battery capacity:	500mah
Speaker Unit:	45mm
Bluetooth version	V2.1+EDR
Transmission Distance	10 meters
Case Material:	Aluminum case
Dimensions:	5cm x 5cm x 5.3cm
Weight:	110g





USER GUIDE:


Button decription:

- 1, "VOL+" press for volume increase
- 2, "VOL-" press for volume decrease
- 3. press for next song.
- 4. press for last song
- .5. short press for pause or answer / off the phone; Long press for change model.

The interface description:



The charging and line in combination port



OFF ON on /off switch

Under BT Model:

Put switch to "on" position, the blue light quickly flashes. Bluetooth pairing with your device. After a successful connection, the blue light slowly flashes, sound will be issued" dong" a tone. When your device is playing, the speaker will immediately sound of music.

Long press disconnect bluetooth to "line in" mode

Under Line-in Model:

AUX audio playback: appendix provides the 3.5mm Audio + Micro USB charging combination cable. Can play music by link to mobile phone、MP3、MP4、PC、IPOD and other audio devices.

Long press disconnect "line in" to bluetooth mode.

Reminder:

In the AUX state, "VOL-, VOL+, " 2 key is valid, But the last and next song is controlled by the connected device.

SAFETY CAUTIONS:

- 1. Please read the instructions carefully before using.
- 2. Avoid contact with liquids; keep away from water and high moisture conditions.
- 3. Do not locate the speaker or cord near heat sources such as radiators, heaters, air ducts. or direct sunlight.
- 4. Do not place a naked flame source such as candles on the Mini Speaker.
- 5. Recharge the battery with suitable voltage output(5V/500mA)
- 6. Do not hit the product severely, or insert any conductive objects into the speaker, or charging jack.
- 7. Do not block the speaker grill when the speaker is running.
- 8. Stop using at once if high temperature, smoke, burning smell, nor-normal noise, or fire are noticed coming from product.
- 9. Do not repair on your own, seek the help of a professional.
- 10. To avoid getting shocked, do not touch product with wet hands.
- 11. Keep out of reach of children.

TROUBLESHOOTING

No Sound:

- 1. Audio cable is not fully plugged into the 3.5mm audio port on device.
- 2. Audio cable is damaged.
- 3. Source of audio is not working.
- 4. No LED indication when audio cable is plugged-in.
- 5. Mini speaker is out power.

Not charging:

- 1. Input power source is not normal(5V/500mA)
- 2. Combination cable is not fully plugged into the charging port.
- 3. Combination cable is damaged.
- 4. Battery failure.

No LED indication:

- 1. LED indication failure.
- 2. No battery power left.
- 3. Combination cable is not fully plugged into the socket.

FCC INFORMATION

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. If this equipment does cause harmful interference to radio or television

reception, which can be determined by tuning the equipment off and on, the user is encouraged to try correct the interference by one or more of the receiving measures:

Reorient or replace relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment..

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.