MK-SPB11 User Manual Greyscale Printing Double side printing

OUTSIDE

DATE: 02/11/14

Fold line

Speaker Specifications:

Output Power: 1.5W (1 channel) Frequency Response: 100Hz to 14KHz Dimensions (WxHxD): 2.75in x 2.75in x 3.2in Weight: 245g

Battery Information:

Built-in Battery: Lithium Input: DC 5V/500mA Battery Capacity: 400mAH Music playing time: Up to 6 Hours* Charging time: 2 hours

*Approximate playback time. Battery life depends

on individual use and may be slightly more or less than the time specified.

Bluetooth Information:

Bluetooth Specification: V2.1

Operating Distance: 10 Meters (Class II)

System Requirements: Bluetooth-capable device

Additional Connection Sources:

Audio Source: Via micro USB to 3.5mm auxillary cable (included) Power Source: Built-in rechargeable battery or via USB cable

CC Notice

This device complies with Part 15 of the FCC Rules. Operation is subject

- to the two following conditions:

 1. This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

Tankainal Cumpari

Please do not attempt to fix the product by yourself. If you are experiencing any problems with the product, please do not return it to the store you bought it from. You can contact our technical support representatives and they will assist you with any questions you might have.

For assistance operating your product, please consult the User's Manual first, then feel free to contact Merkury Innovations technical support:

Merkury Innovations

39 Broadway, 15th Floor

New York, New York 10006

www.merkuryinnovations.com E-mail: support@merkuryinnovations.com

©2014 Merkury Innovations.

To explore our full selection of products, visit us at: www.merkuryinnovations.com

Bluetooth is a registered trademark of Bluetooth SIG, Inc. Official licensed product of Haas Outdoors, Inc., West Point, MS 39773. Distributed by Merkury Innovations LLC.The illustrated product and specifications may differ slightly from those supplied. All other trademarks and trade names are those of their respective owners.

Made in China



MERKURY

Bluetooth CAMO

Portable Wireless Speaker User's manual for MK-SPB11



Package Includes: 1 Bluetooth Speaker

1 Micro USB to USB & AUX Cable

Features

- Automatically reconnects with the last connected Bluetooth device.
- Rechargeable battery provides up to 6 hours of continuous playback.
- Included 2-in-1 cable connects to USB charger to recharge speaker, as well as connects to any 3.5mm audio jack to provide a wired audio input.

BACK COVER

Fold line

COVER

 Plug the micro USB cable into the micro USB port on the side of the speaker, and connect the other end of the cable to either a computer USB port or to a USB-compatible car or wall charger.

Charge It

- Solid red LED light will appear on the bottom of the speaker to indicate when the speaker is charging even while speaker is turned off.
- speaker is charging, even while speaker is turned off.

 When charging is complete, the red LED light will turn off.
- When charging is complete, the red LEDCharging time is approximately 2 hours.

Turn It On

• Switch the power button on the bottom of the speaker from the "OFF" position to either the "** " position to play audio via Bluetooth, or to the "AUX" position to play audio via the included micro USB to AUX cable.

Pair & Connect

- Power the CAMO on (refer to the "Turn It On" section) to the Bluetooth position.
 The LED on the bottom of the speaker will start to quickly flash blue. The speaker is
- now ready to be paired.
- On your Bluetooth-enabled smart phone, tablet or media player, navigate to the Bluetooth settings menu, turn on the Bluetooth feature, and search for new devices.
- After a few seconds you will see "MOSSY OAK SPB11" listed.
 Tap this model to select it, the speaker will emit a beep and the Bluetooth LED will

3.5mm auxillary jack at the other end of the cable to your device's audio jack.

blink slowly to indicate that it has been successfully paired with your device.
If using AUX, connect the included micro USB cable to the micro USB port on the side of the CAMO, and slide the power switch to the AUX position. Then connect the

Play

- Connect your device to the CAMO via Bluetooth (refer to the "Pair & Connect" section)
 or via the included micro USB to AUX cable.
- or via the included micro USB to AUX cable.

 Open your favorite music app and press play.
- Open your ravorite music app and press play.Control your track and volume from your device.
- All audio, including music, games, videos, and notifications will be routed through the CAMO.

Reconnect to Bluetooth

- You only need to pair your Bluetooth device with the CAMO once.
 With your previously paired device's Bluetooth turned on and in range.
- With your previously paired device's Bluetooth turned on and in range, power on the CAMO.
- The speaker will automatically reconnect to the last Bluetooth device it was connected to.
- If you have a previously paired device that does not auto-reconnect, navigate to the Bluetooth settings menu on your device, turn on the Bluetooth feature, and select "MOSSY OAK SPB11" from your list of paired Bluetooth devices.

Troubleshooting


No power

Recharge your CAMO using the included micro-USB cable.

Music is not playing over Bluetooth

Make sure your Bluetooth device has A2DP profile. Check if both devices are paired and connected over Bluetooth. Restart the CAMO to reconnect your Bluetooth device.

Bluetooth device will not reconnect with the speaker Navigate to your Bluetooth settings menu on your Bluetooth device, tap "MOSSY OAK SPB11", and select "Forget". Now follow the steps to pair your device again.



INSIDE

FCC STATEMENT

- 1. This device complies with Part 15 of the FCC Rules.
- Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class C digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However,

there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.
- 3. FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure requirement.

The device can be used in portable exposure condition without RF striction.