




Channel 118 (5590MHz)




Channel 134 (5670MHz)




Channel 142 (5710MHz)





Channel 151 (5755MHz)




Channel 159 (5795MHz)







Channel 100 (5500MHz)



Channel 118 (5580MHz)




Channel 120 (5600MHz)




Channel 140 (5700MHz)





Channel 149 (5745MHz)




Channel 157 (5785MHz)








Channel 100 (5500MHz)




Channel 118 (5580MHz)




Channel 120 (5600MHz)



Channel 140 (5700MHz)



Channel 149 (5745MHz)



Channel 157 (5785MHz)

