




Channel 100 (5500MHz)




Channel 120 (5600MHz)




Channel 140 (5700MHz)




Channel 144 (5720MHz)





Channel 149 (5745MHz)




Channel 157 (5785MHz)









Channel 134 (5670MHz)



Channel 142 (5710MHz)



Channel 151 (5755MHz)



Channel 159 (5795MHz)

