




### Channel 100 (5500MHz)




### Channel 116 (5580MHz)




### Channel 120 (5600MHz)




### Channel 140 (5700MHz)




### Channel 144 (5720MHz)







### Channel 118 (5590MHz)




### Channel 134 (5670MHz)




### Channel 142 (5710MHz)







### Channel 100 (5500MHz)




### Channel 116 (5580MHz)




### Channel 120 (5600MHz)







### Channel 140 (5700MHz)




### Channel 144 (5720MHz)






**Channel 118 (5590MHz)**

**Channel 134 (5670MHz)**

**Channel 142 (5710MHz)**





### 802.11a Power Spectral Density - Ant 1 / Ant 1 + 2 (CDD Mode)


#### Channel 36 (5180MHz)




#### Channel 44 (5220MHz)




#### Channel 48 (5240MHz)




#### Channel 52 (5260MHz)




#### Channel 60 (5300MHz)




#### Channel 64 (5320MHz)




### Channel 100 (5500MHz)




### Channel 116 (5580MHz)




### Channel 120 (5600MHz)



### Channel 140 (5700MHz)



### Channel 144 (5720MHz)




### 802.11n-HT20 Power Spectral Density - Ant 1 / Ant 1 + 2 (CDD Mode)

#### Channel 36 (5180MHz)




#### Channel 44 (5220MHz)




#### Channel 48 (5240MHz)




#### Channel 52 (5260MHz)




#### Channel 60 (5300MHz)




#### Channel 64 (5320MHz)




### Channel 100 (5500MHz)




### Channel 116 (5580MHz)




### Channel 120 (5600MHz)



### Channel 140 (5700MHz)



### Channel 144 (5720MHz)



### 802.11n-HT40 Power Spectral Density - Ant 1 / Ant 1 + 2 (CDD Mode)

#### Channel 38 (5190MHz)




#### Channel 46 (5230MHz)




#### Channel 54 (5270MHz)




#### Channel 62 (5310MHz)




#### Channel 102 (5510MHz)




#### Channel 110 (5550MHz)



### Channel 118 (5590MHz)



### Channel 134 (5670MHz)



### Channel 142 (5710MHz)

