



Channel 106+122 (5530MHz) - Ant 0




Channel 106+122 (5530MHz) - Ant 1




Channel 106+122 (5610MHz) - Ant 2



Channel 106+122 (5610MHz) - Ant 3








Channel 106+138 (5530MHz) - Ant 0




Channel 106+138 (5530MHz) - Ant 1




Channel 106+138 (5690MHz) - Ant 2




Channel 106+138 (5690MHz) - Ant 3








Channel 106+155 (5530MHz) - Ant 0




Channel 106+155 (5530MHz) - Ant 1




Channel 106+155 (5775MHz) - Ant 2




Channel 106+155 (5775MHz) - Ant 3







Channel 122+138 (5610MHz) - Ant 0




Channel 122+138 (5610MHz) - Ant 1




Channel 122+138 (5690MHz) - Ant 2




Channel 122+138 (5690MHz) - Ant 3








Channel 122+155 (5610MHz) - Ant 0




Channel 122+155 (5610MHz) - Ant 1



Channel 122+155 (5775MHz) - Ant 2




Channel 122+155 (5775MHz) - Ant 3








Channel 138+155 (5690MHz) - Ant 0



Channel 138+155 (5690MHz) - Ant 1



Channel 138+155 (5775MHz) - Ant 2



Channel 138+155 (5775MHz) - Ant 3

