

User Manual


Content


1. Overview	1
1.1 What it is	1
1.2 Features	2
2. Getting Started	4
2.1 Install App	4
2.2 Connect Wi-Fi	4
3. Photo Management	5
3.1 Backup the camera photos via USB······	5
3.2 Backup SD/CF Card·····	5
3.3 Start the app	6
4. Using as an external hard drive	7
5. Charge ······	8
6. Appendix	9
6.1 License Agreement And Terms Of Use	9
6.2 limited warranty1	1

1. Overview

1.1 What it is

As an essential tool for every traveling photographer, MPortable allows you to backup, view and organize raw photos. The perfect partner to your digital SLR camera, this powerful device makes it easier than ever to backup and view thousands of photos on the spot.





1.2 Features

- (1) It supports the backing up photos by plugging the SD card into the card port.
- (2) It supports viewing and managing the photos via tablet or smartphone.
- (3) It supports raw file formats. It will output the thumbnail of the raw files and extract the EXIF information to show.
- (4) The USB 2.0 port is used for charging other electronic device and data backup from the camera.

- (5) It can be used as a high-performance portable drive.
- (6) User can access all the files saved on the device with smartphone or tablet, such as office documents, videos, and music.

2. Getting Started

2.1 Install App

MPortable supports iOS and Android. Users may download the apps at the link: www.majcbox.com/en/mportable.html or scan the QR code to go to the web page to install.



After installing the app, users can tap the icon below to start.



2.2 Connect Wi-Fi


After turning on the power, you may scan the Wi-Fi network named MPortable XXX a few seconds later with your iPad or smartphone. The Wi-Fi password will be blank when you first use the device by default. You may change it later via Settings->Wireless Settings.

3. Photo Management

3.1 Backup the camera photos via USB

Using the USB wire to connect the camera and MPortable, turn on both the camera and MPortable.

The photos will be copied into MPortable automatically. You may check the backup progress by app.



USB port to connect with camera

3.2 Backup SD/CF Card


Just put the SD/CF card in the card port and turn on MPortable, and the photos will be piped into MPortable automatically. You may check the backup progress by app.

3.3 Start the app

- 1. Connect the Wi-Fi of MPortable with an iPad or other smart devices.
- 2. Tap the installed app icon. Albums sorted by the taken dates will be shown.

4. Using as an external hard drive


- 1. Turn off the power of MPortable,
- 2. Use a USB 3.0 wire to connect the computer and MPortable.
- 3. Access the storage as an external hard drive.



USB 3.0 port to connect with computer

5. Charge

Charge your MPortable by plugging your MPortable power adapter into an electrical outlet. You can also charge your MPortable or transfer data to it by connecting the USB cord to a computer's USB port.



USB 3.0 port to charge

6. Appendix

6.1 MPortable: License Agreement And Terms

Of Use

BEFORE USING THE MPORTABLE DEVICE, PLEASE READ THE LICENSE AGREEMENT AND TERMS OF USE LOCATED AT WWW.MAJCBOX.COM/MPORTABLE/TERMS AND ALL RULES AND POLICIES FOR THE MPORTABLE DEVICE AND SERVICES RELATED TO THE DEVICE (INCLUDING, BUT NOT LIMITED TO, THE MAJC PRIVACY NOTICE LOCATED AT WWW.MAJCBOX.COM/PRIVACY AND ANY RULES OR USAGE PROVISIONS SPECIFIED ON THE WWW.MAJCBOX.COM WEBSITE OR THE MPORTABLE STORE) (COLLECTIVELY, THIS "AGREEMENT").

IF YOU DO NOT ACCEPT THE TERMS OF THIS AGREEMENT, YOU MAY RETURN THE MPORTABLE DEVICE AND ASSOCIATED SOFTWARE (WITH ALL ORIGINAL PACKAGING, MANUALS, AND ACCESSORIES) WITHIN THIRTY (30) DAYS OF PURCHASE FOR A REFUND OF ITS PURCHASE PRICE IN ACCORDANCE WITH THE MPORTABLE RETURN POLICY.

Contact Information. For communications concerning this

Agreement, you may contact MAJC by writing to majcbox.com, Attn:
Legal Department, Room A10, Floor4, Building B, Science&Technology
Road #10, Tangjia, Zhuhai, China

6.2 limited warranty

This Warranty for the MPortable Device (the "Device") is provided by MAJC Information Technology Co. Ltd. The provider of this warranty is sometimes referred to herein as "we." We warrant the Device against defects in materials and workmanship under ordinary consumer use for one year from the date of original retail purchase. During this warranty period, if a defect arises in the Device, and you follow the instructions for returning the Device, we will, at our option and to the extent permitted by law, either (i) repair the Device using either new or refurbished parts, (ii) replace the Device with a new or refurbished Device, or (iii) refund to you all or part of the purchase price of the Device. This limited warranty applies to any repair, replacement part or replacement Device for the remainder of the original warranty period or for ninety days, whichever period is longer. All replaced parts and Devices for which a refund is given shall become our property. This limited warranty applies only to hardware components of the Device that are not subject to accident, misuse, neglect, fire or other external causes, alterations, repair, or commercial use.

Instructions. For specific instructions about how to obtain warranty service for your Device, please contact Customer Service using the contact information provided in this guide. In general, you will need to deliver your Device in either its original packaging or in equally protective packaging to the address specified by Customer Service.

Before you deliver your Device for warranty service, it is your responsibility to back up any data, software, or other materials you may have stored or preserved on your Device. It is possible that such data, software or other materials will be lost or reformatted during service, and we will not be responsible for any such damage or loss.

Limitations. TO THE EXTENT PERMITTED BY LAW, THE WARRANTY AND REMEDIES SET FORTH ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES AND REMEDIES, AND WE SPECIFICALLY DISCLAIM ALL STATUTORY OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, WARRANTIES limited warranty

FCC Certification Requirements

Caution: Any changes or modifications in construction of this device which are not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.