

2GIG COMPATIBLE

Thanks for choosing the Versa Wireless PRR Motion Detector. This sensor monitors movement, and send signal when movement is detected inside the building. System comes with pet mode build inside for optional function.

Description & Specifications


* For indoor use only.



cy Range 345MHz 19 Range Up to 100 feet line of sight 19 Temp 5°F (+15°C) - 104°F (40°C) Panasonic CR128A	Specifications		In The Box
	Frequency Range	345MHz	1 Pc Versa Wireless PIR
5°F (-15°C) - 104°F (40°C) Panasonic CR123A	Operating Range	Up to 100 feet line of sight	1 Pc CR123A Lithium Battery
Panasonic CR123A		5°F (-15°C) - 104°F (40°C)	1Pc Installation Guide (here)
	Battery	Panasonic CR123A	1 Set Accessory bag (includes 2 jumper header, 2

Installation


- 1. Release cover tab to open the cover.
- Before inserting the CR123A battery, decide whether this device needs to be activated when "Stay Arm Mode". In normal case, PIR will not activate when user stays at home while arming the system. However, some area user won't even entry, so Versa Wireless PIR will let user choose whether sensor should be activated while stay arm.
- The factory default will be "Away Arm Mode", if this is not the function you need, you can change the jumper as the "Esty Arm Mode" or "Per Mode". The per mode won't be able to detect the pet about "Bla and under, but it will also depend on the actual size of pet. Please refer to drawing below. m



- Close the cover back to sensor. 4.
- 5. To HS 512/514 home security controller into learning mode. Press "Program Switch" on the back of the Versa Wireless PIR to learn device

Mounting Suggestion: 9

- Li Use either the screws or adhesive tape to mount the bracket of the Versa Wireless PIR onto the wall or the corner.
 Slide down and clip the Versa Wireless PIR into the bracket.
- 3. Mount the Versa Wireless PIR 2 meters high from the ground for best performance purpose. The solid area means the detector's coverage range.
- 4. To release the Versa Wireless PIR, press the tab of the bracket and slide the sensor from the bracket. Please refer to mounting method below.



Adhesive Tool Nathod L. Sock the Tape right on the makis of Resche. Nathod Z. Cir. apost the Tape and stock them on both wides of Bashel

20.00

- 4. If pet in house, user can choose "pet mode". Please refer to Installation
 - If PIR motion sensor is in low battery status, it will report a message to controller, and LED will flash five times. Please change the battery.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (I) This device may not cause through ult interference and (2) This device must accept any interference reci including interference that may cause undestined operation.

FCC Caution

responsible for compliance may void the user's authority to operate his equipment. (Example – use only shielded interface cables connecting to computer or peripheral devices)

This Class [B] digital apparatus complies with Canadian ICES-003.

- Walk in front of the Versa PIR, sensor will send the signal to system, and the LED will flash once.
 - 2. Normal operation, the LED will not light.
- The Versa PIR is equipped with tamper switch. If the cover of sensor is removed, the PIR sensor will report a zone tamper to the controller, and the LED will flash once.
- section.

FCC Statement

ompliance, any changes or modifications not expressly approved by the party

IC Statement

