## **User Manual**

## Model:OWN F1313

Weight: 76.5g(with battery) Size: 119.5\*48\*11.5mm Battery: 4.2 Li-on For the network: 2G: 850/1900Mhz 3G:850/1700/1900Mhz Battery refer to the following table:

Battery Type	Battery Capacity	Talk time	Standby time
Li-battery	1000mAh	8h(2G) 4h(3G)	About 260h

Battery Manufacturer: Guizhouhangtian
Electric core mode: 523450ART/4.2V/1000mAh
Notice:
The actual condition for mobile phones using has the
relation to the network of the local environmental
conditions, SIM card and the way using.
Warning:
For the consequences result by violating the
following recommendations or using mobile phones
In accurately, the manufacturers has no
responsibility. Explain: If relate to the upgrades,
without notice. The Company has the right for the
final interpretation of this statement.

# Table of Contents Moblie Appearance picture

1.	Quick start	7
	Keypad Explain	7
	Install SIM card	8
	Install T-flash card	8
	Installing Battery	9
	Battery Charging	
	Switching on	
2.	Call function	10
	Dialing	
	Receiving	
3.	Menu functions	
-	Contacts	
	Message	
	Call history	
	Email	
	Browser	
	Facebook	
	Settings	
	Camera	
	Music	
	FM radio	
	Gallery	
	File manager	
	Bluetooth	
	Calendar	
	Alarm	

Calculator		16
Games		16
SIM		16
4.	Accessories	18
5.	SAR	19

### Foreword

Honorific mobile phones user, thank you for choosing our

mobile phone!

Our cellular phones is according with the communication industry standards of PRC, and also according with the standards of European, and are approved for GSM networks.

Your phone may be used internationally with various networks depending on your roaming arrangements with

networks depending on your roaming arrangements with your service provider.

To use this phone you must subscribe to a GSM service from a provider. We have included many features in this device but their function depends on the features

available with your subscribed wireless network. Please contact your service provider for more information.

We strongly recommend you carefully read and understand this manual before using your phone in order to keep it under best conditions for your effective usage and utmost satisfaction.

### Safety

Never attempt to disassemble your phone. You alone are responsible for how you use your phone and any consequences of its use.

As a general rule, always switch off your phone wherever the use of a phone is prohibited.

Use of your phone is subject to safety measures designed to protect users and their environment.

Do not use your phone in damp areas (bathroom, swimming pool...). Protect it from liquids and other moieture. moisture.

Do not expose your phone to extreme temperatures lower than - 10°C and higher than + 55°C.

The physicochemical processes created by chargers

impose temperature limits when charging the battery. Your phone automatically protects the batteries in extreme temperatures.

Do not leave your phone within the reach of small children (certain removable parts may be accidentally ingested). Electrical safety

Only use the chargers listed in the manufacturer's catalogue. Using any other charger may be dangerous; it would also invalidate your warranty. Line voltage must be exactly the one indicated on the charger's serial plate. Aircraft safety.

Aircraft safety
When traveling by plane, you will need to switch your phone off when so instructed by the cabin crew or the warning signs. Using a mobile phone may be dangerous to the operation of the aircraft and may disrupt the phone network.

Its use is illegal and you could be prosecuted or banned from using cellular networks in the future if you do not abide by these regulations.

Explosive materials

Please comply with warning signs at petrol station when personnel asking you to switch your phone off. You will need to comply with radio equipment usage restrictions in places such as chemical plants, fuel depots and at any location where blasting operations are under way. Electronic equipment

To avoid the risk of demagnetization, do not let electronic devices close to your phone for a long time. Electronic medical equipment

Your phone is a radio transmitter which may interfere with electronic medical equipment or implants, such as hearing aids, pacemakers, insulin pumps, etc. It is recommended that a minimum separation of,15 cm be maintained between the phone and an implant. Your doctor or the

manufacturers of such equipment will be able to give you any advice you may need in this area.

Hospitals

Always make sure that your phone is switched off in hospitals when so instructed by warning signs or by medical staff.

Road safety

Do not use your phone when driving. In order to give your full attention to driving, stop and park safely before making a call. You must comply with any current legislation.

a call. You must comply with any current legislation.

Distance of operation
This phone model has been tested and meets radiofrequency exposure guidelines when used
As follows:

-Against the ear: place or receive a phone call and hold the phone as you would a wire line telephone.
-Body worn: when transmitting, place the phone in a carry

Body worn: when transmitting, place the phone in a carry accessory that contains no metal and positions the phone a minimum of 1.0cm from your body. Use of other accessories may not ensure compliance with radiofrequency exposure guidelines. If you do not use a body worn accessory and are not holding the phone at the ear, position the phone a minimum of 1.0 cm from your body.

body,
Data operation: when using a data feature, position the phone a minimum of 1.0cm from your body for the whole duration of the data transmission.

Environmentally friendly disposal



inendly disposal

Old electrical appliances must not be disposed of together with the residual
waste, but have to be disposed of separately. The disposal at the communal
collecting point via private persons is for free. The owner of old appliances is
responsible to bring the appliances to these collecting points or to similar
collection points. With this little personal effort, you contribute to recycle
valuable raw materials and the treatment of toxic substances.

## 1. Quick start

Keypad Explain

Key	Function description
Left softkey	Enter the notification screen
Right softkey	In home screen, press the key enter the shortcut settings screen, other screens, back to home screen.
Green key	Answer the incoming call, and in the home screen, press the key enter the call history direct.
Red key	Reject the incoming call, and in the home screen, short press screen off, long press to power off.
Navigation key	Up/Down/Left/Right move the high light
Center key	Confirm the select to enter function
Number key	Input the corresponding character
*key	Dial pad input star character

Short press to input # character, long press # key to switch the profiles

## Install SIM card

This phone supports one GSM SIM cards. Find SIM card's groove in the back of the phone and slide it completely there. During installation, please make sure the chip is facing downwards and pay attention to slot direction.

### Note:

- Keep SIM card out of children's touch.
   Any abrasion or folding could easily damage SIM card, so please be extremely careful when you
- insert, Remove and preserve it.

  3. Please make sure that you have cut off the power supply and have taken out battery before you remove SIM card.

  Install T-flash card

- First switch off the phone and remove the battery.
   Push the metal card holder toward the bottom of the phone and lift the released end of the holder.
- 3. Place the memory card into the holder with the metal contacts face down and push the holder until it locks into place.

- 1.To avoid damaging memory card, please do not plug memory card fast or frequently.
   2. Please regularly backup information in the
- cards on other equipment when you use Cards like T-flash! Improper use or other uncertain factors may cause the damage or loss to the

### content in the cards.

### Installing Battery

Align the battery chip with the metallic salient point in battery jar, insert the battery until it is inserted into the battery jar. Slide battery cover into back of the phone until

Battery Charging
Unclose dustproof soft gum of attachment mode on the bottom of the phone, insert one end of the charger, i.e., the charging plug into attachment mode and the other end into electrical outlet, Screen will display the charging sign. After charging is finished, just pull out the plug.

### Note:

- 1. Please use the standard battery and charger, or
- Please use the standard battery and charger, or may explode.
   If the battery is completely discharged, the battery icon should be in charge after 2 to 3 minutes to appear. Generally based on the current state of the phone (if boot, call, etc.) of different charging time for 2 to 5 hours.
   Please use the charger, charging as much as possible to avoid using USB cable.
   To ensure optimal battery performance, the completion of two to three times the battery charge and discharge cycles. Several new battery initial charge, please charge more than 10 hours straight.
- straight. Switching on

Long press the Red key to switch your phone on

### 2. **Call function**

### Dialing

1. Direct dial

1. Direct dial
In standby mode, press the corresponding number keys to
enter the phone number that you want to dial, including
necessary area codes. Short Press the Right soft key
[Clear] to delete one character, and Long Press delete all inputs, press the Green key to dial.

2. Making an International Call: To make an international call, long press [0] key until the prefix symbol "+" of international call displays in screen.

3. Dialing from Phonebook

Enter the Phonebook via the menu, use the Up/Down Navigator keys to scroll to the desired contact, or press the first letter of the name of the desired contact as saved in your phonebook for quick access to names beginning with the letter then scroll to the desired, press the green key to dial.

4. Dialing from Call history
Enter the Call center (press the Green key from standby
or via the menu), use the Up/ Down navigation keys to scroll to the desired contact, press the green key to dial.

You can directly dial the emergency service number without SIM card. Different networks use different urgency service numbers, so for details please inquire the network operation company.

Receiving
When there is an incoming call, the phone will give corresponding alert, if your network supports caller ID, the screen will display caller's name or number (depending on whether there is information of the caller in your

### 3. **Menu functions**

The Phone for your well-prepared high-capacity phone storage space. You can use the phone's contacts feature to save the contact name, number and caller ring-tone. Enter the contacts screen, there have three labels on the screen, press the left/right navigation key to switch the label.

**Message**Message service is a network dependent function, which allows you to send, receive and edit all kinds of messages. Please contact the network operator for more details. Edit a new message, save or send it to the recipient.

To send SMS, you need to set the correct SMS service center number which can be obtained from network provider.

Call history
This phone can record all received, dialed and missed calls as well as their call time. Only when related function is supported by network and phone is switched on and in network service area, it can record the answered and

network service area, it can record the answered and missed calls. Call records may be accessed by pressing the Green key from standby.

In the call history list ,press the left/right navigation key, switch to Display list of all /dialed/missed/received calls.

Once on the call records list, press the Green key to make a call; press the Center key to view the details of current call record. call record.

### Email

Your cell phone for your built-in E-mail function, you do not take any action anywhere to view internal documents, e-mail through the mobile network, approval, reply, forward, etc. operating

### Browser

The Internet is the combination of wireless communicate -on and Internet application platform that enables you to get rich by phone and ecommerce and other Internet information resources application.

### Note:

- Note:

  1. Your ISP may not support some features, in order to ensure the normal operation of the browser, make sure your SIM card is supported and open Internet access.

  2. If you browse the web, you need to charge fees
- related to traffic.

Your phone has built-in Facebook application, Use the function to chat with friends or others by connected the

Settings
Wireless& network: include SIM management, wifi, bluetooth, data usage etc. you can enter the corresponding menu to opera.

Device: include audio profiles, display, storage and battery,

you can enter the corresponding menu to opera.

Personal: include location, security, language& input, backup& reset, you can enter the corresponding menu to opera.
Accounts: you can add personal account to use.

System: you can set the date and time, and set the scheduled power on  $\!\!\!$  off.

### Camera

Your phone is fitted with camera allows you to take photos whenever possible. You can store the pictures in phone or

customize the wallpaper.

Press the center key to take photo, press the left/right navigation key switch to video record.

Your music is organized into four categories: Artists, Albums, Songs, and Play lists. Select a category to view the lists within each. Once in a category, keep selecting until you reach the music you want to play.

FM radio
FM radio is supported by the phone. You just pull the
bottom of the antenna and no need plug in your
headphones to listen to FM Channel
Note: Quality of radio subscription is possible
influenced by environment like indoor or under shield.
You can improve this situation as following: stand closer to the window, adjust the position of earphone line or adjust the channel manually

Gallery
You use Gallery to view pictures that you've taken with Camera, downloaded, or copied onto your SD card or USB storage; you can also view pictures in a Picasa web album. You can perform basic editing tasks on pictures and set them as your wallpaper or contact picture. You can also share your pictures with friends, via email or messaging, or by uploading them to the Picasa and YouTube web sites.

### File manager

In document management, you can open files in the Phone or Memory card, you can select file or folder to

Phone or Memory Card, you can select me or loader to view.

This phone supports movable storage, i.e., the U-disk function. When the phone is switched on, you see the icon in the status bar on the top of the screen when its connected to a PC by a data line. Select [USB connected] and touch [Turn on USB storage] to confirm, you can use the phone as a LL-disk the phone as a U-disk.

### Bluetooth

The phone supports Bluetooth (BT) functions, you can establish a wireless connection between the phone with other compatible devices, and data transmission, you can establish a wireless connection between devices in the phone with a distance of up to 10 meters. Bluetooth connection may be interference by obstacles, such as walls or other electronic device.

- 1. Enter the setting menu, Touch the Bluetooth to open the function, idle screen will display BT icon in the status
- bar.
  2. Open the BT discoverable, and other devices can
- Open the BT discoverable, and other devices can search the phone.
   Before using the phone as a Bluetooth device, you need to pair the phone with the target device as follows:

   Sure your phone has Bluetooth-enabled.
   Touch "Scan for devices." Bluetooth devices within the range of the phone will start scanning.
- -Touch the device you want to pair, to confirm password to complete the pairing
  You can use Bluetooth to share the pictures, videos or

music files with family and friends

### Calendar

Choose to enter the calendar, the screen will display the system date on the calendar month, and have a background box marked the current date.

### Alarm

You can use the phone as alarm clock, this feature allows you to set time arrives, make the phone ring or vibrate to remind issue. When the alarm is turned on state, the alarm symbol is displayed in the top of the screen.

### Calculato

Into the calculator, the calculator interface:
Press 0 - 9 number keys to enter the number to be
calculated, press the navigation key to select the location
on the screen corresponding to add, subtract, multiply and
divide symbols for computing.

### Games

The phone offers you a built-in game-loft, specific game and instructions please refer to the help in each game.

### SIM

The phone supports value-added services provided by the SIM, different network operators to provide different types of services, and the menu is shown only if your SIM card supports. The name and contents of the menu depend on the available services. Ask your network availability, price, and information on the SIM card service operators Advisory.





## 4. Accessories

Use only batteries, chargers, and accessories approved by the manufacturer with this device. Use of any other types will invalidate the warranty and may be dangerous. Check with your dealer for available accessories. You may

Check with your dealer for available accessories. To a line, opt to buy:

Charger Plug, charger cable

Charger plug used to connect with the charger cable for charging on wall outlets. Also you can use the charger cable to connect with the other devices such as the personal computers to charge the phone.

Charging time is about 2 to 3 hours. The charging condition is displayed on screen. You may use your phone while charqing.

while charging.

Earphone
A mini, practical, hands-free device; you can use its button to answer and end calls. Some models may also come

with a volume control knob.

Do not plug or unplug the earphone when connecting dialed or incoming calls.

Please to adjust the incoming call alert volume to the felicitousness before you plug in the earphone.

## CAUTION RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

## 5. SAR

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received,

including interference that may cause undesired operation. FCC ID: 2ADA4OWNF1313

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that

interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ---Reorient or relocate the receiving antenna.
- ---Increase the separation between the equipment and
- ---Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. ----Consult the dealer or an experienced radio/TV technician for help.

Body-worn Operation

Body-worn Operation
This device was tested for typical body-worn operations.
To comply With RF exposure requirements, a minimum separation distance of 1.0cm must be maintained between the user's body and the handset, including the antenna.

antenna.

Third-party belt-clips, holsters, and similar including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided.

Specific Absorption Rate (SAR) information:

This wireless phone meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health. FCC RF Exposure Information and Statement The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. The highest SAR value reported under this standard during product certification for use at the ear is 0.97W/kg and when properly worn on the body is 1.17W/kg. The use

of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.



- To prevent possible hearing damage, do not listen at high volume levels for long periods.
   Fully understand user manual before use.
   Ensure your player at low volume levels or power off before you leaving.