EUT inside whole view



Main board component side



Antenna Location



Main board solder side