

ATMOSFX®

SONICSTONE™ BLUETOOTH ROCK SPEAKER



USER MANUAL

Please read carefully before using the speaker

MADE IN CHINA

SECTION 1: SAFETY AND KIT INFORMATION	
1.1 SAFETY INFORMATION	2
1.2 SONICSTONE BLUETOOTH ROCK SPEAKER ACCESSORIES	2
1.3 FUNCTION BUTTONS	3
1.4 LED INDICATOR LIGHTS	4
SECTION 2: USING THE SONICSTONE BLUETOOTH ROCK SPEAKER	
2.1 GETTING STARTED	4-5
2.2 POWERING ON AND OFF	5
2.3 HOW TO CONNECT BLUETOOTH INPUT	5
2.4 HOW TO CONNECT AUDIO CABLE INPUT	
SECTION 3: TROUBLESHOOTING	
3.1 TROUBLESHOOTING	6
SECTION 4: TECHNICAL AND COMPLIANCE INFORMATION	
4.1 TECHNICAL SPECIFICATIONS	
4.2 US FCC STATEMENT	7-8
4.3 ATMOSFX INC LIMITED WARRANTY	

SECTION 1: SAFETY AND KIT INFORMATION


1.1 SAFETY INFORMATION

- FOR ADULT USE ONLY. NOT INTENDED FOR OPERATION BY CHILDREN WITHOUT ADULT SUPERVISION.
- To prevent electric shock, always charge the speaker with the provided adapter indoors, in a dry environment and away from water sources.
- When the power adapter is used as a power source, the speaker should only be used indoors and away from water sources.
- The speaker is rated IP66 (water and dust proof) for water spray and should not be immersed in or submerged under water.
- The power input inlet should always be plugged with the provided rubber plug when the speaker is not being powered. Damaging or losing this plug will affect the IP66 rating.
- Failure to use the adapter and power cord provided may create a fire hazard and may void warranty.
- To conserve energy, please turn off the speaker when not in use.
- Keep the speaker away from high heat, open flame and radiation.
- Tampering with or opening the device housing will void all manufacturer warranties.
- The built-in lithium ion battery is designed to be recharged only; do not try to replace.
- If you find any operational defects, do not attempt to repair. Turn off the speaker and disconnect from the power adapter.

1.2 SONICSTONE BLUETOOTH ROCK SPEAKER ACCESSORIES

- AC-DC Power Adapter (UL/CUL for US/Canada)
- 3.5mm Audio Cable (15 feet (4.6 meters) length)
- Instruction Manual

1.3 FUNCTION BUTTONS



- 1. **POWER INPUT**: DC 9V, 2A power supply adapter (provided)
- AUDIO INPUT JACK: Connects to 3.5mm Audio Cable (provided) (Note: audio playback may be delayed by a few seconds when switching between Bluetooth input and Audio Cable input)
- 3. **POWER**: Press and hold for 2 seconds to turn the speaker ON/OFF
- PAIR: Press to cut off the current Bluetooth signal and wait for new pairing
- VOLUME : Press to decrease sound volume (notification alert stops when lowest setting is reached)
- PLAY / PAUSE: Press once to pause the sound; press again to resume playing
- VOLUME + : Press to increase sound volume (special notification alert sounds when highest setting is reached)
- 8. MODE: Switch between Bluetooth input and Audio Cable input

1.4 LED INDICATOR LIGHTS

Power button lights RED:

- Indicates battery is charging;
- Lights up when adapter is connected to SonicStone.

Mode button lights GREEN:

- Indicates Mode switched from Bluetooth to Audio Cable input;
- Lights up when Mode button has been pressed to switch to Audio Cable input.

Mode button lights BLUE:

- Indicates Bluetooth pairing status;
- Lights when Power button is first pressed and Bluetooth default setting activates, or when Mode button has been pressed to switch from Audio Cable input to Bluetooth;

FAST FLASHING BLUE = Bluetooth pairing in process

SLOW FLASHING BLUE = Bluetooth paired

CONSTANT BLUE = Bluetooth audio playing

SECTION 2: USING THE SONICSTONE BLUETOOTH ROCK SPEAKER

2.1 GETTING STARTED:

- Prior to using the speaker for the first time, it is recommended to fully charge the battery. Connect the power adapter to the speaker power input and plug the power adapter into the AC power source. When charge is in process, the RED charging indicator light will be on. When the charge is completed, the RED charging indicator will turn off. Normal full charge time is around 5 hours.
- Place the speaker on a stable surface. Position the speaker and your Bluetooth-enabled device (such as ATMOSFX Digital Decorating Kit PLUS or your smart phone) no more than 3 feet (0.9 meter) apart for the initial pairing process.

 Once paired, ensure the speaker and the paired Bluetooth device remain no more than 98 feet (30 meters) apart. Obstructions may cause shorter sensing distances.

2.2 POWERING ON AND OFF:

Power ON: Press Power button on the speaker for about 2 seconds. BLUE indicator light will be on and you will hear a notification alert for successful power on.

Power OFF: When speaker is ON, press Power button on the speaker for about 2 seconds to put speaker into standby status (BLUE indicator light will turn off) and you will hear a notification alert for successful power off. DO NOT restart the speaker within 30 seconds. To power off speaker completely, the power adapter should be disconnected.

Warning: Failure to use the provided adapter and power cord may create a fire hazard and void any warranties.

2.3 HOW TO CONNECT BLUETOOTH INPUT:

- Once the speaker powers on, it will automatically enter Bluetooth pairing mode. A pairing notification alert repeatedly sound as will a fast flashing BLUE indicator light. Place the speaker and the Bluetoothenabled device no more than 3 feet (0.9 meter) apart. Activate your Bluetooth-enabled device and select "AtmosFX SonicStone" for pairing.
- When pairing is complete, you will hear a notification alert and see a slow flashing BLUE indicator light.
- If pairing is not completed successfully, the speaker will power off automatically after about 2.5 minutes.

2.4 HOW TO CONNECT AUDIO CABLE INPUT:

You can also connect the speaker to Audio Cable line input using the 3.5mm Audio Cable (provided). Connect the line-out socket of your audio source to the "AUDIO IN" jack on the speaker. Then press the "MODE" button to switch between Bluetooth input and Audio Cable input, and you will see the GREEN indicator light.

SECTION 3: TROUBLESHOOTING

Unable to connect the speaker to your Bluetooth device?

- A. Check that the power of both the speaker and the Bluetooth-enabled device is on.
- B. Check that the speaker volume is not on mute (lowest volume setting).
- C. Ensure the source device's Bluetooth feature is activated.
- D. Ensure the speaker is within a maximum of 98 feet (30 meters) from the Bluetooth-enabled device, and there are no obstructions in between, such as thick solid wall or other electronic devices, which may cause shorter transmission or interference.
- E. Check that no other device is already connected with the speaker.
- F. Check that no other devices are attempting to pair with the speaker.
- G. If all the above steps do not resolve the problem, please turn off the speaker for several minutes and restart the Bluetooth connection process again. However, interoperability between the speaker and other Bluetooth-enabled products is not guaranteed because this depends on compatibility.
- H. If pairing the speaker with the AtmosFX Digital Decorating Kit Plus after the speaker has been paired with other Bluetooth-enabled devices, first power off the speaker for several minutes and then power on again to restart pairing with the Digital Decorating Plus Kit.
- If the Bluetooth connection with the Digital Decorating Kit Plus has been interrupted, you will hear the pairing failure notification alert and it will cut off automatically within 2.5 minutes; or you can turn off the speaker and restart for new Bluetooth pairing.
- J. For additional troubleshooting tips, visit https://support.atmosfx.com

SECTION 4: TECHNICAL AND COMPLIANCE INFORMATION

4.1 TECHNICAL SPECIFICATIONS

Bluetooth Version	Bluetooth 4.0	
Effective Range	30 meters in open area	
Speaker	3.5" Hi-Fi speaker, RMS: 15W, Max: 30W	
Line Input	Audio In Cable and 3.5mm Jack	
Waterproof Rating Level	IP 66 (not to be submerged)	
Built-in Battery	Rechargeable 7200mAh lithium ion battery	
Playing Time	About 10~18 hours after full charge	
Charging Time	Continuously about 4-5 hours for full charge	
Power Adapter	Input AC:100~240V,50/60HZ Output DC:9V,2A	
Operating Temperature	-14℃ to 50℃	
Product Size	195(W)x165(D)x203(H) mm	
Product Net Weight	1.52kgs	
Accessories	UL/CUL Adapter, Audio Cable (15feet), Instruction Manual	

4.2 US FCC STATEMENT

FCC ID 2ADC2-AFXG025

This device complies with Part 15 of FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in

accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: reorient or relocate the receiving antenna; increase the separation between the equipment and receiver; connect the equipment into an outlet on a circuit different from that to which the receiver is connected; consult the dealer or an experienced radio/TV technician for help.

Warning: You are cautioned that any changes or modification not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

This equipment complies with FCC RF exposure limits for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

5.4 ATMOSFX INC. LIMITED WARRANTY

The language contained below is subject to change. For the most up-to-date information regarding AtmosFX Inc's Limited Liability, visit www.atmosfx.com.

AtmosFX Inc. warrants all AtmosFX products that are subject to this Limited Warranty ("Warranted Products") against defects in material and workmanship for 30 days after receipt of shipment. This Limited Warranty extends to the first consumer purchaser of the applicable Warranted Product from AtmosFX. Only items that have been purchased directly from AtmosFX are governed by this Limited Warranty. AtmosFX products purchased through other retailers must be returned in accordance with that retailer's respective replacement and refunds policy.

All AtmosFX Limited Warranties are non-transferable. For clarity, this Limited Warranty does not apply to resellers of AtmosFX products.

Products that are not Warranted Products include: AtmosFX digital downloads and other non-physical goods (including any software embedded in an AtmosFX product); AtmosFX products not purchased directly from www.AtmosFX.com; AtmosFX products purchased as "Final Sale" items; products featuring AtmosFX content or using AtmosFX registered trademarks but not produced by AtmosFX Inc.

AtmosFX's Limited Warranty shall not apply to product that has been damaged through misuse, abuse, accident, modifications, alterations, neglect, mishandling, or faulty installation.

If you believe an AtmosFX product you purchased is subject to a manufacturer defect and you are within the 30-day warranty period, please contact us, using the contact information set forth at the end of this Limited Warranty or visit http://support.atmosfx.com/ and complete the "Contact Us" form. A representative will contact you and direct you through the warranty process.

Do not return products to AtmosFX without first contacting a support representative as this may void your warranty claim. Any products shipped back to AtmosFX will be at the expense of the customer. Cost of shipping for warranty replacements back to the customer will be paid for by AtmosFX.

Disclaimer; Limitation of Liability

TO THE EXTENT PERMISSIBLE BY APPLICABLE LAW, THIS LIMITED WARRANTY AND ANY IMPLIED WARRANTIES ARE YOUR EXCLUSIVE WARRANTIES AND REPLACE ALL OTHER WARRANTIES OR CONDITIONS, EXPRESS OR IMPLIED. SOME STATES OR JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, THE EXCLUSION OF IMPLIED WARRANTIES, OR THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU. YOU MAY ALSO HAVE OTHER RIGHTS THAT VARY FROM STATE TO STATE AND JURISDICTION TO JURISDICTION.

AtmosFX's Limited Warranty is governed by the laws of the State of Washington. For more information about the Limited Warranty, visit www.AtmosFX.com.

Warrantor: AtmosFX Inc Seattle, WA 98107 info@atmosfx.com