



EN IP Camera Quick Start Guide























Copyright

@ 2017 TENVIS. all right reserved. All text instructions on product information and services are protected by copyright or other intellectual property, any use of the text instructions without TENVIS's authorization is illegal.

Here TENVIS stated, without the license of TENVIS, everyone is prohibited copying the instruction in any way by any means, for transcription electronic, mechanical, optical and other commercial purposes.

Welcome


Thanks for your support to TENVIS IP camera, if you have good suggestions or questions to our products, please contact us in time. It's our pleasure to offer you a good service.

Product Feature


1280X720
1280X960
1920X1080
Support Wi-Fi smart link
10m/32feet
Support max 128GB SD card (excluding Micro SD)
Support alarm through Micro SD card, App, E-mail, FTP
H.264
25 fps
WPA/WPA2/WPA-PSK/WPA2-PSK
2.4Ghz
Support

▲ Attention: The actual resolution of the camera is based on the device itself.

Package contents



- Fixed Camera
 - 100V~240V AC 50~60Hz mains adaptor / 5V DC 1A
- Wall plugs for attaching the base
- Screws for attaching the base
- Quick Start Guide
- Reset Pin










PT Camera
Wall mounting bracket
100V~240V AC 50~60Hz mains adaptor / 5V DC 1A
Screws for attaching the base
Wall plugs for attaching the base
Quick Start Guide
Reset Pin

▲ Attention:

If anything is missing or damaged, please contact your dealer immediately for replacement.

IP Camera Overview



Operating System Requirement

The app is compatible with Android 2.3+ and IOS 7.0+.

App Setup and Camera Connection

Before beginning the setup process, your phone must be connected to a Wi-Fi network.

Download App

Two ways:

Install "iMegaCam" from the app Store or Google Play Store. Scan the corresponding QR code to download and install the app.





Connection to power

Plug a power cable to camera, and then wait for a while until the camera exits a beeping sound.

▲ Attention: If there is no beeping sound, press the reset button and hold it for approximately 10 seconds until there is a successful music.


Connection to Internet

Before you start:

- If you want to set the IP camera via Wi-Fi, please refer to Section 1;
- If you want to set the IP camera via Ethernet cable, please refer to Section 2.

Section 1 Wireless Connection to Internet

After running the "iMegaCam" app, please use the following steps:



Scan camera UID

NO QR Code? click here.

Enter Wi-Fi password



Section 2 Ethernet cable connection to Internet Connect camera to router with an Ethernet cable.

(A Attention: This method only works for camera with RJ45



Add camera in App

After connecting to Internet, please add camera in the "Add Camera" page.

Three ways for adding camera:

- 1.Scan
- Search and add existed camera from LAN.

Function Introduction

Add Camera Interface



Wireless Installation: Connect camera to Wi-Fi with the one-key configuration. For details, refer to Section 1, Wireless Connection to

Scan QR code: Scan the QR code at the bottom of the camera to get UID.

Internet.

LAN Serach: Search the


Camera Interface



- **①Edit:** To delete or change the name, UID, password and other configuration of camera.
- ②Add Camera: To add the camera
- ③Vision: To see real-time video
- **4 Settings:** To set the camera's functions.
- ⑤ Picture: To browse snapshot pictures.
- **®Video:** To watch stored videos stored in a cell phone or an SD card
- **7About:** To check the app's version information

EN-8

Real-time viewing Function



- ①Image Rotate: Click the button to flip and invert the pictures in the video.
- ②Preset: After presetting the position needed to monitor, click to view the position quickly.
- ③Exit: Click the Exit button and return to the camera interface.
- 4 Listen: Listen to the sounds around camera.
- ⑤Speak: Push to speak to camera.
- Snapshot: Snapshot real time pictures and transfer to smartphones.
- ⑦Record: Record the video and transfer to the cell phones.
- quality: High Definition (HD) or Standard Definition (SD)
- Pan & Tilt: Slide the phone screen vertically or horizontally to the correct shooting position.