
User Manual of IP Fusion Curve

Install the P2PWIFICAM in the APP market.


- 1 Turn on electric with camera. Waiting for it at least 30s to 1minute. And if the blue is flickering, it means the camera is working now. Since the camera has been set when tested, please click on the button on the back (a small hole) of camera for 2-3 seconds. Then it will flashing regularly which means it works.
- 2 Then search the your camera in your smart phone. Which means search Wifi, its name is IPCAM-AP, each camera has different names. Connect the Camera AP.



Then open the P2PWIFICAM in your phone, Scan the camera. Input the password:admin Click the blue icon.




Then Click the WIFI Setting.



Choose your local WIFI.



Input the password. Click Done



*when the light keeps flashing very quickly, which means it is difficult to search the wifi, in this case, please try more than one times.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter should be installed and operatated with a minimum distance of 20 centimeters between the radiator and your body and must not be co-located or operating in conjunction with any other antenna or transmitter.

Caution!

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.