

# Getting Started With Your




nuu  
mobile

www.nuumobile.com

## Z8 Overview

### Front/Back



## Setting Up Your Phone

Follow these step-by-step instructions to set up your Z8.  
Power off the phone and remove battery **before** inserting any cards!

- 1 Remove Back Cover
  - Remove the back cover by prying any corner of your device with your fingers.
- 2 Insert microSD™ Memory Card
  - Power off the phone and remove battery before inserting memory card.
- 3 Insert SIM (Dual SIM standby)
  - Orient SIM card to match diagram on slot.
  - SIM 1 (micro) supports 4G LTE connections
  - SIM 2 (micro) supports 4G LTE connections
- 4 Insert the Battery
  - Align the battery contacts, then insert the battery contact-first.




**Warning:** SIM cards are small enough to become a choking hazard, so please keep them away from children. SIM cards are also quite delicate. Please be careful when handling your card.

## Welcome to Your Z8

Follow on-screen instructions to complete initial setup. Simply follow the on-screen instructions.

- 1 Tap to Wake
  - With the LCD off, simply double tap the screen of your locked phone to wake it up.
- 2 Home
  - Tap at any time to return to the central Home screen. Press and hold to view recent apps.
- 3 Back
  - Tap at any time to return to the previous screen.



## Basic Controls

### HotKnot™

Your phone is equipped with gesture controls to quickly and easily access features and settings.

- Tap-to-Wake: With the LCD off, simply double tap the screen of your locked phone to wake it up.
- Select the media you wish to share and simply hold the screens of two HotKnot-enabled devices less than one centimeter apart and the media will appear.
- Wave-to-Mute: Wave your hand in front of the screen to mute the ringer.
- To power off or reboot your phone, press and hold the Wake/Sleep button, then select your desired action/response from the list.
- Back: tap at any time to return to the previous screen.

- To Lock, press the Wake/Sleep button.
- Swipe up to unlock your phone.
- Swipe to the left to enable camera.
- Swipe to the right to enable phone.




## Voice Search

### Google Now

Google Now is your personal digital assistant. It uses location reporting and history to provide you with easy access to weather, traffic, scores, and other ongoing events. When a notification arrives, the corresponding icon will appear at the bottom of every Home screen.

- Recent: tap to see previously opened applications.
- Home: tap at any time to return to the central Home screen. Press and hold to view recent apps.
- Wave-to-Mute: Wave your hand in front of the screen to mute the ringer.
- To expand a notification, drag-n-drop the icon by slowly swiping downward. When finished, either swipe it away or tap the dismiss all button.




## Gesture Control

### Phone

Make and receive phone calls via the following methods:


- Speed Dial: one-touch dialing for favorites and numbers you call frequently.
- Recents: view call log. Tap an entry to redial.
- Contacts: view your contacts. Tap a contact to call.
- Keypad: manually enter phone numbers.
- Flip-to-Mute: Flip the phone over to mute the ringer.
- O-to-Open Camera: With the LCD off, draw an "O" on the screen to open the camera.
- Shake-to-Light: Shake the phone in lock screen state to toggle the flashlight.



### Voicemail

To access your voicemail, press and hold 1 on the keypad.

Voicemail number and setup will vary by provider.



Access voicemail

### Messaging

Send an SMS or MMS to another mobile phone user by tapping the Messages icon.

Type name or phone number in the To field or select someone from Frequent or All Contacts. Type your message, add desired attachments (by tapping the paperclip icon), then tap Send.




Attachments  
Send

### Email

You can set up your account in just a few steps.

Simply follow the on-screen instructions:




Account setup  
Email account  
Email address  
Send button

### Camera

Use the built-in camera to take pictures or record videos. To access the camera from the lock screen, swipe from right to left. From the Home screen, tap the camera icon.


Modes: Motion Track, Live Photo, PIP, Normal.



Motion Track  
Live Photo  
PIP  
Normal  
Settings  
Video  
Camera

### Chrome

Use Menu to access a new tab, bookmarks, history, reload a page, request a desktop version of the site, and change other settings.



Omnibox  
Address bar  
Search field  
Locate icon  
Directions icon

### Google Maps

Browse the web with Chrome by tapping the Chrome icon. Type an address or search term into the Omnibox to get started.

Use Menu to access a new tab, bookmarks, history, reload a page, request a desktop version of the site, and change other settings.




Google Maps  
Omnibox  
Address bar  
Search field  
Locate icon  
Directions icon

### Play Store

Google Play allows you to download apps, music, movies, and games directly to your device.

To access the Google Play Store:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.



Play Store  
Drawer  
Categories  
Address bar

### FCC Information

Limited Two Year Warranty Information

**FCC STATEMENT**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

FCC RF Warning Statement: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC that it does not exceed the limit established by the government adopted requirement for safe exposure. The tests are performed in positions (e.g., at the ear and worn on the body) as required by the FCC for each model.

from that to which the receiver is connected. Consult the dealer or experienced radio/TV technician for help.

Google Maps  
Omnibox  
Address bar  
Search field  
Locate icon  
Directions icon

### Warranty Information

**WARRANTY REGISTRATION**

Register Your Device

Thank you for choosing NUU Mobile. To receive helpful tips and faster tech support, register your device online at [www.nuumobile.com](http://www.nuumobile.com)

**Customer Support**

Questions? Let us help. We're here to support you.

**Phone:** Toll Free: 844-NUU-3365  
507-529-1441  
U.S. hours: M-F 8:00am-4:30pm CT  
See our website for after-hours support.

**Email:** [support@nuumobile.com](mailto:support@nuumobile.com)

Learn more about NUU Mobile products, features and accessories at [www.nuumobile.com](http://www.nuumobile.com)

The complete user manual for the NUU Mobile Z8 can be found online at [www.nuumobile.com](http://www.nuumobile.com)

NUU Service Center: 3111 19th Street NW Rochester, MN 55901-6606 USA Phone: 844-688-3365

NUU mobile

