

Quick guide

The contents of this manual may different in certain respects from the description of your phone depending on its software version and your telephone operator.

English

How to use the phone keys

In any screen, Tap ("< ", "< ", "< ", "="), to return to previous screen or exit the application.

Tap("o", "o", "o") Home Key, to return to the main menu. Tap("...","...."," o"," ∈ "), to display the settings/option list. Tap the "on/off" button, to turn on or off the screen and block the screen.

Long press " on/off " to shut down or to restart your mobile.

Press and hold the "on/off" button and then press the volume down key to take a screen capture.

Language

Tap the settings icon. Scroll down and tap the "Language and input", then choose language in the field "language".

Calls

Press the "contact" icon, email, message or any number on the phone to make a phone call. Or make a phone call by inputting the number on the dial keyboard on the "dial" application.

Message

Tap the "Messaging" icon to send messages to your contacts. Input a name or a number on the receiver field or choose someone from your contact list, then press the send button after writing your message.

Press the "

" button if you want to attach a picture, a video, a file, etc...

Writing and copying a text

Mobile phone will make recommendation while you write. If you want to copy or cut a text, long press the text for a few seconds and use the selecting arrows to select, or the "select all" options and copy or paste your text.

Camera

Tap the "camera" icon to open the camera. Mobile phone supports a variety of picture modes, HDR panoramic, automatic smile mode, etc... Voice control allows to take group or family pictures without having to touch the phone.

Gallery

Video camera

Tap the "Camera" icon to open the camera and switch to video mode. Tap "

to record videos.

Mail

Tap the "Email" icon. After setting your email account, you can send and receive emails in your phone anywhere you are.

Music

Tap the "Music" icon, and listen to your music. Playlist can be categorized by artists, albums and others.

FM Radio

Connect the earphones to the audio jack, tap the "Radio" icon and select frequency.

Theme

Tap ("...","...."," = ") and in the main screen, select "Wallpaper", select a picture and then tap "Set as wallpaper".

Guía rápida

El contenido de este manual podría diferir del de su teléfono en función de la versión del software o de su operador de teléfonia.

España

Botones exteriores

En cualquier pantalla:

Pulsa ("<", "<", "=") para volver a la pantalla anterior o salir.

Pulsa ('o', 'o', 'a') tecla de inicio para volver a la pantalla de inicio.

Pulsa("...","...."," ⇒ "," ≡ ")para acceder a las opciones de configuración. Pulse "on/off" para bloquear o desbloquear la pantalla.

Mantenga pulsado "on/off" para apagar o reiniciar el teléfono.

Pulse "on/off" y el boton de bajar el volumen para realizar una captura de pantalla.

Idiomas

Pulse el icono de "Ajustes" y entre en la opcion de "idioma y entrada de texto" Para cambiar de idioma.

Hacer Hamadas

Pulse el icono de contactos, email, mensajes o cualquier numero de teléfono en el móvil para realizar una llamada. También puede hacer llamadas usando el teclado en la aplicación "Teléfono".

Mensaje

Pulse el icono de mensajes para enviar un mensaje a un contacto. Escriba un numero de teléfono o un nombre en el campo "recipiente" o escoja un contacto de la lista de contactos, a continuación escriba el mensaje que desea enviar y pulse el botón de enviar. Pulse "

" si quiere añadir , fotos, videos, etc...

Escritura y copia

Teléfono móvil hace recomendaciones al escribir. Si quiere copiar un texto, púlselo durante unos segundo y a continuación podrá copiarlo o cortarlo.

Grabación

Pulse el icono de "cámara" para tomar una foto. El Teléfono móvil incluye una variedad de modos inteligentes, HDR panorámico, modo sonrisa. El control por voz permite realizar fotos en grupo y familiar sin tocar el teléfono.

Galería de fotos y edición

Vídeo

Pulse el icono de "cámara" para iniciar la cámara, cambie a modo grabación. Pulse "

para grabar vídeos.

Enviar Email

Pulse el icono de "email" y después de configurar su cuenta podrá recibir y enviar correos electrónicos desde su móvil.

Musica

Pulse el icono de "Musica" y disfrute de su musica ordenada por artistas álbumes y otras categorías.

Radio FM

Inserte los auriculares en el conector. Pulse el icono de "Radio" para escuchar la radio.

Cambiar de fondo de pantalla

Pulse ("--"." -- "." = ") y elija una imagen para establecerla como fondo de pantalla.

FCC Caution:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF Exposure Information and Statement?

This LTE/WCDMA/GSM MOBILE PHONE meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

FCC RF Exposure Information and Statement The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: Elite 4 (FCC ID: 2ADKW-LEAGOO-ELITE4) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at the ear is 0.712 W/kg and when properly worn on the body is 1.234 W/kg. This device was tested for typical body-worn operations with the back of the handset kept1.0cm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 1.0cmseparation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 1.0 cm must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.

IC

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

LEAGOO Mobile Phone Getting Started Guide

Note: Our products uses "dual SIM dual standby but single pass" design, it means, the two SIM cards can not be used at the same time, neither phone call, nor internet.

Designed by LEAGOO Made in P.R.C