(BLACK AND WHITE, DOUBLE SIDED-PRINTING)

105(H) x 297(W) mm



INSTRUCTION MANUAL

Thank you for purchasing the PULSE Wireless Earbuds.


This manual provides more information about the wireless earbuds, please read the instructions before using.

Earbuds Overview



Earbuds Overview





Power On/Off

Power on

Press and hold down the On/Off Button for 3 seconds and the LED will flash.

Power of

Press and hold down the On/Off Button for 4 seconds and the LED will turn off.

Pair PULSE Wireless Earbuds with your mobile device

- Keep the distance between your wireless earbuds and mobile phone (or other devices) within 32.8 Feet.
- 2. Power on the PULSE Wireless Earbuds
- 3 Activate the Bluetooth function on your phone within range and select "PULSE WIRELESS EARBUDS" from the list shown.
- 4. The LED blinks in blue when paired successfully.
- Attention: If the pairing is not successful within 10 minutes, the earbuds will
 power of, please repeat the pairing procedures to try again.

Reconnect PULSE Wireless Earbuds to your mobile device

 When powered on, the earbuds will automatically connect with the last successfully paired device.

Disconnect the earbuds from your mobile device

- · Power off the earbuds; or
- · Switch off the Bluetooth on your mobile phone; or
- ◆ Leave the earbuds 60ft away from your mobile phone or further.

Answer/Reject a call

- When you receive a call, press the On/Off Button once to accept the call, or answer the call normally via your mobile phone.
- ◆ Long press On/Off Button to reject a call

End a call

◆ Press the On/Off Button once to end the call or hang up your mobile phone.

Functions

- ◆ Short press + Button to turn up volume
- Short press Button to turn down volume
- ◆ Long press + Button to advance to next song
- ◆ Long press Button to go back to previous song

Charging your Earbuds

- ◆ LED indicator light turns red when charging your earbuds
- ◆ LED indicator light turns off when your earbuds are fully charged

Technical specification

Bluetooth Version:	4.2
Bluetooth Operating Range: 32.8 Fe	eet
Frequency Response: 20Hz - 20K	Hz
Playing Time: 2 - 2.5	hrs
Charging Time: 2	hrs
Battery Capacity: 55m	Αh
Rechargeable Li-Ion Battery 3.	7V

FAQ

Micro USB Charging Cable:

USB Plug

- If the PULSE Wireless Earbuds cannot be paired with your device, please try the following:
- Ensure that your earbuds are in pairing mode or reconnection mode.

 Ensure that Bluetooth search function of your mobile device is activated
- ◆ If the PULSE Wireless Earbuds will not turn on:

Micro USB Plug

- Make sure the earbuds are fully charged.
- ♦ Can I change the battery for the earbuds?
- PULSE Wireless Earbuds use a built-in non-detachable battery which cannot be removed.
- ◆ If the PULSE Wireless Earbuds cannot be recharged:

If you use a power outlet, ensure that the power supply is connected securely and the outlet works. If you use a computer, ensure that it is connected and the USB port is powered.

 \triangle Safety instructions for the lithium battery and charging the product

-The input voltage to the product is 5V 1A.

-In order to charge the product in safe manner and reliable conditions, please only adopt certified appropriate charger/ adapter for charging the product. -Only charge the product at ambient temperatures between 10 deg °C/ 50 deg °F and 40 deg °C/104 deg °F.

-Do not heat above 70 deg °C/158 deg °F, eg. Do not expose to sunlight or throw into fire.

- -Switch off the product after use
- -Please note that we won't take any responsibility for any wrong operation (e.g. Voltage higher than 5V) as this may result in severe injury or loss of property, and we cannot control the operating process during the time the user using this product.
- -In extreme cases, abuse or misuse of Lithium battery pack can lead to explosion, heat generation, fire development or smoke development.

FCC STATEMENT

- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID: 2ADM5-EP-0538

Distributed by Five Below Merchandising, Inc. 1818 Market Street, Suite 2000 Philadelphia, PA 19103 Made in China

Visit us at: www.fivebelow.com

Keep all relevant information for future reference