H6816 Bluetooth Speaker
Operation Manual

Product features

Hi-Fi bluetooth phone call Edition V3. 0+EDR
Bluetooth music play for cellphone
Play MP3 music directly from TF
card, automatically decoding
Supporting audio line in/out with PC/mobile phone
Double-bass
NFC Fast connection

Product parameters

Working Range: 10m
Speaker: 52MM
Max.Power: 4W
Frequency Range: 100Hz-16KHz
Signal/Noise: ≥85db
Distortion: ≤ 0.5%
Battery Voltabe Capacity：1000mAH
Battery Charging Voltage: 5V-500mA
Battery Charge Time: 4H

Detailed list

USB line for chargingx1、audio linex1、user manualx1
Penx3

Caution

There is built-in lithium battery in the speaker
Do not disassemble or replace the battery.
Do not put the speaker in high temperature
environment or throw it into fire

Function description

1.power on/off
2.function control
3.USB charging port
4.TF card port
5.line in/out
6.microphone

Charge description

a please fully charge the battery before first
   operation of the device
b Connect with PC USB port while another end
   connecting with the device, and the Blue LED lights
   up indicating charge status and lights out after the
   device is fully charged

Note

A This bluetooth speaker can only connect with one
   bluetooth device a time, if connect it with other device
   power off the speaker and repeat the pairing steps
   said above
B This bluetooth speaker can only connect with one
   bluetooth device a time. if you do not know if the speaker
   is connected with other devices, please stop the
   connection between them and connect it with the
   desired device. The maxium distance between the
   2 bluetooth devices is 10 meters
C If there is other bluetooth device in operation nearby
   interference may happen if there is any mistake
   transport between your desired devices,move away the
   bluetooth device to avoid interference among them

Bluetooth connection

a Power ON and Hear the voice
b 30 seconds later, LED flashes in color between
  blue and green, and the alert sounds "PARING"
  indicating that the speaker turns into paring mode
c turn on the bluetooth on/off key to search the
  model No. HMG 6816 in the device and click
  Connection to connect the bluetooth device
  with the bluetooth speaker. Input 0000 as
  pairing code if necessary until "Pairing
  Completed"sounds
  indicating that pairing is completed
d pairing mode may last for 60 seconds if the
  connection fails, the LED will flashes 5 times
  and the speaker turns into standby mode.
  The speaker automatically search the last
  pairing device and complete the pairing if you
  click the play/pause mode.If you want to
  connect the blue spearker again turn off the
  ON/OFF key and go to step one for pairing
  connection
e press ▶❙ key once to play and pause the music
  while music playing and press the ◀◀ key to turn
  it to next music and hold on this key to voice up
  and press the key once to turn it to▶▶ last music
  and hold on this key to voice down

NFC Connect

Attach the back of cellphone to the NFC sticker
of the bluetooth speaker, cellphone can quickly
turn to the automatically matching mode.

Audio connection

a power on the bluetooth speaker, and connect
  audio wire with the audio-in port of the speaker
  with another end into the audio-out port of your
  device to play musicb
b press on the ▶❙ key once to mute mode, hold
  on ▶▶ key to voice up and hold on◀◀ key to
  voice down

TF card player

a Power on the speaker and insert the TF card
   inside to play musicb
b In playing music, press on the   key once to
   play or   pause the music, and press ▶▶key
   once to next music and hold on this key to
   voice up, press on◀◀ key once to last music
   and hold on this key to voice down

Mode switch

a power on the bluetooth speaker and the default
  mode is bluetooth connection mode
b The M key is a switch key for options among the
  3 modes:bluetooth connection/TF card/Line-in

Call answering

There is a built-in microphone in the speaker
when your mobile phone is paired with the
speaker which will alert a call is coming in if
there is and press the ▶❙ key to answer the call.
Press the ▶▶ key to voice up during talk and
press◀◀key to voice down