BLUETOOTH SPEAKER



*Please charge the speaker every three months if the speaker don't play for a long time

Dear Sir/Madam:

Thank you for purchasing Bluetooth Speaker.

This product adopts high-capacity polymer lithium battery,bass and noi reduction techniques,general Bluetooth audio module and A2DP for au transmission to give you hi-fi music.

Also, it has built-in microphone to support hands-free talking and satisfy you with excellent user experience. Please read this manual carefully and completely before using the device. Please keep this manual for future reference.

Please adjust the volume properly to avoid excessive output power, which may impair your hearing.

 Please keep the device away from moisture. rainwater, sand ,heat source and

any container with liquid

3.Please clean this device with slightly wet cloth instead of alcohol or benzene-containing solvent.

*Please charge the speaker every three months if the speaker don't play for a

What's in the box






User Manual





Device Layout





① MIC ② VOL+/NEXT track ③ Hand-Free Talking/Pause ④ VOL-/Previous ⑤ Power/Bluetooth ⑥ Indicator Light ⑦ Audio input ⑦ USB port

Charge the Battery

When the battery is running low, you will see the red light blink twice every four seconds and hear warning tone at the same time, in this case, please charge the battery immediately.

When the battery is fully charged, the red light will turn off automatically. You may charge the battery by connecting it to PC or power source via USB Cable.



1.Insert DC port of cable into the speaker via the jack marked with "5V" 2.Insert USB port of cable into PC or charger. When the battery is being charged, the red light turns on. Once the battery is fully charged, the red light turns off. It takes 2 to 3 hours to be fully charge the battery. The speaker is able to work for 8 hours is Bluetooth mode when fully charged (The working hours may vary due to volume, exterior environment and other factors.)

You can listen music when the speaker is in charging status, however, it may take long time for charging battery.

Bluetooth:How to Turn On/Off and Connect





Blue light blinks: no audio cable or Bluetooth device is connected yet, in this case, you may connect the speaker to Bluetooth device (mobile phone)

Blue and red light blinks alternately: no audio cable is connected yet while new Bluetooth device is found.

Red light turns on:the speaker is in charging

1. Press the power button until you hear a sound and see blue light blinks, which I ndicate the speaker is already connected with the device. Press power button until you hear a sound twice and see red and blue lights blink alternately, you may use your smart phone to directly pair with the speaker.

2.In working status, press power button until you hear a sound twice and see the Blue and red light turns on, which indicates the speaker is shutting down.

3.While the speaker is playing music via Bluetooth, the music will pause and you will hear the ringtone in case of any incoming call. You may press phone function key to answer the call. Press the phone function key twice time, decline the last phone number and then press it again to end this call so that the product will continue to play music. You may also press and hold the phone function key for 1 second to decline the incoming call and the speaker will continue to play music.

 $4.\mbox{Press}$ and hold VOL+ to increase the volume, which will reach the maximum value when you hear beep sound.

5. Press and hold VOL- to decrease the volume

6.Press VOL+/NEXT track button, the speaker will play the next song. Press VOL-/Previous track button, the speaker will play the previous song

7.The sound volume can also be controlled by using smart phone or other Bluetooth device.

8. Once you hear "toot, toot..." while playing music, it means the speaker is out out power, please charge the speaker immediately.

9.In charging status, the red light is on. Once fully charged, the red light goes out.

In order to maintain battery capacity, please fully discharge and charge the battery every three months whether you use it or not during such period.

Connect the speaker to Bluetooth Device

Before connecting the speaker to Bluetooth device, please make sure Bluetooth is enabled and no other audio device is connected via AUX port.

1.Press and hold the Bluetooth button for several seconds until you see red and

1.Press and hold the Bluetooth button for several seconds until you see red and blue lights blink alternately.
2.Turn on Bluetooth device and find the speaker Bluetooth name, pair your Bluetooth device with, when the blue light blinks, the speaker is connected. You can play music as per remote control of your Bluetooth device. In case the speaker is power off, please press power button for reboot and turn on Bluetooth again so that it will automatically start connecting to the device as it did last time and the red light will blink. Once they are connected, the red light turns blue.

*In case any audio device is connected via AUX port,the speaker will play music saved in such audio device instead of that saved in Bluetooth device. In order to resume music in Bluetooth device, please disconnect audio device.

Blutooth: Play Music and Hands-Free Talking

Play Music
The speaker is able to play all music as long as they are supported by other
Bluetooth device or your smartphone. Also, you may use AZDP for audio
transmission with other Bluetooth device or your smartphone.
It may be required to enable AZDP transmission by setting Bluetooth device or
your mobile phone by hand. For details, please refer to relevant instructions

your mobile phone by hand. For details, please refer to relevant instructions

1: Turn on the speaker for music play;

2. Turn on your Bluetooth device and select music you want to play;

3. Pause the music: press power button when playing the music.

Resume playback: press power button again to continue.

4. Hands-free talking.

The speaker has microphone built in ,therefore, you may use it to answer the call as a hands-free device.

5. Answer a call.

While the speaker is playing music via Bluetooth, the music will pause and you will hear the rigitone in case of any incoming call. You may press phone function key to speak to the caller via built-in mic, or you may select to answer the call via your mobile phone.

6. Decline a call.

You may press and hold the phone function key to decline an incoming call.

Connect to Non-Bluetooth Device

You may connect the speaker to other audio device or mobile phone which doesn't support Bluetooth transmission as long as you have an audio cable with 3.5mm connectors at both ends.

Please refer to mobile phone user manual before connection.

After connecting the speaker to non-Bluetooth device via AUX port, the volume may only be adjusted by pressing Vol-t/VOL- on the speaker. You may play or pause music either with such device or the speaker.

2.Turn on both the speaker and mobile phone.
3.Turn on music player built in mobile phone.
4.Increase the volume of mobile phone to the maximum, and then adjust by pressing VOL+/VOL- on the speaker.
*Before disconnecting mobile phone and the speaker, please firstly turn both of them off.

Troubleshooting

The speaker doesn't work.

1. Check whether the battery power ran out?

If so, please connect the speaker to PC or USB charger for charging.

2. Check whether it is powered off or in standby status?

If so, please press power burton until you see the indicator light turns on or blinks.

3. Check whether it is far away from Bluetooth device or mobile phone?

If so,please get them close to each other.

Fail to connect the speaker to other Bluetooth device or mobile phone.

1.Check whether the speaker can be paired with such device or mobile phone?
Please refer to user manual of such device or mobile phone or see things of your mobile phone to see Bluetooth is turned on?
Plea se turn on Bluetooth and then check whether the speaker is on the list of Is coverable devices. If not ,please try again.

3.Check whether you entered password correctly?
Please click settings and check.

Fail to play music.

1.Check whether there is no music file saved in your device?
Please check music folder in your device by referring to relevant instructions.

2.Check whether the music is paused?
If so, please press power button to resume playback.

3.Check whether the volume of your device is too low?

4.Check whether the volume of the speaker is too low?

5.Check whether the speaker is connected to other audio device via AUX port?

4

If so, the music saved in Bluetooth device will be pau 6.Check whether the speaker is running out of power? If so, please charge it and restart.

Technical Parameters

Voltage:5V; Current: 1800mA (at DC end) ower: 100~240V/ 50~60Hz

Input power: 100"240V/ 50" buns.
Output power: 1A USB
Output power: 3.7V 1800mAh polymer lithium battery
Charging time: around 3 hours
Working hours: around 8 hours

Power Amplifier Interface: 3.5mm jack Output power: 2*3W THD=10% Input sensitivity: 800mV1KHZ Frequency: 40Hz~19KHZ SNR: >50db Stereo isolation: >40DB Volume: 90db

Bluetooth Version: 4.0 Range: Max. 15.0M Environment temperature: +10oC~+40oC

Name and Content of Toxic or Hazardous Substances and Elements ording Management Methods for Controlling Pollution by Electronic Information Produc

Toxic or Hazardous Substances and Elements						
Part Name	(Pb)	(Hg)	(Cd)	(Cr (VI))	(Cr (VI))	(PBDE)
Cable	х	0	0	0	0	0
PW As	х	0	0	0	0	0
Plastic parts	0	0	0	0	0	0
Wood parts	0	0	0	0	0	0
Metallic elements	X	0	0	X	0	0

X: indicates that this toxic or hazardous substance contained in all the homogeneous materials for this part is below the limit requirement in 5/lT 11363-2006 O: indicates that this toxic or hazardous substance contained in all the homogeneous materials for this part is above the limit requirement in 5/lT 11363-2006

FCC STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

warning:Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installation. This equipment generates uses and can radiate radio frequency energyand, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guaantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment of and on, the user is encouraged to try to correct the interference by one or more of the following more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to

which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement: The device has been evaluated to meet general RF exposure requirement

The device can be used in portable exposure condition without restriction.