
# 刀模线不印刷

单号: EAP160216053 型号:3522037-CBT

印刷机材质要求:80g书纸,正反面单色印刷,共8页

尺寸:50\*65mm

文件完成日期: 2016/04/06



move product from packaging.Read instructions carefully before using the produc and retain them for future reference. Retail the packing to store the product, or dispose of (or recycle it) safely and properly.

- Bluetooth speake
- USB charging cable
   3.5mm audio connection cable
- Instruction manual

- Stream audio wirelessly from Bluetooth devices (or connect via a 3.5mm audio jack) Answers and makes calls with the built-in microphone(requi
- cellular phone)

  Delivers deep, rich sound from a portable and compact design
- Built-in battery can be recharged via LISB cable

# Instructions for use

# Charging the internal battery

- Fully charge the unit before use

  Connect the USB cord to the port on the back of the speaker and insert the other end into a port on your computer or other suitable USB outlet.
- The LED on the back will show that the battery is charging.
  The light will turn off when your units is fully charged.

### LED indicator

- LED off -power off
   Flashing Blue-power on
- . Flashing Blue-Pairing mode

### Placing the speaker in Bluetooth pairing mode:

Press and hold" (1) "on the top to power on the speaker When LED light flashes blue ,the speaker is now ready to be paired with another

Pairing a Bluetooth Device with your speaker Your wireless speaker can stream audio form any Bluetooth-enabled device within 10m(33 feet)

- Simply follow the steps below
- Turn the speaker on to place it in pairing mode.
   Set your phone, tablet or other device to search for Bluetto devices(i.e., the speaker).
- When the speaker is found (17-B38-UE) select is from the list.

# . When the pairing process is complete, then LED will light a steady blue

# Taking calls on your speaker when connected to phone

- Press to pick up the call.

  During a call!press again to hang up the call.

  You may also answer/end calls by using your phone as you would normally.

  Notelf you are listening to music from your phone, the music will automatically pause.

Controlling music playback when connected via Bluetooth: Once your Bluetooth audio source is successfully paired to your Bluetooth speaker any music played will automatically be heard through your speaker.

- Press (b) to play/pause the audio.
  Press and hold the «-- button to lower the volume level of the unit. Tap this button to go to the last track in a play list.
- Press and hold the »+ button to raise the volume level of the unit. Tap this button to go to the next in a play list.

Quickly press twice to change the mode, once into the FM radio press one time to After that, to navigate to through FM channels use the next and last track button.

### Playing MP3 Files through the Speaker using the USB/Micro SD Card

In USB/Micro SD mode, you can short press the power buttonto twice to change to the USB or Micro SD card mode

1.Plug in your USB/Micro SD Card in the slots provided Please make sure you use the correct file format in your media devices-MP3 FILES ONLY..

### Quickly press twice no to change the mode

Specifications Sneaker 3W\*2 Sizer280v40v54m Frequency:100-20KHZ Power input:5V500m/ Bluetooth range:10m(33 feet)

## FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for changes or modifications to expressly approved by the party reporting to compliance could be used in a burnity to operate the expulsions. The report compliance could be used to the used a burnity to operate the expulsions. The rest digital device, pursuant to Part 15 of the ECE Bules. These limits are designed to provide reasonable protection against harmful interference in a readential installation. This equipment generates, uses and can adates radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to addio and used in accordance with the instructions, may cause harmful interference to addio and used in accordance with the instructions, may cause harmful interference to addiand used in accordance with the instructions, may cause narmin interference to racic communications. However, there is no guarantee that interference will not occur in a particular installation, if this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
   Connect the equipment into an outlet on a circuit different from that to which the

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

## Altavoz Bluetooth barra de sonido



# Empezando

Retirar el producto de su embalaie. Lea las instrucciones cuidadosamente antes de usar el producto y guárdelas para referencia futura. Venta al por menor del embalaje para almacenar el producto, o disponer de (o reciclarlo) segura y adecuada.

# Qué está incluido:

- Altavoz Bluetooth
   Cable de carga USB
- Cable conector de audio de 3.5 mm Manual de instruccione

### Caracteristicas

- Transmite el audio de forma inalámbrica desde dispositivos Bluetooth (o conectarse a Transitute ir adulto de Torina initiani inicia de Sos min)
   Contestar y hacer llamadas con el micrófono incorporado (requiere conexión con un
- teléfono celular)
- Emite un sonido rico y profundo, de un diseño portátil y compacto
- La batería incorporada se puede recargar mediante un cable USB
   Radio FM
- USB, tarjeta del TF

# INSTRUCCIONES DE USO

- Cargar completamente la unidad antes de usarla

  Conecte el cable USB al puerto ubicado en la parte posterior del altavoz e inserte el
- Concette et capier Osa a poete o unicación en la plane posterior de analyza insister otro extreme en un puero en el ordenador u otro tomacorriente USB adecuado.

  La luz LED en la parte posterior mostrará que la batería se está cargando.

  La luz se apagará cuando sus unidades está completamente cargada.

### LED indicador

- LED luz apagada = apagado
   Azul luz intermitente = encendido
   Luz intermitente = El modo de emparejamiento Azul

 La luz roja = recarga de la bateria
 Colocar el altavoz en el modo de emparejamiento de Bluetooth:
 Mantenga pulsada la tecla " () " en la parte superior para encender el altavoz. Cuando el LED parpadea la luz azul, el altavoz está ahora listo para ser emparejado co

# El emparejamiento de un dispositivo Bluetooth con el altavoz:

- Su altavoz inalámbrico puede transmitir cualquier forma de audio dispo habilitado para Bluetooth radio desde 33 pies.
- Sólo tiene que seguir los pasos a continuaci Activar el altavoz para colocarlo en modo de empareiamiento
- Establecer el teléfono, tablet u otro dispositivo para buscar dispositivos Bluetooth (es decir, el altavoz).
- Cuando se encuentra el altavoz (17-B38-UF), seleccione esto de la lista.
   Cuando el proceso de emparejamiento se ha completado, la luz LED se vuelve de

### Tomando llamadas desde el altavoz cuando está conectado a su teléfono: Presione 🗢 para contestar la llamada.

- • También puede contestar / finalizar llamadas utilizando el teléfono como lo haria
- Nota: Si está escuchando la música de su teléfono, la música se detendrá

### Control de la reproducción de música cuando se conecta a través de Blueto

Una vez que la fuente de audio Bluetooth está emparejado con éxito para su altav Bluetooth, cualquier música que se reproduce automáticamente se escuchará a tr

Pulse ( para reproducir / pausar el audio.

Mantenga pulsado el botón ≪- para bajar el nivel de volumen de la unidad. Toque este botón para ir a la última pista en una lista de reproducción.

Mantenga pulsado el botón »+ para elevar el nivel de volumen de la unidad. Toque este botón para ir a la siguiente en una lista de reproducción.

Pulse rápidamente 🚗 dos veces para cambiar el modo de la radio FM. Una vez que ruise rapidamente a dos veces para cambiar el modo e a ratio mon ina vez que estés en el modo de radio FM, pulse a una vez para iniciar la búsqueda automática. Después de eso, para navegar a través de los canales de FM utilizan el botón siguiente

Pulse 🍙 rápidamente dos veces para cambiar el modo de

### Reproducción de archivos MP3 a través del altavoz utilizando la tarjeta SD USB / Micro

En el modo SD / Micro USB, puede pulse brevemente el botón de encendido dos veces para cambiar al modo de tarjeta Micro SD o USB 1.Plug en su tarjeta SD / Micro USB en las ranuras previstas. Por favor asegúrese de que utiliza el formato de archivo correcto en sus medios de comunicación los dispositivos de MP3 archivos sólo

# Especificaciones

Altavoz: Dos 3 vatios Tamaño: 280 x 40 x 54 mm Frecuencia: 100-20KHZ Entrada de energía: 5V, 500mA El alcance de Bluetooth: 33 pies Le présent appareil est conforme aux CNR d'Industrie Canada applicables a appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes

(1) il ne doit pas produire de brouillage et

(2) l' utilisateur du dispositif doit être prêt à accepter tout brouillage radioélectrique re?u, même si ce brouillage est susceptible de compromettre le fomctionnement du dispositif.