



User Manual



Model : OJJI lite

SAFETY PRECAUTION

1. Use a wireless hands-free system (headphone, headset) with a low power Bluetooth emitter.
2. Make sure the cell phone has a low SAR.
3. Keep your calls short or send a text message (SMS) instead. This advice applies especially to children, adolescents and pregnant women.
4. Use cell-phone when the signal quality is good.
5. People having active medical implants should preferably keep the cell phone at least 15cm away from the implant

Thank you for choosing this mobile phone, this device will offer you unprecedented surprise for it can support GSM cards and multiple cards standby. Meanwhile, this phone is equipped with a 3 megapixel HD digital camera, a MP3 Mobile Music and a MP4 video player. Enjoy yourself!

◊ Mounting The SIM Card/ T-Flash Card

Keep all miniature SIM cards out of children's reach. Please consult with your SIM card dealer on SIM card services and its usages. The SIM card dealer could be your local network operator or other related dealers.

◊ Note: Always make sure the phone is switched off before you insert or remove the SIM card, otherwise it may damage the SIM card.

1. Remove the battery cover by sliding it, insert the SIM card, with the notch at the upper left and the gold contacts face down, into the card slot.

2. Open the gold cap from the Hinge Type Connector. Lay the T-Flash card which gold contacts face down on the Connector, then close it. Align the card to the arrow sign as the following picture shows:

3. Replace the battery and close the cover tightly.

◊ Charging The Battery

1. Connect the connector of the travel adapter to the phone.

2. Plug the travel adapter into a proper AC wall outlet.

3. When your phone indicates that the battery is fully charged, please pull the travel adapter out from the I/O socket.

◊ Switching Your Phone On/Off

1. Press and hold Power key for a few seconds to switch your phone on/off.

1

2. If the phone asks for a phone lock code, enter the phone lock code, and press OK. The default code is 1234.

◊ Making/Answering Calls

Enter the phone number (with the area code). According to your need, enter the country code or the extension number.

Press the Pick up key to make a call.

To answer an incoming call, press the Pick up key or the left soft key. To end or reject an incoming/ongoing call, press the Hang up key.

◊ Using The Personal Hands free Handset

Connect the hands free handset to your mobile phone, you can still answer calls and use the microphone without holding the phone.

◊ Travel Charger

You can charge the phone with the Travel Charger when you are on the move.

◊ Note: Please use approved accessories to get the most out of your phone.

◊ Guidance On Entry Methods

This phone provides input methods of ABC, abc, Numeric (123) and so on, etc. which can be used in editing the phone book, short messages, alarms and other text applications.

Switch Input Methods

Please click the icon to switch the input methods. Press 0 to enter a blank space or "0".

Input Special Symbols

If you want to input special symbols, such as "., !? = < >" , etc. Please follow the steps below:

2

Search Contact

You can find the desired phone number from the phone book easily and quickly.

Add New Contact

1. To SIM: Press the left key to select OK to start to edit the contact's name and phone number.

2. To Phone: You can add the contact's name, phone number and so on.

Mark

This function enables you mark one or mark all Phone Book List from the SIM card or the phone, then you can select copy, delete or other options.

Delete

You can select to delete entries from the SIM card, the phone or one by one.

Copy All

This function enables you copy all entries both from the SIM card and the phone. The copy content takes the smaller one as standard.

Call Group

You can set group name (like family), caller ringtone, caller picture and group members for different caller group.

Others

You can check the memory status, and configure the Caller ID, Show number style.

Caller Picture / Ring Tone

Each of picture / ring tone can be selected to the new contact / the selected contact the caller group.

◊ Call Log

The phone registers missed calls, dialed calls, received calls, and also registers the approximate

4

Select Line: Switch to Line 1 or 2, the default one is Line 1.

Others: the settings item include 50 secs warning, Auto redial, Vibration for outgoing calls .

Phone Settings

Time and Date: You can set Time/Date, Time Format and Date display type.

Select Language: Select the desired language for the display text.

Auto Power On/Off: You can set the time for auto power on/off.

Power Management: Display the battery power information.

Restore Factory Settings: All settings can be restored to factory settings with this function. The factory setting for the password is 1234/0000.

Display Settings

You can configure the wallpaper, Idle display settings, Contrast, Backlight, Power on/off display and so on.

Security Setup

Your phone is equipped with a versatile security system to prevent unauthorized use of the phone or the SIM card, such as SIM1/SIM2 security setup, Phone Lock, Data security, Auto keypad Lock, and Change Password.

User Profiles

You can select General, Outdoor or Indoor. For each mode, you can configure the Ring settings, Adjust Volume, Call alert, Message alert, Extra ringtone according to your need.

◊ Note: Insert the earphone to access the Headset mode automatically. This mode has no Activate option.

◊ Multimedia

3

6

Camera

During the view-findings mode, press the left soft key, to carry out the following operations:

Gallery: To display the file list.

Settings: Modify some parameters set. For more information please read the help menu.

Storage: To set the default storage path.

Help: Some help information about camera.

◊ Note: Please click the blank to show the OSD menu, then you can confirm them.

Video recorder

For more information please read camera details.

Video

The video supports 3GP and MP4 documents. If the document is the standard format not supported, use the tools to convert to standard format.

◊ Note: You can add the videos in the memory card.

Audio

This function enables you to play songs. Select option to access the Play List. Select a song and then select Options to perform the following functions:

◊ Note: The current system does not support some MP3 with a non-standard format.

1. Play: To play the specified music.

2. Details: Filename, Quality, Size, Time, and so on.

3. Add to Ringtones: You can use MP3 music as the ring tone for incoming calls.

5. Repeat> You can select Off, One or All.

6. Shuffle> You can select On/Off.

Background Play > Press Red key to enter Background Play, the music will continue to play even if

7

you exit the Playing Screen (music will stop when a call is coming).

◊ Note: Press Side Key to adjust the volume.

FM Radio

The mobile phone supports recording. If there is a record, press the left soft key you can select:

New Record, Settings and so on.

Image browser

Enter the "Image browser" to view the image files in the default folder "photos".

◊ File Manager

You can use the function to manage all types of files saved in the memory card.

◊ Organizer

Bluetooth

You can use Bluetooth transmission of documents directly. Search equipment to the transfer. In accordance with the onscreen instructions can operate, and accepts data, choose to receive the same, document will be automatically stored in the directory.

Open Bluetooth: Bluetooth Switched on or off.

Bluetooth Visibility: You can search audio device.

Paired device: Can inquiry new device.

My Bluetooth name: You can rename your Bluetooth.

Address info: Check the Bluetooth address.

8

Help: Can read information about my devices.

Alarm

The mobile phone provides several alarms and you can set them as your need.

Calendar

You can view date with this function.

Calculator

The calculator can add, subtract, multiply and divide. Press "*"key to enter the decimal point. Press Clear to delete the figure.

STK Service

This service is offered as the SIM card service provided by the network operator.

◊ Entertainment

There is several interesting application in the phone. Please refer to instructions from the game help for more details. Some network don't support the function. Please consult your network for more information.

◊ Internet

Internet is an application platform integrating wireless communication and Internet technology, which makes it possible for you to access to rich Internet information source and e-commerce application etc.

◊ Safety Precautions

Before using your phone, please read the following important information to eliminate or reduce any possibility causing damage and personal injury.

◊ Do not use wireless phones while driving.

9

● Switch off wireless devices in aircraft. The signal may cause interference. ● Do not use mobile phones at fueling point. Don't use near fuel or chemicals.

● Follow regulations or rules in hospital and health care facilities.

● All wireless devices may get interference that could affect performance.

● Only qualified service personnel can install or repair this device.

● Use only approved accessories and batteries.

● Use only in normal position.

● Do not expose your phone to extreme high temperatures above+60°C(+140 F).

● Do not use anything static to clean your phone.

◊ Battery Information

Information Charging and Discharging

● Do not charge the phone in wet and damp conditions.

● Use only batteries approved by the phone manufacturer and recharge your battery only when the phone is turned off.

● We strive to produce products in compliance with global environmental standards.

● The charger meets the standard for safety of information technology equipment and office equipment use. It must be used for this purpose only.

● When the battery level is low, "Low Battery" will be display on the screen.

● Do not leave the battery connected a charger for longer than 12 hours.

● Temperature extremes will affect the ability of your battery to charge.

Tips for Battery

● Use the battery only for its intended purpose.

10

● Make sure that the line switch in call setting is the system preset line. Default is line 1.

● Check whether you have set up call barring or fixed dialing or any other safety function.

● Check whether you have set up call divert.

◊ Low voice

● Check whether the ring volume is not too low.

2. To Phone : Check whether you have set up the "Silent" option.

● Move away from a noisy place to check if you can hear the phone ringing.

● Check whether you have set up call divert.

◊ Manual Statements

All rights are reserved. No part of this document may be reproduced without permission. All trademark and brand names mentioned in this publication are property of their respective owners.

We have made every effort to ensure

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ▶ -Reorient or relocate the receiving antenna.
- ▶ -Increase the separation between the equipment and receiver.
- ▶ -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ▶ -Consult the dealer or an experienced radio/TV technician for help.

Specific Absorption Rate (SAR) information:

This 3G Smart phone meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

FCC RF Exposure Information and Statement

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: OJJI lite (FCC ID: 2AE2XOJJILITE) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at the ear is 0.344W/kg and when properly worn on the body is 0.982W/kg. This device was tested for typical body-worn operations with the back of the handset kept 10mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 10mm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 10mm must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.