

Thermal Printer



**The Smart Way to Manage
Your Restaurant Operations**

GL2120TF

GoLabel is a wireless label printer designed to work with a tablet running GoOps or SubOps.


GoLabel simplifies your food prepping and labeling procedures. This Quick Start Guide will help you familiarize yourself with GoLabel before you get started.




www.zippyyum.com
support@zippyyum.com
(888) 636-7557

SETUP


- 1 Plug in and turn on your GoLabel printer




- 2 Insert the spindle into the roll of labels, then insert the roll into the printer aligning the spindle into the slots



- 3 Download and install the GoOps or SubOps app on a compatible tablet



GOOPS



SUBOPS

SETUP

4

Enter your credentials and log into the app


If you've registered, sign in using your credentials

Restaurant#

Password



5

From the main menu, go to "Settings," then select "Printer" and "Connection Settings" Make sure your printer is turned on. Tap on the printer to connect to it.



GETTING TO KNOW YOUR GOLABEL HARDWARE

- 1 Cover Release Button
- 2 Connection Indicator
- 3 Error Indicator
- 4 Pause Button
- 5 Feed Button
- 6 Power Button
- 7 Paper Loading Axis



CONNECTING TO GOLABEL



PRINTING LABELS

The number on the printer shows how many labels will be printed. After printing a label(s), the number will turn grey and reset to 1.

Prepping & Printing Labels				Count
PRODUCTS	Quantity	Containers	HOW-TO	PRINT 
Protein				
Cheese Pepper Jck Slcd	2 Pack (1 lb)	1 1/6 container	 	
Cheese Swiss Nat Sl 32	2 Pack (1 lb)	1 1/6 container	 	
Chs American White Trngl 400S	1 Pack (5 lbs)	2 1/6 container	 	
Chs Jck/Ched Shred	1 Bag (2 lbs)	2 1/6 container	 	
Chs Provolone Slc	2 Pack (1 lb)	1 1/6 container	 	
Egg Patty Ylw 1 5 oz Fz	6 Pack (1 ct)	1 1/3 container	 	
Egg Whi Patty 1 5 oz Fz	6 Pack (1 ct)	1 1/3 container	 	
Toppings				
Glaze Teryaki	N/A	N/A	 	
Mayo Light	1 Pouch (52 oz)	8 Bottles	 	

Changing the number in the containers or quantity box will make the icon green again, indicating the new number of labels to print.

This icon indicates the item does not need a printed label. Just tap to mark it as completed.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- o Reorient or relocate the receiving antenna.
- o Increase the separation between the equipment and receiver.
- o Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- o Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.