



Speakers

Speaker cable





Carrying case

Power adapter with plug



Sound cable



The actual components may differ from the picture, and some items may be changed.

Safety and Warranty Statement

[Product-related]

Warning! Failure to observe safety precautions may result in injury or death.

Be careful when using the speakers and the power adapter.

- Please use only genuine power adapters.
- Store or manage the speakers and the power adapters in a manner that does not cause impact, flooding, heat, breakage, bending or pressing.
- Plug the power adapter properly to prevent it from being loose, and do not bend, twist or cut the cable connected.
- In case of damages or deformation of the power adapter, stop using it and dispose of it safely.
- The power supply unit may become hot during the normal use. Do not put it on a heat-sensitive surface

Be careful not to cause the product to be wet.

- · You must not touch the product or the power adapter with a wet hand.
- · Do not use the product and the power adapter in an environment in which they may come into contact with a liquid
- · If the product is wet damaged, stop using it immediately and remove the product and the power
- If the product is wet damaged, do not leave it alone for a long period of time or dry it by any arbitrary way such as a hand dryer or a microwave Instead, contact or visit our repair service center as soon as possible.
- · Warranty does not apply to a wet damaged product, and repair may be impossible or impractical

Attention! Failure to observe safety precautions may result in minor injury or property damages such as product malfunction

Do not drop or apply impact.

- The appearance or internal parts of the product may be damaged, and other failures may occur
- Store the product in a safe place with a flat and unsloped surface.

Do not disassemble, modify or repair the product arbitrarily.

Do not change the system or parts.

 Modification without our permission may cause safety issues, nonconformance to statutory regulations and system performance. In this case, warranty does not apply, and is invalidated

Use the product, power adapter and other accessories for their originally intended purposes.

 Failures, damages or other unexpected accidents may occur

[Cleaning the speakers]

Clean the speakers carefully using only a soft and dry

- Do not spill liquid on the speakers or the vent of each speaker.
- · Do not use an abrasive, liquid or spray on the speakers or the speaker grill.

[FCC Statement]

operation.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: This device may not cause harmful interference. (2) This device must accept any interference received, including interference that may cause undesired

WARNING: To reduce the risk of fire or electric

The apparatus shall not be exposed to dripping or

splashing and that objects filled with liquids, such

WARNING: The battery (battery or batteries or bat-

tery pack) shall not be exposed to excessive heat

WARNING: The direct plug-in adapter is used as

This marking indicates that this product should not be disposed with other household wastes throughout the EU.

To prevent possible harm to the environ-

waste disposal, recycle it responsibly to promote the sustainable reuse of mate-

ment or human health from uncontrolled

rial resources. To return your used device,

or contact the retailer where the product

for environmental safe recycling.

was purchased. They can take this product

please use the return and collection systems

disconnect device, the disconnect device shall

shock, do not expose this apparatus to rain or

as vases, shall not be placed on apparatus.

such as sunshine, fire or the like.

Correct Disposal of this product.

remain readily operable.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- · Consult the dealer or an experienced radio/TV technician for help.

[FCC Radiation Exposure Statement]

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled and operated with minimum distance 20Cm between the radiator & your body

[IC Warning]

This device complies with industry Canada licenceexempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate equipment

[IC Avertissement]

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioelectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

[Specification]

- Color: Silver / Black
- Size: 128 x 114 x 70.5 mm (H x D x W)
- Weight: 0.45 kg x 2 EA
 Output power: 8 W / CH @ 1 kHz 450 mV
 THD: 0.10 % @ 1 kHz 450 mV
- Bluetooth Version: 4.0

© 2014 by BONFIRE ACOUSTIC ALL RIGHTS RESERVED. Any use of materials on this website, including reproduction, modification, distribution or republication, without the prior written consent of BONFIRE ACOUSTIC, is strictly prohibited.

WARNING: Please refer the information on exterior bottom enclosure for electrical and safety informa-

The product label is located at the bottom of the

tion before installing or operating the apparatus.

The power plug or electrical appliances combiner is used as a separation device, and such separation device should be stored in an easily accessible

This product should be used indoors.

 This product is not designed or tested to be used in outdoor places such as recreational vehicles or

It is required to use only the provided power supply



This product complies with the requirements of all applicable EU guidelines. You can find the full text of the standard compliance notification statement at: www bfna kr

Input: AC100-240V ~ 50/60 Hz 0.6 A Output: DC12.0V = 1500 mA Model: FD10K-15120-1500


Manufacture: Shenzhen forever sheen c(UL) china electronics.,co.,ltd



3 Getting Started

Connecting/Disconnecting the power

1. Put the plug that meets the local standards in the power adapter and push it to be plugged. Press and push upwards the lock to remove the plug from the power adapter.



2. Connect between the product's power terminal and the household outlet using the power adapter.

To remove the power from the product, remove the power adapter from the outlet and the product's power terminal.

Turning On/Off

- 1. When the power adapter is plugged to the outlet, the unit turns the standby mode.
- 2. When you press and hold the Power [6] button in Play mode, the speakers are turned off.

- Connect the speaker cable to the other speaker. Connect the audio cable (AUX IN) to the external
- **3** Connect the plug of the power adapter into a household outlet then the indicator lamp is displayed in red. Do not plug in the power adapter until all other connections are completed.

It is recommended to use a surge protector approved by safety authorities for all electronic devices.


4 Connecting/Playing a Bluetooth

1. Press the Power/Bluetooth (🕩) button repeatedly until the lamp will be displayed in blue.

If you do not have a registered device; the lamp will flash blue. Searches for Bluetooth devices in the device to be registered, and then select the product "MM2B" / connect.

If the registered device is ready, while the lamp is lit in blue will blink automatically.

- 2. From the Bluetooth device connected, execute the music play function.
- 3. If you press the Power/Bluetooth [心*] button when the speakers are connected with other external device, the external device comes to be in Play mode




5 Playing the AUX.....

- 1. Press the Power/Bluetooth [心*] button repeatedly until the lamp will be displayed
- 2. From the AUX device connected, execute...... the music play function. The speakers start to emit audible sounds

6 Volume control

Press the Volume [+]/[-] button located at the top of the speaker to increase or decrease the sound volume.



7 Troubleshooting

When the speakers don't produce any

Check whether the adapter is firmly connected to the speaker and the outlet.

Check whether the lamp located at the top of the right speaker has turned red to verify that the speaker is turned on.

Check whether the speaker volume is set to off. To increase the volume, press the [+] button on the right speaker. Check whether external device is plugged into a

power source and is turned on, and the volume is set to at least two thirds of the maximum

Check whether the audio input cable is connected to the audio input [AUX IN] terminal of the speaker and the audio output terminal of the external device correctly.

When one of the speakers does not produce a sound

Check whether the speaker cable is connected to both the speakers firmly.

8 Product registration

You can register your product at http://www.bfna.kr. You can find the product serial number at the bottom of the right speaker and on the customer warranty

Serial Number:

Model Name:

(marked on the label at the button of the speaker)

Please fill in the information and keep it.



BONFIRE ACOUSTIC

302 222, Maeyeong-ro, Yeongtong-gu, Suwon-si,

Gyeonggi-do, Korea e-mail: support@bfna.kr | Tel: +82-70-8202-0438