Mini Shutter Speaker


INSTRUCTIONS

This Mini Bluetooth shutter speaker only 26.8*26.8*26.6, small size, but powerful multi-function, support Bluetooth Camera, Bluetooth music playing, Bluetooth phone call, Bluetooth anti-lost feature, etc., with fashion design, can hang as a cell phone ornaments, etc., a good choose as for the promotional season.

Features

- Bluetooth Remote Camera (2)
- APP: NO
- For IOS (iphone4S/5/5S/6/6+ or up) & Android (4.3 or up)
- Bluetooth Speaker Phone Option (Hands-free call) (5)
- Anti-Loss Feature
- Bluetooth Speaker (8)
- Very Small Size, 26.8*26.8*26.6mm
- Rechargeable Battery

Easy operation



- 1. Press button: Play/Pause/Answer Calls
- Press and hold the Power button to power On/Off
- Press the button to pause when music is playing, press again to replay
- Press the button to answer incoming calls when the device is paired with a phone, press again to end call
- 2. Remote Camera Shortcut
- Open the device's "Camera", press the shortcut (2) to take pictures while music is playing
- 3. Bluetooth indicator light:
- Fast flashing green LED light shows that the speaker is Bluetooth searching and pairing mode
- Slow flashing green LED light indicates that the phone was successfully paired
- 4. Charging indicator Light
- Steady red LED light while the device is charging
- The indicator light (4) extinguished when fully charged
- 5. Microphone
- 6. Sling hole
- 7. Micro USB (power input)
- 8. Speaker

Pairing:

- Press and hold the power button until you hear the start-up chime. The green LED light will be flashing quickly.
- Switch on your Bluetooth device and wait until JTL-6 shows up on your screen. When JTL-6 appears on your device, select and pair with the speaker.
- When the pairing is completed you will hear a message and the green LED light will flash less frequently
- To turn off the speaker, press and hold the Power button (1)

Charging

You should fully charge the speaker prior to first use. Plug the charging cable into the micro USB port (7) and then connect the charging cable to the USB port of your PC or other compatible power source. The red LED light (4) will flash during charging and remain solid when fully charged.

Power On\Off

Power on: Press the power button and hold until a beeping sound is heard and the green light flashes quickly.

To turn off: press the power button (1) and hold, "Power off" will be heard and the green light (3) will go off.

Please Note: It is strongly recommended that you turn off the speaker while not in use.

Bluetooth Pairing

Please check to make sure the device to which you are pairing has Bluetooth capabilities. This information should be included in your phone or device's instructions or packaging.

- 1. Make sure that the speaker is turned off.
- Place the speaker and the device in proximity so that both devices are in view.
- 3. Press and hold the power button until speaker power is on. A green LED light (3) will flash quickly.
- 4. To active the Bluetooth mode and functions on your phone or device, see the instructions for that device.
- 5. Set the phone or device to search for Bluetooth devices and select the speaker.
- When the pairing is complete, the green LED light (3) will flash more slowly. The speaker is now ready for listening to music or answering calls.

Note: Some mobile phones or other devices may pair automatically when re-started.

Bluetooth Camera

- 1. Open the device's "Camera", press the shortcut (2) to take pictures while music is playing.
- 2. Turn off the bluetooth, you can share pictures with others by send email or message.

Note: Make sure Bluetooth is connected the device.

Anti-Loss

When device connected the speaker, once the distance up to 10-15meters, speaker will start to alarm with "Dududu, Dududu", until the two devices close again, it will stop and connect again automatically.

Answer / Reject / End a call

During a call, the ring is heard through the speaker when paired. The microphone (5) is a small hole in the speaker on the button side.

- 1. Press the power button (1) for about 1 second to answer the call.
- You may also accept or decline a call using your phone's functions.
- 3. To end a call, press the power button (1) during the call. You may also end the call using your phone's functions.

Play / Pause

In the process of playing music, press the power button (1) to pause/play the music.

Specifications

Rated Power
Frequency Response
Distortion Factor
Signal to Noise Ratio:
Separation
Speaker
PO=2W
T80HZ-16KHZ
THD<1%
S/N≥90DB
≥55DB
23mm;4Ω 2W

• Battery 3.7V/180mAh polymer Li battery

Precautions

- Please only use the computer USB or the DC 5V power matching the Micro USB interface to charge.
- Please keep and use in normal environments. Exposure to extreme elements such as fire, water, or other extreme elements may damage the unit. Do not handle with wet hands.
- Keep debris or other items from blocking the speakers or from entering any of the ports.
- Do not attempt to open or take apart this speaker. The speaker will be damaged during that process.
- If the speaker quality seems lessened, or a slight popping noise is heard, it may be caused by a low battery. Please recharge the speaker.

TROUBLESHOOTING

No Sound

- Make sure that the music player is working and that the speaker is charged.
- Make sure the Bluetooth is paired with the correct speaker.

Not charging

 Check to make sure that you are using the correct cable and that it is fully plugged into both the device and the USB port that you are charging from. Also check to make sure the PC or other USB charger is turned on.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - -Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Caution:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.