Button Functions:





- 1. Power: Press to turn speak ON/OFF.
- 2. Mode: Change between Bluetooth®, Radio & AUX Input.
- Previous Song / Volume Down: Press for previous song or previous radio station. Hold down to reduce volume.
- Next Song / Volume Up: Press for next song or next radio station.
 Hold down to increase volume.
- 5. Pause / Play / Phone / Change Station: Press to pause or play a song. Press to answer phone. In Radio mode, press for station search. Press & hold down to remove device pairing. On first use of radio, press button #5 for radio station auto-scan. Once auto-scan is complete, use button #3 & #4 to change the station.



1. MICRO USB:

Charging, AUX cord & Radio Antenna.

CARABINER:Built-In carabiner loop.

Charge Time: 2-3 hours regular, 12 hours initial

Insert Micro USB cable into device and plug into computer via USB Port. The red light will turn on when the device is charging & will turn off when charging is complete.

Radio Reception: Insert the Micro USB cord into the speaker for antenna extension. Place speaker near a window or outdoors for best reception. Do not expose speaker to inclement weather.

FCC Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: Modifications to this product will void the user's authority to operate this equipment.