CAUTION

The battery used in this device may present a risk of fire, explosion or chemical burn if mistreated

- Never use or charge the battery if it appears to be leaking, discolored, deformed, or in any way abnormal.
- Never disassemble the unit or attempt to remove battery as that could cause leakage of alkaline solution or other electrolytic
- Always confirm that the temperature is 5°C 35° C (41° 95° Fahrenheit) before you charge the battery. Leakage or deterioration of the battery may occur if this warning is not heeded.
- Never expose the battery to any liquid.
- Never expose the battery to excessive heat such as direct sunlight or fire. Never use the battery pack in an unventilated vehicle where excessive internal temperatures may be encoun-
- Always keep the battery out of the reach of infants and small children

IMPORTANT SAFETY INSTRUCTIONS

When used in the directed manner, this unit has been designed and manufactured to ensure your personal safety. However, improper use can result in potential electrical shock or fire nazards. Please read all safety and operating instructions carefully before installation and use, and keep these instructions handy for future reference. Take special note of all warnings listed in these instructions and on the unit.

- . Water and Moisture The unit should not be used near water. For example: near a bathtub, washbowl, kitchen sink, laundry tub, swimming pool or in a wet basement
- 2. Ventilation The unit should be situated so that its location or position does not interfere with its proper ventilation. For example,

it should not be situated on a bed, sofa, rug or similar surface that may block ventilation openings. Also, it should not be placed in a built-in installation, such as a bookcase or cabinet, which may

impede the flow of air through the ventilation openings. 3. Heat - The unit should be situated away from heat sources such as radiators, heat registers, stoves or other appliances (including amplifiers) that produce heat.

- 4. Power Sources The unit should be connected to a power supply only of the type described in the operating instructions or as marked on the appliance.
- 5. Cleaning The unit should be cleaned only using a warm damp cloth. Do not use solvents, etc.
- 6. Objects and Liquid Entry Care should be taken so that objects do not fall and liquids are not spilled into any openings or vents located on the product.
- . Periods of Nonuse If the unit is to be left unused for an extended period of time, such as a month or longer, the power cable should be unplugged from the unit to prevent damage or

FCC Information






Bluetooth Tombstone Speaker



Instruction Manual

©2015 PAC (BVI), Ltd 115-53-H005₁₋₇

Page 5 Page 6 Page 7 Front




Includes:

- 15 in LED Bluetooth Tombstone Speaker.
- Micro USB to USB power cable.



Charging the Unit:

11. Connect the micro USB plug to the micro USB charging port on the back of the unit.



2. Connect the "Standard" end of the USB cable to a USB power port or other USB charging device, such as a USB power adapter. The battery should be charged for 4 hours before first

3. While the battery is charging, red light will alow. When the battery is fully charged, green light will alow .

Using Bluetooth: Pairing Your Unit

- 1. Please make sure the battery has been fully charged before using the unit for the first time.
- 2. Place the power switch into the "ON" position. You will hear "Bluetooth waiting for Bluetooth connecting".
- 3. On your device, turn on Bluetooth Capability and search for the Bluetooth Tombstone Speaker's name "BT SPEAKER". Now, tap the name to begin pairing. Once the two devices are connected, vou will hear "Paired".
- 4. Enjoy using your Bluetooth Tombstone Speaker!
- 5. When the unit is not in use, please place the Power Switch into the "OFF" position.

The Bluetooth Tombstone contains a Rechargeable Lithium-ion Battery which should last the lifetime of the devise.

WARNING AND DISPOSAL OF UNIT

Please DO NOT attempt to change the Lithium-ion Battery yourself. If the battery will no longer hold I a charge, you should follow the following disposal instructions:

- Never dispose of used batteries or electronics with ordinary solid waste - they contain toxic substances.
- Used batteries and electronics should be disposed of as required by local or state regulations.
- RECYCLE YOUR BATTERIES: To help protect our environment, we recommend that all batteries be recycled. You can find a local recycling center by going to: http://earth911.com/hazardous/single-use-batteries/ Or, in the United States call 1-800-CLEANUP for a recycling location near you.

Page 1 Page 2 Page 3 Page 4 This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.