Message

Call logs

8

Settings

Multimedia

File manager

Application

Profiles

Internet

FM Radio

Audio

Calendar

1. Contacts

7. Application

In the main display, you may see several icons shown on your status bar.

You can use the Contacts features business card information will be stored to mobile phones.

1.1.Quick search
Enter the name of the first letter in the contacts to find qualified records.
1.2.New
In the options, add a telephone number to phone or SIM

card.

1.3.Delete multiple
choose to delete phone numbers from SIM or Phone, you
can mark all of the phone numbers then choose "OK" to
delete . you can also choose to delete them one by one.

- 3 -

7.1. Calculator
This function enables you to add, subtract, multiply and

User Manual

3.1.Missed calls
In Call logs menu, choose Missed calls and press "OK key" to view the records.
Your phone provides the option to Recent Contacts with the

3.2.Dialed number
In Call logs menu, choose Dialed number and press "OK key" to view the records.
Your phone provides the option to Recent Contacts with the

same.
3.3.Received calls
In Call logs menu, choose Received calls and press "OK key" to view the records.
Your phone provides the option to Recent Contacts with the same

same.
3.4.Rejected calls
In Call logs menu, choose Rejected calls and press "OK key" to view the records.
3.5.Delete call
Your phone allows you to delete all of call logs.

3.6.Call timers
Your phone allows you to view the timers for calls made and

received.
In Call logs menu, choose Call timers, press "OK key" to view

the content.

• Last Call: List out the last call time of your conversation

Received calls: Sum of total call time you have received.
 Dialed calls:Sum of total call time you have dialed.
 Reset All: Reset the time counter to zero.

3. Call logs

UNO M8

Basic Knowledge

- Basic Knowledge
 Introduction

 Thank you for choose our digital color screen mobile phone. By reading these guidelines before using your mobile phone you will have an overall knowledge of this phone set and understand its simple but outstanding functions.

 This phone set is designed for GSM/GPRS networks. On top of basic functions, it enables you to use name card style contacts, clock/ alarm, calendar, calculator, games, audio player, camera, yideo recorder, image,FM radio and other functions. It serves your work and leisure time. Having unique interface and perfect feature designing this phone set meets all your expectation.

 Our phone set meets the GSM/GPRS standard and has the qualification from related organizations worldwide.

 Our company reserves the rights modifying the content in this Instruction without pre-notify.

 Safety information

 Under the circumstance of stealing and lost, contact the telecom branch or sales outlet immediately.

 When you contact with telecom branch and sales outlet, it is necessary to provide them with IMEI number (printed on the back of the phone set, remove the battery to discover it). Please record the IMEI number and keep it safe for future use.

- To prevent miss usage of your phone set please take ecautions such as:

 Set the PIN number of the SIM card, and update it timely
- When get off the car. Please do not leave the phone set unattended, keep it with you or in the suitcase. Set call barring
- Safety and health precautions

Description	of Keys
Name of key	Letters or functions
1key	,.?!"'-@:;/ 1
2key	ABCabc2
3key	DEFdef3
4key	GHIghi4
5key	JKLjkl5
6kev	MNOmno6

Call barring: All outgoing calls/All incoming calls/Incoming calls when roaming/ISD calling/Dial when INTL roaming/cancel all barring/change password Hide ID-Hide ID/Display own ID/Display ID by network Other:P prefix/Call time reminder/Auto redial/Vibration when connected.

Onter. In preserved unter terminative designation with whether connected (Reply SMS after reject/Auto record voice call 4.2.Phone settings Into the phone set up sub-menu, you can set the following: Date and time: At the time and date menu, you can set the time, date.

Language setting: Includes languages type.

Shortcut settings: to define the shortcut functions.

Auto power on/off:In this menu, you can set the timer switch machine.

machine.
Restore factory settings:input password to restore factory

settings.

4.3.Display
Wallpaper settings/Idle display settings/Contrast/keypad
backlight/auto keypad lock
4.4.Security settings
Your phone provides the following selections for your option:
PIN:on/off/Modify PIN

Maddiv PIN210 modify PIN2 number

Modify the cellphone password Privacy :to choose the functions that you need to enter

password when entering. Lock screen by end-key:to lock screen by end-key.

Guardlock:status/change password Fixed dialing: fixed dialing/Fixed dialing number Black list: blacklist list/blacklist settings

4.5.Connections
Network selection:Auto select/Manual select

Phone locked:on/off

5. Multimedia

8key	TUVtuv8
9key	WXYZwxyz9
0key	0
*key	1.after inputting telephone number, if you want to input extension number, please press twice asterisk key, after the display screen shows "+" please input your extension number. 2?!(@:#\$/)
#key	In text editing interface, press "#" key to switch text the input method. On the standby interface Press and hold "# key to transfer the profile of General/Silent Vibrate.
Scrolling Up	Move cursor up
Scrolling	Move cursor down
down Scrolling left	Move cursor left
Scrolling right	Move cursor right
Left soft key/ Right soft key	In the standby mode, press Left Soft key to acces Main menu, Right Soft key to access Contacts.
Ok key	determining options
Dial key	dial telephone numbers and receive incoming
End	 Return to idle screen 2.End calls or rejectincoming calls.

7key PQRSpqrs7

李和	The SIM				of	the	cellular
Hill	network a	t your cu	rrent loc	ation.			
एड ली	The SIM:				of	the	cellular
Zhilli	network a	t your cu	rrent loc	ation.			
(IIII	The batter	ry charge	e level.				
	Contacts						

- 2 -

	nemory card. The status of your camera setting will ad on the top of preview mode.
Store ohotos	You can review pictures you have taken by pressing OK
DV mode	Switch to DV mode
Effect	Set photo color
Settings	Size:Set photo size Quality:Set photo quality Banding:to avoid flashing Shutter sound:activate/off

5.4.Image
View the images
5.5.Recorder

- 8 -

5.1. Camera
The camera lens is on the top of the phone, and the display of the phone works as a viewfinder. If there's not enough memory for camera, you need to delete old photos to free some spaces for new photos or you can choose to save

Store photos	You can review pictures you have taken by OK
DV mode	Switch to DV mode
Effect	Set photo color
Settings	Size:Set photo size Quality:Set photo quality Banding:to avoid flashing Shutter sound:activate/off Auto save:activate/off Storage:phone/memory card
5 2 DV	

5.2.DV
You can record the video clip through build-in camera.The status of your video recorder setting will be displayed on the top of preview mode.To start using Video recorder in Multimedia menu, select Video recorder and press "OK key" Press Options to personalize your camera setting.
5.3.Video

Key Video Play Function
Fress Video Fress Vi

6. File manager

To view the file memory.

This function enables you to add, subtract, multiply and divide. The screen will initially display the number "0". Enter the first number to be calculated. 7.2.Alarm To set a new alarm, alarm clock icon will be displayed when an alarm is active. At the same time, three groups can be set up alarm clock. 7.3.Bluetooth Your phone provides the following selections for your option: Bluetooth/Bluetooth visibility/Paired device/Transferring fles/device name/Bluetooth file storage/help According to the menu, will enter the corresponding function set.

8. Profiles Normal: Suitable for normal use.
Silent:Suitable for silent use.
Meeting: During the meeting, suitable for use.
Outdoor: Suitable for outdoor use
Indoor: Suitable for indoor use.

The service is provided by network operator, If SIM card or network operator fails to provide the service, the function can not be available. Contact network service operator, if you want to have more information.

10. FM radio

You can listen to Fm radio freely with plug in the earphone. Enter the radio interface, search the frequency, (87.5-108.) Auto search and save/Channel list/sexe/Manual search/dose/open speaker/background play
--Auto search and save:Search frequency available automatically

1.4.Import/Export

Export contacts

Own number

Copy
Copy contacts from phone/SIM card to SIM card/phone.

Import contacts
Import contacts file from phone or memory card to

Choose some phone numbers in contacts then export them to phone or memory card.

To edit the name and the number of your SIM card.

1.6.groups
You can view and edit the details of the group and

members of the group to remove or add operation.
Your phone provides the following selections for your

Mass texting
Send SMS to many phone numbers that you select from
Contacts.

2.1.Write message
You could write new message by using this function. When
you input the message to be sent, press left soft key to send,
to insert the templates, to add contact person information, to
add phiz and to save, etc. Within the write message menu
you can write and edit text message up to 160 characters.
2.2.Inbox
After you have an incoming text message. The phope stores

After you have an incoming text message .The phone stores the message in the inbox folder of the SMS menu.

2.3.Outbox
When you fail to send a message. The phone stores the message in the outbox folder.

Memory status
To view the capacity of SIM card and phone.

option: Family/Friends/Business/Classmates

New group Add a new group

2. Message

Service number
Support the steps for reaching actual people to solve your

- Channel list: You can view all the broadcasting stations you - Channel list: You can view all me broadcasting stations you saved.
-save:Save a channel to channel list.
-Manual search: Search the broadcasting station by input frequency manually.
-close/open speaker:You can start up loudspeaker to make the sound bouder.
-background play:you can do other operations while listening to the radio.
-Record:to record a channel.
-Timing record:to set the time of recording and the channel.
-Record file list-list the record file you have recorded.

11. Audio

up/down key.

Music listto list the musics of your phone and memory card.

Add:to saved play list/to new play list

Set as ringtone:set as incoming call ringtone/set as alarm

ringtone
Shuffle.whether to shuffle play
Repeat.to set the play mode off/repeat all/repeat one
Settings:Equalizer/BT stereo output/BT stereo headset
Open review:to review music

12. Calendar

To view the calendar.

When you send a message successfully. The phone stores the message in the sentbox folder.

2.5.Drafts When you save a message you have written. The phone

2.6.Security inbox

you can move a message from inbox ,outbox,drafts,sentbox To enter the security inbox, you should input the security

inbox password. Your phone offers you a list of templates that you can use in replying to messages. You can also use templates whe

2.8.Broadcast message

Send or receive message to same area subscribers in Broadcast Message mode. You also can turn this function on/off here.

Receive mode: ON/OFF broadcasting function.

Receive mode: ON/OFF broadcasting function.
Language: Turn On/Off all languages.
Channel Setting: Set Broadcasting Message parameter.
2.9 Voice mail server
Line 1 number /Fax number/Data number
2.10.SMS Settings
SIM1 message center/SIM2 message center:to show your
text message center.
Message validity period:6 hours/24 hours/72 hours/1
week/maximum

week/maximum
Status report: You can request the network to send status reports on your text message(network service). A status report is indicated by in front of the message header. Save sent message:prompt user/save/don't save Preferred storage:phone/SIM
2.11.Message capacity to view the SMS memory of SIM card and phone.

- 5 -

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class & digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against hormful interference in a designed to provide reasonable protection against hormful interference in a feet great provide reasonable protection against hormful interference in the feet great provide representations and used in accordance with the instructions, may cause harmful interference to radio communications However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value.

Before a new model phone is a available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC, fests for each phone are performed in positions and locations (e.g. at the ear and worm on the body) as required by the FCC.

■ For body worn operation, this model phone has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that Contains no metal and that positions the handset a minimum of 5mm from the body.

■ Non-compliance with the above restrictions may result in violation of RF exposure guidelines.

4.1.Call Settings
Your phone provides the following selections for your option:
Dual-SIM:Standby mode/Repty by original SIM/Set SIM Call divert:call forwarding unconditional/call forwarding on busy/call forwarding on no reply/divert if unreachable/cancel

Call waiting: Activate/Deactivate/Query Status.

- 6 -