## Manual

## Operation:

- 1. Insert Battery Remove battery cover, insert one CR2025 (3V) battery, ensuring the correct +/- polarity.
- 2. Press the power button to "Turn On"
- 3. Turn on the Bluetooth function on your smartphone and select the remote on the Bluetooth menu.
- 4. Open the smartphone camera function, and press the shutter button on the remote to take a photo.

## Accessories (Package Contents):

- 1 x Camera Remote Control
- 1 x Battery CR2025(3V)
- 1 x Phone Strap
- 1 x Phone Stand

Maximum Remote Distance: Works up to 8-10 meters away.

Compatibility:

Above Android 3.2-4.3 System & IOS System

## Warninas:

- Do not subject the unit to excessive force, shock, dust or humid environments
- Do not immerse the unit in water. If you spill liquid over it, dry it immediately with a soft, lint-free cloth.
- Do not clean the unit with abrasive or corrosive materials.
- Do not tamper with the unit's internal components.
- Only use fresh batteries.
- When disposing of this product, please obey the environmental protection policy
  Do not dispose old batteries as unsorted municipal waste. Collection of such waste
  separately for special treatment is necessary.

4590003763/4 88015240 MADE IN CHINA

Heineken International B.V. Stadhouderskade 79, 1072 AE Amsterdam







NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.
☐ Increase the separation between the equipment and receiver.
lacksquare Connect the equipment into an outlet on a circuit different from that to which th
receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

FCC ID: 2AEPX71473 Model No: 71473 Brand Name: Heineken

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

007™ and related James Bond Trademarks © 1962-2015 Danjaq, LLC and United Artists Corporation.

All Rights Reserved. 007™ and related James Bond Trademarks are trademarks of Danjaq, LLC licensed by EON Productions Limited.