3.5.2 The rear panel




Figure 3.2 Rear panel

- 1) Volume control
 - To adjust the volume of the output tone.
- 2) Ventilation slots
- 3) Place holder for country specific RFID symbol and registration number Only applicable for specific countries. Not applicable for the European Union.
- **4) Equipotential bonding point**To increase electrical safety by potential equalization
- 5) Symbol plate
- 6) Power socket with fuse holder
- 7) Rating plate
- 8) Foot switch socket

To connect the double pedal foot switch.