

1. Photographs of Conducted Emissions Test Configuration



Front view




Side view

TEL: 886-3-327-3456 Page number : F1 of F5

FAX: 886-3-327-0973 852814






Under table view

TEL: 886-3-327-3456 Page number : F2 of F5


FAX: 886-3-327-0973 852814



2. Photographs of Radiated Emissions Test Configuration For radiated emissions 9kHz~30MHz



Front view




Rear view

TEL: 886-3-327-3456 Page number : F3 of F5

FAX: 886-3-327-0973 852814



For radiated emissions 30MHz~1GHz



Front view



Rear view

TEL: 886-3-327-3456 Page number : F4 of F5

FAX: 886-3-327-0973 852814



For radiated emissions above 1GHz



Front view



Rear view

Page number : F5 of F5

-THE END-

TEL: 886-3-327-3456 FAX: 886-3-327-0973