

BLUETOOTH WIRELESS HEADPHONES

User's Guide for Model No. IAHB64 v1376-01

- Real times insurance.

 Recop these Instructions.

 Recop data (Marnings.

 Bread all Warnings.

 Do not use this apparatus near water.

 Clean only with a dry cloth.

 Do not the best apparatus near water.

 Clean only with a dry cloth.

 Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.

 Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

 Do not defeat the safety purpose of the polarized or grounding type plug. A polarized plug has two blades with one wider than the other A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. When the provided plug does not fit into your outlet, constal an electricani for replacement of the obsolete outlet.

 Protect the power cord from temic walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.

 Unplug this apparatus during lightning storms or when tunued for long periods of time.

 Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or moisture, does not operate normally, or has been dropped.

 Use only with a cart, stand, tripod haseke, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the eart' apparatus combination to avoid sijury from tip-over.

Important Safety Instructions



FCC Warnings

Warning Changes or modifications to his unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device; pursuant to Part I 5 of the FCC Rules. These limits are designed to provide reasonable, and care in the protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference to to not or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Romerican for relocate the receiving antenna.

- Reorient or relocate the receiving antenna. Increase the sparation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

Additional Warnings and Precautions

- Additional Warnings and Precautions
 CAUTION: TO BEVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE
 SLOT, PULLY INSERT.
 WARNING: The risk of fire or electric shock, do not expose this apparatus to rain,
 Warning the risk of fire or electric shock, do not expose this apparatus to rain,
 Warning the risque of incendie ou de choc électrique, ne pas exposer cet appareil sous
 la pluie et l'humidité.
 CAUTION: Use of controls or adjustments or performance of procedures other than those specified
 may result in hazardous radiation exposure.
 WARNING: Thouge sor modifications to this unit not expressly approved by the party responsible
 for compliance could void the user's authority to operate the equipment.
 WARNING: Don of place this unit directly onto firmiture surfaces with may type of soft, porous, or
 sensitive finish. As with any rubber compound made with oils, the feet could cause marks or staining
 where the feet reade. We recommend using a protective burier such as a cloth or a piece of glass
 between the unit and the surface to reduce the risk of damage and/or staining.
 WARNING: Does of this unit near theroceaster lighting may cause interference regarding use of
 the remote. If the unit is displaying creatic behavior move away from any fluorescent lighting, as
 it may be the cause of the control of the property of the control. The planting of the property of the control of the property of

- autres offices as seminators.

 Keep new and used batteries away from children. If the battery compartment does not close securely, stop using the product and keep it away from children.

- Gardee les piles neuves et d'occasion à partir des enfants. Si le compartiment de la batterie ne

 pas fermer correctement, cesser d'utiliser le produit et garder loin des enfants.

 Il you think batteries might have been swallowed or placed inside any part of the body, seek
 immediate medical attention.

 Si vous pensez que les batteries peuvent avoir été avalé ou placé à l'intérieur d'une partie du corps,
 consulter immédiatement un médecin.

 Do not mix old and new batteries.

 Ne pas médianger vieilles et nouvelles batteries.

 Completely replace all old batteries with new ones.
 Remplacer complétement toutes les piles par des neuves.

 Do not mix alkaline, standard (carbon-zino), or rechargeable (ni-cad, ni-mh, etc) batteries.

 Ne mélanges pas des plue alcalines, standard (carbon-zino) ou rechargeables
 (Ni-CA, Ni-MH, etc) batteries.

 Batteries should be recycled or disposed of as per state and local guidelines.

 Piles doivent être recyclèes ou éliminées selon les directives étatiques et locales.



WARNING: To reduce the risk of electric shock, do not remove cover (or back). No user-serviceable parts inside. Refer servicing to qualified service personnel.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



This symbol indicates that this product incorporates double insulation between hazardous mains voltage and user accessible parts.


FEATURES AND CONTROLS

FEATURES

- Supports Bluetooth
- Wireless range: 33 feet
- Built-in microphone
- Micro-USB port for battery recharge
- Aux in (3.5mm audio input)
- Adjustable headband
- On-ear controls
- DC battery power: built-in rechargeable lithium ion battery
- Battery life: approx. 8 hours at 100% volume 15 hours at 50% volume

INCLUDES

- Micro-USB to USB cable
- 3.5mm audio cable
- Carry pouch











BLUETOOTH

Pairing a Bluetooth Device for the First Time

- Simultaneously power on the unit and begin the pairing process by pressing and holding the **Power/Pair** button for approximately **4 seconds.**
 - The indicator will flash red and blue. When pairing, remain within 3 feet of the unit.
- 2. Using the native controls on your Bluetooth device, select the **IAHB64** in your Bluetooth settings to pair.
 - If your device requests a password, enter the default password 0 0 0 0. Refer to the user's manual for your specific device for instructions on pairing and connecting Bluetooth devices.
 - After initial pairing, the unit will stay paired unless unpaired manually by the user or erased due to a reset of the device.
- If your device should become unpaired or you find it is unable to connect, repeat the above steps.

LINE IN

Using the Audio Input

Requires a 3.5mm audio cable (included).

- Connect a 3.5mm audio cable to the Line In Input on the unit and the audio output on an audio device.
- 2. Use the controls on the connected device to select and play your audio through the headphones.

Playing Audio Wirelessly

- 1. To play or pause the selected track, use the native controls on the connected Bluetooth Device or press the **Play/Pause/Volume** button.
- Audio played through the connected Bluetooth device will now be heard through the headphones.

Using the Speakerphone

- 1. When a call is received, a ringtone will sound through the headphones.
- 2. Press the **Power/Pair** button to accept the call or accept the call with the native controls on the connected device.
- The incoming call received through the device will now be heard through the headphones.
- To end the call, press the Power/Pair button or end the call using the controls on the connected device.
 Note: To re-dial the last dialed number, press the Power/Pair button twice.

LED INDICATORS

STATUS	INDICATOR
Power On	Flashing blue light
Power Off	No light
Charging	Solid red light
Charging Complete	No light
Pairing	Flashing red and blue lights





INTERNATIONAL SUPPORT

To download this User's Guide in English, Spanish, or French, or to get answers to frequently asked questions, visit the support section at: **www.iLiveElectronics.com**

Para descargar este Manual del Usuario en inglés, español y francés, o para obtener respuestas a preguntas frecuentes, visite la sección de apoyo en: **www.iLiveElectronics.com**

Pour télécharger ce guide de l'utilisateur en anglais, espagnol ou français, ou pour obtenir des réponses à des questions fréquemment posées, consultez la rubrique d'assistance sur: **www.iLiveElectronics.com**

For Warranty Information and the most up-to-date version of this User's Guide, go to www.iLiveElectronics.com

Customer Service: 1-888-999-4215 | Email Support: prodinfo@dpiinc.com | Email Parts: partsinfo@dpiinc.com

Copyright © 2014 Digital Products International (DPI, Inc.) All other trademarks appearing herein are the property of their respective owners. Specifications are subject to change without notice.





Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- —Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.