
Many thanks for purchasing our product! This is a portable wireless control, used for mobile phone,MID,TV box, smart TV,PC and so on.lt can be used as gamepad, wireless mouse, music control, e-book page, PPT presentation etc.and support IOS, Android, Windowsoperate system and so on.

 $\textbf{Important Note:} \ \, \textbf{Products are subject to change without any notice.} \ \, \textbf{And}$ this product has applied for patents, counterfeiting is not pemitted

Oproduct sketch map :



Operating instructions:

(1) Power On: Press START button until LED is on (about 2 seconds). Default

is automatic mode.

Power on mode changing instruction(please operater on power off mode)

Stand automatic mode: Press A button, then press START to power on, Mouse light
will be on first, this is standard mode;
Android MTK mode: Press Y button, then press START button to power on, charging
light will be on first, this is Android MTK mode;



Power on

Press START button until LED is on (about 2 seconds) . Default is automatic mode

Apple iCade mode: Press B button, then press START button to power on, GAME light

will be on first, this is Apple iCade mode;
Apple iOS mode: Press X button , then press START button to power on, KEY light will pe on first, this is Apple iOS mode;

Remark:(1)when use the specified mode for first time, then press START button to power on next time, remote will default specified mode before. If need shift to other node, please refer to above power on mode.

(2) Under stand automatic mode, when connected with Android equipment then it is stand Android mode, when connected with Apple equipment, then change to Apple iCade mode. If under other mode, device can't shift mode automatically.

Power off

Long press START button, LED light will flash to off(about 5 seconds), device will power off. Note: If no connecting with Bluetooth device after 5mins, system will power off



(2) Power off: Long press START button, LED light will flash to off (about 5 seconds), device will power off. Note: If no connecting with Bluetooth device after 5mins, system will power off automatically, after connecting with Bluetooth device, if no any operation, system will power off after 3mins.

Pair and connect

after power on, LED will flash, the device will enter into the Bluetooth pair mode automatically to find the address and name of this device(X-039-XXX), click then can

3 Pair and connect : after power on, LED will flash, the device will enter into the Bluetooth pair mode automatically to find the address and name of this device(X-039-XXX), click then can connect. Pair and connect successfully, LED indicator will turn off. Next power on, it can connect and match the last Bluetooth device. Under turn off state.long press START button more than 8 seconds, LED will flash, then go to pair mode again, and can't connect last paired device automatically.

 $2. \mbox{GAME function:} \mbox{(Turn side switch to Game side, now device is operated by }$

(1) Standard Android device: In Menu, if joystick can move cursor, X, Y button is on button, A B button is returning key; this means your mobile system car

support international standard gamepad, just download game and play directly (If can't

support international standard gamepad, just download game and play directly (if can't operate, the neter to part (2), Android MTK mobile operation).

Game Download: use QR code software to scan QR code on the device (or enter into website http:// www.mcouts.com) to enter into ZHUZILIN download center, then you can download ZHUZILIN game application or third party's game application. ZHUZILIN Game penter have all gamepad games, and support NES/GRIGGECFCS/MDIGBAN/MAME/EPS games. Users can also download simulator BIN files to Games file folder in mobile, then can use ZHUZILIN software to open the game file, like many famous games: Super Mario, Metal Slug, Sangokushi and so on.

and so on.

Android games usually have gamepad type, download this kind of games, just connect
with Bluetooth then can operate with gamepad directly, this kind of games are like:
Elternity Warniors 2, FIFA 15 and so on. (Some games maybe need set to use
gamepad control when playing)

Senior game combination key : L1=SELECT+A R1=SELECT+B

right joystick=left joystick+START L2=SELECT+X R2=SELECT+Y

② Android MTK mobile operation:Like Redmi 3G version, Huawei Honor3X, ② Android MTK mobile operation.Like Redmi 3G version, Huawei Honor3X, CoolPAD, Zhongxing, these old style mobiles use MTK CPU, due to MTK bad compatibility, they can't support international standard gamepad agreement. So if by standard Android connection method, unusual problems will happen. We preset MTK mode to support ZHu/ZLIN games.
③ Mouse operation(just for Android)in GAME mode: In GAME mode, press M button, then yellow MOUSE indicate light will be on, mouse function ok. Now joyatick can move cursor, X button is volume+, A button is volume+, B button is left key of mouse, Y button is returning, and pressing M button again can quit mouse function.
⑤ Manual Cafe mode: Take into JOS APP store or other Anna store search "icade"

Apple iCade mode: Enter into iOS APP store or other Apple store, search "icade".

Hen you can find games of Cade which support gamepad, download and install then ok, like Akane Lite, Brotherhood, TTR Premium and so on. Before play games, please set keyboard linput mode to English input and can input English letters then ok. Next, please connect with Bluetooth and enter games then an play (Some games maybe need set to use iCade when playing)

Combination key: L1=SELECT+A R1=SELECT+B
when connected with control, if soft keyboard can't work, please hit M button or

 Apple iOS model 2: This mode is custom non-standard third party Apple game model(like NFW GAMF) 3.KEY mode function(please turn switch to KEY on device side, now device is operated by single hand and multimedia function buttons work on back)

① Android devices: X button is Volume+, A button is Volume-, B button is

mute, Y button is returning key:

Music function operation: after connected with bluetooth, open media player(like
SAMSUNG's media player), and play music, now our remote can do some
operations: like stop, play, pause,changing songs and so on . Long pressing

us/next can forward/backward

Self-shutter: Android/Apple mobile use "camera" to take photoes. Android mobile like Sent-situate. Autionary-per titionize externed to take protects, Autional mobile can go into SAMISUNG can use Volumn to adjust focus length, other Android mobile can go into camera setting to set volume for taking photo or scan barcode to download ZHUZHILIN application software, then can use camera directly. E-Book page up and downleader use Volume+/- to page, Kindle use jokstick to

page. Mouse function:Pressing M button, then yellow MOUSE indicated light ill be long on, now mouse can work, joystick can move, SELECT is for left key of mouse, START is right key of mouse, top button is mouse long-pressing function, when pressing top button, MOUSE indicated light will flash, now moving mouse can achieve drag function or pressing top button and using joystick to achieve drag function.

②Apple device: X button is Volume+, A button is Volumne- B button is mute, Y button is HOME, Musice and self-shutter is same with Android device. Apple device

don't support mouse function.

4.Key-locked function 4.Rey-locked full club.

After device connected, pressing SELECT and M button at the same time, can lock all keys beside START key(Means other keys can't work), and pressing SELECT and M button at the same time again can unlock, when buttons locks, KEY and GAME

indicated light will flash at the same time.

siblefor compliance could void the user's authority to operate the equipment. This equipment has beentested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection a gainst harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio on the complete that the complete the complete the complete that the complete the complete that the complete the complete that the complete that the complete the complete that the complete that the complete that the complete the complete that the complete the complete that the complete

Our product is with inner rechargeable lithium battery, when power is low, charging red LED will flash.Please insert 5V USB port to charge, then charging LED will be on. And when power is full, charging LED will be off. Notes: 1. When accident cause not boot or unable to shutdown, please use needle

to press Reset button on side.

2.If already paired ,but can't connect, please cancel the pair and boot the device and

Item	SPEC
SIZE	92mm*40mm*10mm
weight	27 gram
wireless protocol	wireless 3.0 compliant
wireless distance	2-10 meters
08	Android /iOS/PC
Battery	Rechargeable lithium battery 100mA
Working time	About 10hours
Recharging current	5V <200mA



ce that may cause undesired operation.

FCC Warning Statement
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equ



START.....

Universal Wireless Remote Controller

Operation Manual




ON/OFF

Press START button until LED is on (about 2 seconds) Default is automatic mode.



Pair and Connect

After power on, LED will flash, the device will enter into the Bluetooth pair mode automatically to find the address and name of this device(X-039-XXX), click then can connect



Mode Change

Press M button, change mouse mode Toggle Switches to change GAME or KEYmode.



Multimedia function Button

Multimedia keys for operations such as pause and down song.



Download

Support massive resources