

# Monopodfor Android phone & iPhone Extendable Wireless Shutter Release

## Product Manual V 1.0

with iOS 4.0, Android 3.0 and above systems release monopod BM-101. This product is based on Bluetooth wireless communication technology. It supports smart phones Thanks for choosing Essentialz extendable wireless shutter

#### . Features

- 1.1 Monopod with Built-in Bluetooth Remote Shutter Button (2 in 1);
- 1.2 Phone holder with a stand behind, which enables watch TV or video. you to use the holder independently on table to
- Non-slip soft silicon handle;
   4 One size adjustable phone adapter fit all phones width between 5.5-8.5 cm;
- 1.5 Adjustable ball head and thumb screw of monopoc locks for multiple angle shooting with 180 degree
- position: 1.6 Compatible Phones: iPhone 5S 5C 4S 4, Samsung Galaxy S5 54 S3 Note 3/2, Motorola Moto G, Huawei 4/5/7/8, HTC One M8 Sony Xperia BLU Studio and other Android Smart Phones; Ascend, LG Optimus, Amazon Fire, Google Nexus
- 1.7 Supports both photo and video shooting. A good assistant to take photos by yourself when you alone or take photos with all members;
- 1.9 Perfect for: Traveling, Video diaries, Hiking/camping 1.8 Universal 1/4 inch screw, can also be used for Digital Film Camera;

## Package contents

Parties, etc

- 1 x Extendable Wireless Shutter Release Monopod
  1 x Phone clamp bracket
  1 x USB charging cable
  1 x User manual

## Specifications

Standby time: 100 hours Supports, iOS 4.0, Andriod 3.0 and above systems Battery capacity: 45 mAh Charging voltage: DC 5V Max loading weight: 500g Net Weiht: 160g Length Flex of the holder: 225-1090 mm Main material: stainless steel Working temperature—10 to 40 C Working humidity: 10%—90% Charging time: I hour

### 4. Instructions

- 4.1 Bluetoolh pairing
- 4.1.1 Switch the power button on the tail end of the monopod. The blue LED light inside the holder start to flash for 3 minutes, indicating the monopod is sending out Bluetooth signal.
- 4.1.2 While the blue LED light is flashing, go to Bluetooth menu on your smart phone, turn on Bluetooth, and start to search for Bluetooth device Your phone will
- 4.1.3 Select"iselfie". When the phone asks if you want find "iselfie
- to pair with it, confirm by selecting Yes or OK 4.14 When the pairing is completed, the blue LED light will stop flashing, and goes off.
- phone, please switch off the monopod and turn off the Bluetooth of the phone currently in use Then repeats the steps from 4.1.1 to 4.1.3 4.2 Put the mobile phone into the phone clamp bracket Note: If you want to use the monopod with another

- Note: the clamp bracket can be extended vertically to
- hold bigger smart phones.

  4.3 Fix the mobile phone clamp bracket on the screw.

  Turn the thumb screw on the right side of the clamp bracket to lock for multiple shooting angles
- 4.4 Enter smart phone camera application 4.5 Stretch the monopod
- 4.6 Focus on yourself and push the "press" button

Note: when the smart phone is in video application,

the "press" button can start and stop the video

# Battery charging

shooting

If the blue LED light does not flash after switching on

or the phone does not respond to the "press" button after paired, it means the battery has run out, Please connect the monopod to the USB port of a PC with the micro USB charging cable to charge the battery. The LED light in the monopod turns red while charging, and will go off after battery is fully charged. The charging time is about 1 hour.

### 6. Cautions

- 6.1 After paired with smart phone, the monopod "press" button can increase the volume of the phone when the phone is in the standby state
- 6.2 After use, please switch off the monopod to save
- power and avoid unintended operation 6.3 The Bluetooth remote shutter monopod does not available) to take selfies. timer function of the phone (if this function is support Windows phones at present. But you can use it as an extendable monopod and use the self

#### Safety

- 7.1 Don't dismantle the product
  7.2 Don't use corrosive solvent to clean the product
  7.3 Don't use or charge the product under high
- temperature or strong light

- 7.4 Don't use it in the rain
  7.5 Don't throw it into fire
  7.6 Don't squeeze or smash it by force

### 00 Produce available colors



Essentialz International Co., Ltd. www.essentialzintl.com

> approved by the party responsible for compliance could FCC Caution: Any changes or modifications not expressly

This device and its antenna(s)must not be co-located or undesired operation. received, including interference that may cause And (2) this device must accept any interference This device maynot cause harmful interference, Operation is subject to the following two conditions: This device complies with Part 15 of the FCC Rules. user's authority to operate this equipment.

equipment generates, uses and can radiate radio harmful interference in a residential installation. This designed to Provi dereasonable protection against pursuant to Part 15 of the FCC Rules. These limits are comply with the limits for a Class B digital device, NOTE: This equipment has been tested and found to transmitter. operating in conjunction with any other antenna or

 Reorient or relocate the receiving antenna. interference by one or more of the followingmeasures: and on, the user is encouraged to try to correct the which can be determined by turning the equipment off cause harmful interference to radio or television reception occur in a particular installation. If this equipment does maycause harmful interference to radio communications installed and used in accordance with the instructions, However, there is no guarantee that interference will not requency energy and, if not

- Increase the separation between the equipment and
- Connect the equipment into an outlet on a circuit
- Consult the dealer or an experienced radio/TV different from that to which the receiver is connected technicianfor help.