

Please read all of the instructions carefully and retain for future reference.

Safety Instructions

When using electrical units, basic safety precautions should always be followed.

Check that the voltage indicated on the rating plate corresponds with that of the local network before connecting the unit to the mains power supply. Children aged from 8 years and people with reduced physical, sensory or mental capabilities or lack of experience and knowledge can use this unit, only if they have been given supervision or instruction concerning use of the unit in a safe way and understand the hazards involved. Children should be supervised to ensure that they do not play with the unit.

Unless they are older than 8 and supervised, children should not perform cleaning or user maintenance. This unit is not a toy.

This unit contains no user serviceable parts. If the unit and any of its accessories are malfunctioning or it has been dropped or damaged, only a qualified electrician should carry out repairs. Improper repairs may place the user at risk of harm. Keep the unit and USB cable out of reach of children. Keep the unit and USB cable away from heat or sharp edges that could cause damage.

Keep the unit away from heat sources, direct sunlight, humidity, water and any other liquid.

Keep the USB cable away from any parts of the unit that may become hot during use.

Keep the unit free from dust, lint etc.

Do not immerse the unit in water or any other liquid.

Do not operate the unit with wet hands.

Do not operate the unit if it has been exposed to water, moisture or any other liquid, to prevent against electric shock, explosion and/or injury to yourself and damage to the unit. Do not leave the unit unattended whilst connected to another device.

Do not use the unit for anything other than its intended use. Do not use any accessories other than those supplied.

Do not use this unit outdoors.

Do not store the unit in direct sunlight or in high humidity conditions.

Do not move the unit whilst it is in use.

Do not put objects into any of the openings.

Do not play music at excessive volume levels as damage to hearing and/or the equipment may occur.

It is imperative to unplug the USB cable after the unit has been used, before it is cleaned and whilst being repaired. This unit must be placed on a stable, heat-resistant surface. This unit is intended for domestic use only. It should not be used for commercial purposes.

To prevent possible hearing damage, do not listen at high volume levels for long periods of time.

Warning: Keep the unit away from flammable materials.

Battery Safety

The battery unit should not be placed near excessive heat sources, such as fire.

The supply terminals are not to be short-circuited.

Exhausted batteries should be removed from the unit to avoid leakage.

In the event of the battery leaking, do not allow any liquid to come into contact with the skin or eyes.

If contact has been made, wash the affected area with copious amounts of water and seek medical advice.

Keep batteries out of reach of children.

Avoid storing in direct sunlight.

Do not dispose of the battery unit in a fire.

Do not crush, puncture, dismantle or otherwise damage the battery.

Do not store above 60 °C.

Do not expose batteries to heat or fire as they may explode.

Do not subject the battery (batteries) to mechanical shock.

Do not dispose of the exhausted battery in your household waste.

To dispose of the exhausted battery, take it to your local recycling station. Contact your local government offices for further details

This unit is fitted with a 800 mAh li-ion rechargeable battery.

Getting Started

Remove the unit from the box.

Remove any packaging from the unit.

Place the packaging inside the box and either store or dispose of safely.

In the Box

T16 Main Unit USB Cable Aux. In Cable Instruction Manual

Features

Bluetooth Version 3 O FDR

Aux. Input Function


Total Speaker Output: 10 W Battery Type: 800 mAh USB Charging Cable Included

Charging Time: 3 Hours Approx.

Driver Size: 2Ω 10 cm

Frequency Response: 70 Hz ~ 20 kHz

Description of Parts



- 1. T16 Main Unit
- 2. Speakers
- 3. Battery Compartment Cover 8. Skip + Button
- 4. Control Panel
- 5. Bass Control Dial

- 6. Skip Button7. Play/Pause Button

- 9. Mode Button
- 10. Volume Control Dial
- 11. Aux. Indicator Light
- 12. Bluetooth Indicator Light
- 13. On/Off Switch
- 14. Micro USB Charging Port
- 15. Aux. Input Jack

- 16. Charging Indicator Light
- 17. USB Cable
- 18. Mini USB Connector
- 19. USB Connector

Instructions for Use Using the T16

Plug the micro USB connector on the USB charging cable into the micro USB charging port on the reverse of the T16 and then plug the USB connector into a compatible USB port on a powered device to begin to charge the T16; this will take 2-3 hours approx. The charging indicator light will illuminate red, indicating that the T16 is charging; this will switch off once the T16 has fully charged.

Switch on the T16 by flicking the On/Off switch to the 'On' position; slide it to the 'Off' position to switch it off. Press the 'Mode' button on the control panel to change between the Bluetooth and Aux. functions; the corresponding indicator light will illuminate, indicating which mode is currently selected. Adjust the volume of the T16 by turning the volume control dial or using the connected Bluetooth compatible device. To alter the bass, turn the bass control dial.

Bluetooth Mode

Press the 'Mode' button on the control panel until the Bluetooth indicator light illuminates.

Pair the Bluetooth compatible device with the T16 by selecting "EARISE T16" from the listed devices.

Tracks can be played, paused and skipped using either the Bluetooth compatible device or the control panel on the T16.

Adjust the volume of the T16 by turning the volume control dial or by using the connected Bluetooth compatible device.

Aux. Mode

Connect a 3.5 mm cable to the Aux. input jack and the other end to an audio device.

Press the 'Mode' button on the control panel until the Aux. indicator light illuminates red.

Tracks can be played, paused and skipped using the connected device.

Adjust the volume of the T16 by turning the volume control dial or by using the connected Bluetooth compatible device.

Troubleshooting

Problem	Cause	Solution
No power.	The USB adaptor has not been plugged in properly.	Ensure that the USB adaptor has been properly connected.
	The T16 is out of charge.	Charge the T16 as indicated in the section entitled 'Using the T16'.

No sound.	The volume level is set too low.	Check that the volume level is set at an audible level and adjust accordingly with the control panel or connected Bluetooth compatible device.
Unable to pair a Bluetooth device with the T16	The Bluetooth device is not compatible with the T16	Ensure that the Bluetooth device is compatible with the T16 and that the Bluetooth function on the device to be connected is switched on.
	The T16 has not been adjusted to the correct mode.	Press the 'Mode' button on the control panel until Bluetooth indicator light blinks. Pair the Bluetooth compatible device with the T16 by selecting 'EARISE T16' from the listed devices.

Care and Maintenance

Before attempting any cleaning or maintenance, ensure that the T16 is turned off at the mains power supply and has been unplugged.

Wipe down the T16 with a soft, damp cloth and dry thoroughly.

Do not use abrasive cleaning solvents to clean the T16 Do not immerse the T16 in water or any other liquid. Do not expose the T16 to extremely high or low temperatures, as this may destroy the battery.

Specification

Product code: T16 Power source: 5 V USB

Output: 2 x 5 W

Frequency response: 70 Hz ~ 20 kHz Battery: 800 mAh rechargeable Charging Time: 3 Hours Approx.

Notes:		

WARNING: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interferencewill not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Mei Zhi Zun Electronics Technology Co., Ltd.

If this product does not reach you in an acceptable condition please contact our Customer Services Department by one of the following methods:

Telephone: +0086 769 89166166

Please have your delivery note to hand as details from it will be required.

If you wish to return this product please return it to the retailer from where it was purchased with your receipt (subject to their terms and conditions).

Guarantee

This product is guaranteed for a period of 1 year from the date of purchase against mechanical and electrical defects. This guarantee is only valid if the appliance is used solely for domestic purposes in accordance with the instructions and provided that it is not connected to an unsuitable electricity supply or dismantled or interfered with in any way or damaged through misuse. Under this guarantee we undertake to repair or replace free of charge any parts found to be defective. Reasonable proof of purchase must be provided.

Nothing in this guarantee or in the instructions relating to this products excludes, restricts or otherwise affects your statutory rights. In line with our policy of continuous development we reserve the right to change this product, packaging and documentation specification without notice.

Consumables are not guaranteed i.e. plug and fuse.

The crossed out wheelie bin symbol on this item indicates that this appliance needs to be disposed of in an environmentally friendly way when it becomes of no further use or has worn out. Contact your local authority for details of where to take the item for recycling.

FCC RF Radiation Exposure Statement:

- 1. This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
- 2. This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This device was tested for typical hand held operations with the device contacted directly to the human body to the sides of the device. To maintain compliance with FCC RF exposure compliance requirements, avoid direct contact to the transmitting antenna during transmitting

EARISE



Factory:Dongguan MeiZhiZun Electronics Technology Co., LTD The 33rd of HeHe Road,XiangXi Village,LiaoBu Town,DongGuan City,GuangDong Province,China.

Http://www.earise.cn



DO NOT PRINT THIS PAGE ARTWORK REFERENCE ONLY