
IM-X-JS05 REV 1






Features and Specifications

- Main device parameters
- Output Power: 3W
- Frequency Response: 150Hz-18KHz
- RMS: (THD=10%)
- Driver: 2"
- Power Supply: USB ,DC 5V -- 500mA
- Distortion: ≤0.5%
- S/N: ≥70dB
- Battery Capacity: 400mAh
- Battery Play Time: 1.5-2 hours
- Battery Charging Time: 1.5-2 hours
- Product Size: 170x71x70mm
- Product Weight: 350g

Package Contents

- 1. Speaker
- 2. User's Manual
- 3. USB to Micro-USB cable







Charging The Speaker

Before using the speaker for the first time charge for at least 24 hours.

- 1. Plug the Micro-USB cable into the port on the speaker. Plug the opposite, USB end, into the USB port on a computer or compatible AC wall adapter.
- 2. The red LED will turn on to indicate that the unit is charging.
- 3. Once fully charged, the red LED will turn off.

Pairing the Device

- 1. Place speaker within 30 ft of Bluetooth-enabled device.
- 2. Slide the ON/OFF button to ON. The blue LED will flash 3 times slowly then flash quickly to indicate Bluetooth
- 3. Follow the instructions of your device to search for the
- 4. The speaker is called "Zoom Audio Decible" If a PIN is required, enter "0000."
- 5. The blue LED will flash slowly when pairing is complete.

Basic Instructions

To turn the speaker on, slide the ON/OFF button to ON. The Speaker will beep and a blue LED will flash slowly. The blue LED will stay on when playing music.

The speaker will beep every 20 seconds when battery is low. To turn speaker off, slide the ON/OFF button to OFF.

LED Indicator

Charging: Red LED on Fully Charged: Red LED off Pairing Mode: Blue LED will flash quickly Connected: Blue LED will flash slowly Plaving: Blue LED on


Safety Information

Do not expose the device to water or attempt to disassemble the device to reduce the risk of electric shock. Do not use this product in an aircraft or in a hospital. Do not expose the device to direct sunlight, heat or flame. Device may become warm while charging.

Caution

- · Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.
- This device and its antenna(s) must not be co-located or operate in conjunction with any other antenna or transmitter.

Speaker Button Functions



- 1.

 Decrease Volume/Previous Track Short press for previous track, press and hold to decrease volume
- 2.

 Phone Answer/Redial/Play/Pause Button When Bluetooth connection is active: Press button once to pause and again to resume play. Press button once to answer an incoming call. Double click to redial the last call.
- 3. @ Increase Volume/Next Track Short press for next track, press and hold to increase

When volume reaches maximum limit, speaker will beep.

Use a computer USB port/AC power adapter with USB When battery is low, approximately 4 hours of charging

time is necessary to replenish battery capacity.

- 5, ⊕ Power On/Off
- 7.

 Microphone
- 8.

 Bluetooth LED Indicator

Blue light, guick flash = searching for Bluetooth signal. Blue light, slow flash = Bluetooth connection successful, Red light on = charging

(Once completely charged, light will turn off).

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference and
- 2. This device must accept any inference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can against raminal interference in a leasterinal installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures Reorient or relocate the receiving antenna.

- —Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is
- —Consult the dealer or an experienced radio/TV technician for help

Art.No.: 7003-47 Made in China

生产单号	:		型된	글:	Q5	
料号:			物料	4名称:	说明书	\$
其它要求	· 尺寸:7 材质:1	'0*134mm 05G铜板纸,	单	铜单配	面印刷	
美	エ			结构	构	
电	子			审相	亥	