Connecting your selfie stick to a Windows device

 In the App List, tap [SETTINGS], then tap [BLUETOOTH]. Enure Bluetooth is 'On' then wait while Windows searches for Bluetooth devices. When the Caseflex Selfie Stick has been found, tap on the device to connect.



 You have successfully connected your Bluetooth selfie stick to your Windows device.

Charging

- This selfie stick is supplied with a Micro USB cable. Before charging, make sure the selfie stick is switched off. (To switch off hold down shutter button until the light turns off)
- Plug the Micro USB cable into the charging port and connect to a powered device or mains adaptor.
- When the battery is full, the Red LED light will switch off.
- For first time charging, ensure the battery is charged fully before use.





PJA Distribution Limited TEL:+44-1642 788882 Fax:+44-1642 788882

Connecting your selfie stick

 On the handle, press and hold the Bluetooth shutter button to turn on. The indicator light will flash to show the selfie stick is ready to be connected to a device.



 Now follow the relevant set of further instructions (see overleaf).

Connecting your selfie stick to an iOS device

 On your iPhone, tap the [SETTINGS] icon. Select [BLUETOOTH] and turn on. The iPhone will automatically search for a Bluetooth-enabled device. When the Caseflex Selfie Stick has been found, tap on the device to connect.



 You have successfully connected your Bluetooth selfie stick to your iOS device.

Connecting your selfie stick to an Android device

On your phone, tap the [SETTINGS] icon. Click [Bluetooth] to access the [Bluetooth Settings] page, ensure Bluetooth is 'On'. Click [SCAN FOR DEVICES]. When the Caseflex Selfie Stick has been found, tap on the device to connect.



 You have successfully connected your Bluetooth selfie stick to your Android device.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.