USER MANUAL

o controller battery installation:

- o loosen the screws on the he radio controller.
- installed correctly according to the positive (+) and negative (-) marking on the battery compartment. c) Replace the battery cover and tighten screw. ry cover of the radio controller. ease install the battery and make sure the battery is
 - cover and tighten screw. Replace the battery





and can Uses 2 "AA" size batteries NOTE: This equipment has been tested and found to co limits are designed to provide reasonable protection aga radiate radio frequency energy and, if not installed and i communications. However, there is no guarantee that is


5 "AA"Size Batteris

Uses

(Not Included)







ELONGATE

NO.1911-17B