


use this portable charger!



All sketches shown are visual guides and examples


on how to operate the Portable Wireless Charger.



* You can not charge the battery while charging F704W







* Power adapter and wireless charging pad NOT included

Caution

- Do not disassemble or apply excessive pressure.
- Avoid using in extreme temperatures.
- Keep away from liquids and moist environments. - Avoid direct contact of the portable wireless charger
- with magnetic chips/cards and implantable medical devices to prevent magnetic failure and potential malfunctions.
- Keep out of reach of children.

Included in Package

- Portable Wireless Charger(F704W)
- Power Cable
- 150cm Power Cable
- User Manual


Specification

주의


- Battery:Polymer Li-ion Battery
- Battery capacity:4000mA
- Input voltage:DC5V, 2A MAX
- Ouput voltage:DC5V, 2.1A
- Dimensions:105x72x20mm - Weight:135g

FCC REQUIREMENTS PART 15

- Caution: Any changes or modifications in construction of this device which are not expressly approved by the responsible for compliance could void the user's authority to operate the
- NOTE: This device complies with Part 15 of the FCC Rules.
- Operation is subject to the following two conditions; 1. This device may not cause harmful interface, and
- 2. This device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to Part 15 of the FCC Rules. These limits are designed to this equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions. may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the radio or television off and on, the user is encouraged to try to correct interference by one or more of the following measures.
- 1) Reorient or relocate the receiving antenna.
- 2) Increase the separation between the equipment and
- 3) Connect the equipment into an outlet on another circuit. 4) Consult the dealer or an experienced radio/TV technician
- for help.



SP1312







* 전원 어댑터와 무선 충전 패드는 포함되어있지 않습니다.

- 분해하거나 무리한 충격을 가하지 마십시오
- 극도로 높거나 낮은 온도에서 사용하지 마십시오
- 액체나 습기가 많은 환경을 피하십시오
- 자석에 의한 고장이나 오동작을 막기 위해 마그네틱 칩

