DISCO DOME PARTY LIGHT


Part # LS-HZ-DOME6 15-0518

PARTS

Dome speaker




3.5mm audio cable




AC charging cable



Voltage rating: 5Vdc 1500mA




- (1) MODE SWITCH BUTTON
- (2) PREVIOUS SONG/VOLUME DECREASE
- (3) PLAY/PAUSE
- (4) NEXT SONG/VOLUME INCREASE
- (5) LED LIGHTING MODE



Back

- (A) MINI USB PORT
- (B) USB PORT
- (C) TF CARD PORT
- (D) 3.5 AUDIO JACK (AUX)
- (E) POWER ON/OFF

SET UP



- (1) Plug AC adapter into power source
- (2) Switch power to On
- (3) Turn volume down before connecting to device
- (4) Press mode button to choose input:
 - Bluetooth mode, sync to device
 - AUX mode, plug in 3.5mm audio cable
 - USB mode, plug in flash drive
 - TF mode, insert TF chip
- (5) Adjust volume level
- 6 Press LED mode button to choose between four LED color modes

WARNING NOT A TOYNot for use by children.

Do not open base or tamper with electrical source. No user servaceable parts inside. For indoor use only. Place on flat surface and away from flammable materials. Never operate this appliance if it has a damaged cord, plug or cable.

Keep cord away from heated and/or damp areas.

www.LumiSource.com

3.5mm audio cable

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.