

## Troubleshooting

Please read this User Guide carefully before using your wireless speaker. Check this list for a possible troubleshooting solution before calling for service.

Problem	Solution
No power	<ul style="list-style-type: none"> <li>Make sure that the USB charging line is correctly connected.</li> <li>The built-in lithium battery may be drained. Charge the battery by connecting the USB charger.</li> </ul>
No sound output via Bluetooth	<ul style="list-style-type: none"> <li>Make sure your Bluetooth device is properly connected to the speaker.</li> <li>Make sure that the volume level of your AcTek device is not set to the minimum.</li> <li>Make sure that the volume level of your Bluetooth device connected to the speaker is not set to the minimum.</li> <li>Make sure that your Bluetooth device is not muted.</li> <li>Make sure that your stereo audio cable is not connected to the AUX IN jack of the speaker.</li> </ul>
No sound output in AUX IN mode	<ul style="list-style-type: none"> <li>Make sure that the AUX cable is undamaged and firmly connected to the AcTek device.</li> <li>Make sure that the volume level of the speaker is not set to the minimum.</li> <li>Make sure that the volume level of the connected external device is not set to the minimum.</li> </ul>
Low Battery Warning	<ul style="list-style-type: none"> <li>When the battery is low, the indicator light will turn red and an alert will sound. Use the USB cable for charging.</li> <li>The internal battery is drained. Charge the battery or connect the USB charger and turn on the system again.</li> </ul>
Bluetooth connection cannot be established	<ul style="list-style-type: none"> <li>Make sure that the audio cable has been removed from the AUX IN jack of your wireless speaker.</li> <li>If the connection fails when making a Bluetooth connection between the speaker and your Bluetooth device for the first time, turn off your AcTek unit, then turn it on again to clear the device name, then try the connection again.</li> </ul>

4

## Specifications

Designs and specifications are subject to change without notice.

English	Español
Transducers	2x40mm
Amplifier power	2x4W
Frequency response	150Hz - 20kHz
Signal-to-noise ratio	>85dB
Battery type	polymer Li-ion
Bluetooth transmitter Frequency range	2.402-2.480GHz
Listening time on battery power	Up to 10 hours@0.2W
Battery charge time(Max)	3 hours
Dimensions	159*108*143(mm)
Bluetooth version	V3.0+BLE
Francés	Deutsch
Transducteurs	2x40mm
Puissance d'amplificateur	2x4W
Courbe de résonance	150Hz - 20kHz
Rapport signal sur bruit	>85dB
Type de batterie	Li-ion polymère
Plage de fréquence de l'émetteur Bluetooth	2.402-2.480GHz
Autonomie d'écoute	> 10 heures (@0.2W)
Durée de charge	3 heure
Dimensions	159*108*143 (mm)
Bluetooth version	V3.0+BLE
Italiano	日本語
Trasduttori	2x40mm
Potenza amplificatore	2x4W
Risposta in frequenza	150Hz - 20kHz
Rapporto segnale-rumore	>85dB
Tipo batteria	polimeri di ioni di litio
Intervallo di frequenza trasmettore Bluetooth	2.402-2.480GHz
Tempo di ascolto con batteria	> 10 ore @0.2W
Tempo di ricarica della batteria	3 ore
Dimensioni	159*108*143 (mm)
Versione del Bluetooth	V3.0+BLE
	トランスデューサー 2x40mm アンプの電源 2x4W 周波数特性 150Hz - 20kHz 信号対雑音比 >85デシベル 電源 リチウムイオン充電池 Bluetooth送信周波数範囲 2.402-2.480GHz バッテリー再生時間 >10時間(@0.2W) バッテリー充電時間 3時間 サイズ 159*108*143 (mm) Bluetoothバージョン V3.0+BLE

5

## FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of FCC Rules. Operation is subject to the following two conditions: (1)This device may not cause harmful interference, and (2)This device must accept any interference received, including interference that may cause undesired operation.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate this equipment. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device is measured RF output power is less than the SAR exclusion threshold value for human head and body. Therefore, SAR test is not necessary.

6

## Contents


Introduction .....	1
Safety information .....	1
Features.....	2
Setting up/Using your wireless speaker.....	3
Troubleshooting .....	4
Specifications.....	5
FCC Statement .....	6

## Introduction

This manual explains how to correctly install, operate and get the best performance from your AcTek Wireless Portable Speaker. Read this user guide carefully before installing your system and keep it for later reference.

Your AcTek Wireless Portable Speaker uses Bluetooth to receive audio from a smartphone, tablet or any other Bluetooth-enabled device, providing superior level audio quality and resistance to interference.

## Safety information



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

## Important Safety Instructions

- 1) Read these instructions.
- 2) Keep these instructions.
- 3) Heed all warnings.
- 4) Follow all instructions.
- 5) Do not use this apparatus near water.
- 6) Clean only with dry, soft cloth. Household cleaners or solvents can damage the finish on your AcTek system.
- 7) Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- 8) Do not install near any heat sources such as radiators, heat registers, stoves or other apparatus that produce heat.

1

## Features

- 2-in-1, Bluetooth Speaker and phone stand
- Unique, patented design
- Touch-sensitive controls
- 2 broad-frequency response speakers
- Rich, 360°, crystal-clear sound
- Compatible with Android/IOS/Windows/MAC OS
- Built-in, rechargeable Li-ion battery provides up to 10 hours play time
- Supports both Bluetooth and Audio
- Memory pairing capability. Easy to operate
- Two-way USB port, plays and charges at the same time

## Package contents

Examine the contents of the box for your AcTek Wireless Speaker.

The box should contain:

- AcTek Wireless Portable Speaker
- USB charging cord
- 3.5mm Audio cable
- User Guide

2

**AcTek**™  
designed for Life

**Sundock 100**  
Wireless Portable Speaker




## AcTek™ Wireless Portable Speaker

### User Guide

Before using your new product, please read these instructions to prevent any damage.

## Setting up / Using your wireless speaker



3