Product Name:Bluetooth Speaker Model name:M3

Brand Name: AOMAIS

If you have any question please contact with our support

Customer Service Email:Support@aomais.com

Tool Free:833-4AOMAIS(833-4266247)

AOMAIS LIFE



Quick Start Guide Designed and Engineered By aomais

AGMAIS

www.aomais.com

Support@aomais.com 12-month limited warranty

Lifetime technical support

Your Bluetooth device may be out of range, move closer within 66 unobstructed Turn your AOMAIS LIFE off and back on.

No audio playing from the speaker when connected with the 3.5mm audio

Make sure the 3.5mm audio cable is fully inserted the AOMAIS LIFE and device.

Make sure your device is on and playing music. Increase the volume level on the AOMAIS LIFE and device. Poor sound quality when connected over Bluetooth Your Bluetooth device may be out of range, move closer within 66 unobstructed

Remove the AOMAIS LIFE from the Bluetooth device list on you source device, and then re-pair and connect to the speaker. Turn your AOMAIS LIFE off and back on. Some devices need to have their WIFI turned off to improve audio quality over

Poor sound quality when connected within the 3.5mm audio cable Reduce the volume level on the AUX source. Remove the charging cable while playing.

Page25

like to pair the speaker with a second different device, you must cut off the pairing between device and the speaker. Check that your AOMAIS LIFE has a sufficient battery charge, the speaker may not connect when the battery has a low charge.

The speaker can be paired with only one device at a time. Meaning if you would

Connect the speaker to a charging source and try again pair and connect. Your device may be out of range. Move it closer to within 66 unobstructed feet of Some older windows computers and operating systeams may have diffculty

connect using the 3.5mm audio cable. No audio playing from the speaker when connected over Bluetooth Remove the AOMAIS LIFE from the Bluetooth device list on you source

pairing and connecting over Bluetooth. If this occurs it is recommended to


device, and then re-pair and connect to the speaker.

Page24


1.Power button 2.TWS button/Play/Pause 3. Volume up/Next track

4. Volume down/Previous track

- 5. Transform button 6.Function button LED1
- 7.Battery charging LED2 8. Mobile power port
- 9.USB charging port 10.3.5mm port
- Page2



In The Package



Page1

Troubleshooting & Customer Support For assistance with the questions or any issue with your AOMAIS LIFE that

is not answered in the troubleshooting tips below, please contact us by visiting: AOMAIS.com/contact and sent the mail to our customer service. Can not turn on

The battery may have become fully drained. Charge the AOMAIS LIFE use wall

charge from a Smartphone/iphone, then press power button to turn the speaker on. Then continue charging the battery. Can not pair or connect to Bluetooth

Check the Bluetooth LED light (Blue) to make sure it is quick flashing. If it is blue light the AOMAIS LIFE is already connected to another source device.

Page23

Follow all instructions-All operating and use instructions should be

Safety and Precautions

followed. If not use the device for long time, to protect the battery life, please full

charge the Speaker and keep it alway spowered. Protect the Micro USB charging cable from pinched particularly at the connectors.

Unplug the USB charging cable during storms or when unused for long periods of time.


Page22

Model: AOMAIS LIFE

Specifications:

Woder. Admais Lif L	Addio Odiput. 3000
Size: 11. 93*3. 74*2. 99 inch	Range: 20m/66ft
Weight: 3. 07 lb	Input: 5V/2A
Bluetooth Version: V4. 2	THD: 1% Volume max
Main Material: Bamboo	Charging Time: 3. 5 hours
Battery Capacity: 5000mAh lithium battery	Play Time: 10 hours (50% Volume)
	Page3





Notice



60% of the volume. After the first use the speaker will remember the volume used last time.

Instructions

Power Button

Power Button

Volume -

Volume +

Bluetooth Button

Volume -

Volume +

Bluetooth + Vol-

Page21

Current status

Power on

Power off

Music playing

Music playing

Music playing

Connection Status


Connection Status

Bluetooth is connected

Notice

Page20









automatically.

Number

3

4

5

6

8

10

11

12

Function

Power On

Power Off

Volume +


Volume

Play / Paus

Previous Track

Next Track

Into the Pairing State



Seconds

2s

0.5s

0.5s

0.5s


0.5s

2s

2s

2s

Pairing&Bluetooth



3. The audible blue light will be on all the time when the pairing is successful.

Notice





If you accidentally press the horn into the speaker, you can use a transparent tape to restore it to the original state.

Page19


Notice

Page6









Note: Please turn off your bluetooth of your device before stereo pairing 2 speakers.

Note: The LED flashes slowly (blue) is the main speaker.

The LED is a blue light and does not flash speaker is slave

speaker.

Notice

LED1

Start your music party

Page7

Page17

Page9


Distance


Notice

Page16

Page12


Page18






WARNING: Please don't charging the speaker when it in wet Press the Volume "-" and Volume "+" you can change the Mono or condition, otherwise it will lead the battery burned Stereo mode. It is useful in a TWS (two speakers are paired) Plugged in for charging, please far away from water. If you have any question please contact with our support Email: situation. Support@aomais.com

EQ Button




Mono/Stereo



Notice


Bluetooth Connect



Page11




Page14



You can play with your Apple Mac, Laptop, Computer and

non-Bluetooth devices with the 3.5mm audio cable

Power Bank



mobile power bank so you can charge smartphones, tablets, or other devices that need a boost.

The built-in 3.7V/5000mAh battery even turns the speaker into a

The speaker will automatically to connect with the last source device. If you want to pair or connect to other source device you can press the Bluetooth and Volume - button for 4s to disconnect the current paired device.

Page13

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.