C2202

Instructions in English

Directory

CHAPTER 1 BASIC DESCRIPTION4
1.1 The Keyboard4
1.2 Phone features······4
1.2.1 Make a call5
1.2.2 Answer the phone5
1.2.3 To reject a call ································
CHAPTER 2 MENU DETAILS REFER6
CHAPTER 2 MENU DETAILS REFER6
CHAPTER 2 MENU DETAILS REFER 6 2.1 Alarm 6
CHAPTER 2 MENU DETAILS REFER 6 2.1 Alarm 6 2.2 Schedule 6
2.1 Alarm 6 2.2 Schedule 6 2.3 Memo 6

2.7 Phonebook7
2.8 Messages 8
2.9 Music player 9
2.10 FM radio 9
2.11 Camera9
2.12 Call10
2.13 Profiles11
2.14 Extra12
2.15 Bluetooth
2.16 Gallery13
2.17 Settings
2.18 Mobile TV16

Chapter 1 Basic Description

1.1 The Keyboard

- > OK kev: Enter the shortcut menu
- > left soft key: short press, call log into the interface
- > menu: short press to enter the main menu interface
- Return key: short press set personal preferences menu interface, in other cases, the return to the state at the next higher level

Power button: long press to switch machine; Short press, end or reject calls, call in other cases, the return to standby mode

direction key: short press to enter text interface

under the direction key: short press, into the inbox

direction left key: short press, situational model into the interface

right direction: short press, alarm clock into the interface

* Note: "Press a key, press this key after the release;" long press a key, press the key and hold for more than 3 seconds or 3 seconds.

1.2 Phone features

The phone trial is a single-C single standby function. UIM card can be inserted into the phone. To call and answer a call.

When the network provider's logo appears on the display, you can call or receive calls. The upper-left corner of the display signal bar display network

signal strength (of which there are four pieces of information that the strongest signal). The call quality is affected by the impact of obstacles is relatively large, so the movement in a small area can effectively improve call quality.

1.2.1 Make a call

> Domestic calls :

Use the numeric keys to enter the phone number, then press the dial key to start the call. If you need to change the phone number, press the direction key, down key, left, right arrow keys to move the cursor, press the right soft key key to delete characters entered. The dialing display will show the dialed animation. The other party answers the display will show the call status information, If you turn connected to a tone, a tone (network support).

After the call, press the Goodbye key to hang up the phone.

> Emergency call:

If the phone is in network coverage (check the phone display the upper-left corner of the network signal strength indicator that), you should be able to call the emergency services (even if there is no R-UIM card can make emergency calls). If your network supplier does not provide roaming services in the region, the display will show "Only emergency call (EMERGENCY), tells you can only make that sort of call.

1.2.2 Answer the phone

> Under normal circumstances, there is an incoming call, press the

- "SEND" key can answer.
- > If you set the Any key answer On, press any key to answer the call.

1.2.3 To reject a call

> There is an incoming call, you can press the "END" key to reject a call

Chapter 2 menu details refer

2.1 Alarm

Most mobile phones can be installed three alarm clocks (turned off the alarm clock is still valid after)

2.2 Schedule

Show that between January 1970 and December 1970 calendar (the Gregorian calendar and the lunar calendar), show memo event date.

Into schedule management interface, the or so direction key to date, before and after the menu button for the options button

2.3 Memo

> Enter the notepad, can record events, each not more than 120 characters

2.4 Recorder

> Can record the sound

2.5 Games

> Can run into the game tetris and related Settings

2.6 U-disk

> Open U disk, U disk, mobile phone connection USB, USB function can be

realized

2.7 Phonebook

- > View: You can view the stored contact details
- > New: New contacts, stored in the phone or R-UIM card.
- > Delete: Delete the contact
- Export record: To export business CARDS will exist in the mobile phone contact on mobile phones or T - flash record
- > Send SMS: Can edit the text messages sent to a contact
- > Call: UIM card and call a contact
- > IP dial: can use UIM card IP call contact
- > Add to blacklist : Contacts can be added to the blacklist
- Multiple choice :
- > New: new contacts, can be stored in the phone or R UIM card
- Search: through all show/name/number/group/phone list and R UIM list to find the phone book record
- Group: group can modify the ring tone/modify the group name and group messaging functions
- Delete: you can delete individual/phone/R UIM card/group and all contacts
- Import Record : There can be a phone or T flash record card into the phone book
- > Export Record: export business CARDS will exist in the mobile phone

contact on mobile phones or T - flash record

- Speed dialing: Set the speed dial, press the number keys can be directly dial the preset number
- > Own number: can set the machine number or modify
- Capacity:UIM card phone book and the usage of mobile phone book information

2.8 Messages

New Message :

Choose to write the contents of the edit box, edit the contents of the short message, you can select the input method, For details, see the part of the input method

In the process of new short messages, select the "Options" menu, you can up the options menu.

Inbox:

View received messages. After the short list of messages in the Inbox, press OK to read the message content.

> Outbox:

View unsent message. Outbox short message list, press OK to read the message content.

> Sent Items :

To view the information has been sent. Outbox short message list, press OK to read the message content.

> Drafts:

If you do not send SMS finished editing can be saved here. Information is sent after the dump has been sent information.

- SMS setting: At the time of using short message function, can enter the information set menu, enter related set of messages
- Delete all:Can be achieved, the inbox outbox/issued draft box/box, and all mail messages delete function, and can according to the number to delete messages

Voicemail: Can set up voicemail number and voice calls

2.9 Music player

This cell phone can play music files stored in the phone/T card, and support MP3 background play

The music player interface, press "*" to stop

In the song list interface, can choose songs

2.10 FM radio

Choose FM radio FM broadcast into the interface. In the FM broadcast interface, and then press the menu option to enter some FM associated Settinos

2.11 Camera

Phone camera, select the menu to enter the camera to take a picture, press the ok button.

Of the phone's built-in high-definition camera, you can take pictures

anytime, anywhere and save photos to the phone or T card (OK T card has been inserted)

2 12 Call

call setting

- > Answer mode: Open and close the Any Key Answer function.
- > Minute reminder : Opening and closing call tips.
- Call waiting: Turn on or turn off call waiting function. Select query to view the current call waiting state.

Call forward :

- ➤ All :Open unconditional transfer, the incoming telephone calls in any case transferred to the number you set₀
- Busy: On busy transfer, in your phone is busy, will be transferred calls to the number you set.
- No answer: On No Answer transfer, there is no answer your phone, will be transferred calls to the number you set.
- Default: Open implied transfer will not contact each other redirect calls to the number you set your case,

Call records

- > Missed call: Record number of missed calls.
- > Incoming call: Record received phone number.
- Outgoing call: Record dialed numbers.

- Duration: Record recently, accumulated inbound call, accumulated exhale, accumulated talk time, still can talk time reset
- Delete: Delete did not call, call, already has dialed the phone records, also all records can be deleted.

In the call history list interface, press OK, you can view the details of the record, including the date, call time, name, number, and the number of call.

Details screen, you can press the option currently selected phone records.

- view: view the number of contact person.
- Call: dial the phone records by R-UIM,
- add black list: the number is added to the black list
- send sms: Send a short message to the number,
- delete: delete the record.
- choose Delete: the call records selective deletion,

2.13 Profiles

General

- > Start: Choose to boot into standard mode.
- Edit profiles: elect to customize personal settings into the normal mode. Functions are as follows:

> Ring settings:

- Ring tone : Change the incoming ring.
- Message tone : Change to SMS tones.
- Alarm tone : Change the alarm clock ringing.
- Power on tone: To enable or disable the startup sound.
- Power off tone: To enable or disable the shutdown sound.

Volume settings

- Ring volume: Adjust the volume of the ringing tone
- Voice volume : Adjust the earpiece volume
- Key tone volume: To adjust the volume of the key

> Alert settings

Prompted to select ringing, vibration or mute

> Meeting:

Operation with Standard Mode.

> Outdoor:

Operation with Standard Mode.

> Silent

Operation with Standard Mode.

2.14 Extra

Calculator

Um die Anzahl der Tasteneingabe 0-9 berechnen.

Ebook

E-books can be read the suffix named TXT format text document, connected to the computer via a USB cable into the T card or phone EBook folder, find the folder can open books, open the e-book can also be directly into the reading text.

Power off timer

Stellen Sie die Zeit, in der Zeit der Abschaltung.

- > Stopwatch: Enter the stopwatch sub-menu, Open stopwatch function
- > Timer : Set the time, time to rings
- > Torch : On/off function

2.15 Bluetooth

> Open the bluetooth function, can be matched, and transfer files

2.16 Gallery

The unit provides a certain space for users, but also support T card (capacity optional). You can use this feature to facilitate the management of storage on the phone and T card for various types of directories and files.

2.17 Settings

Phone settings

> Language : Can switch the Spanish and English language

> Time format : Set the time format 12/24H

> Date format : Set the date format

- > Auto keypad Lock : Setting the keyboard lock time
- > T-flash card format : T-Flash card is formatted

Connection settings

> U-disk: Open U disk, connect your phone USB USB function can be realized

Display settings

- Wallpaper: For the standby interface wallpaper.
- Backlight : Selection screen screen off time.
- Brightness: Select the brightness of the screen

Security

> Phone lock

This function allows you to carry out your phone is locked / unlock operation, enter a password to turn on or off the phone lock operation, when the phone is locked, the power will be asked to enter the phone password. Phone default password 0000.

> Data protection: Turn this feature into the phone book // call records into lock

> Call blacklist :

Call in limit

- Restrict all: Turn on this feature, you can restrict all incoming calls
- Blacklist: Contact blacklist barring of incoming calls

- Whitelist: Unrestricted, Normal incoming
- Close: Close all limit functions

Call out limit

- Restrict all: Turn on this feature, you can restrict all outgoing calls
- Blacklist: The contact blacklist can be realized outgoing call barring
- Whitelist: Unrestricted.Normal exhaled
- Close: Close all limit functions

> SMS blacklist :

Receive limit

- Restrict all: Turn on this feature, you can restrict all letters
- Blacklist : Add a contact to blacklist to SMS limit function
- Whitelist: Unrestricted, Can receive SMS
- Close: Turn off so limit

Send limit

- Restrict all : Turn on this feature, you can restrict all text messages can
 not be sent
- Blacklist: Contacts to the blacklist, SMS text messages limit function
- Whitelist: Unrestricted.Can be normally transmitted
- Close: Turn off so limit
- > Storage erase : All Clear phone / R-UIM card

> Flight mode:

Turn on this feature, flight mode

Restore factory settings: Phone feature set to their default values My shortcuts: up, down, left and right arrow keys to set 2.18 Mobile TV

Mobile TV broadcast into the interface.In the mobile TV interface, and then press the menu option to enter mobile TV some relevant Settings

FCC Warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

Specific Absorption Rate (SAR) information

SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value, in general, the closer you are to a wireless base station antenna, the lower the power output. Before a new model phone is a available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC, Tests for each phone are performed in positions and locations (e.g. at the ear and worn on the body)as required by the FCC. For body worn operation, this model phone has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal and that positions the handset a minimum of 1.5 cm from the body. Non-compliance with the above restrictions may result in violation of RF exposure guidelines.