

XDVD236BT

GUÍA RÁPIDA DE INICIO

Receptor Multimedia de DVD con Bluetooth con Pantalla Táctil de 6.2"

Esta Guía Rápida le brinda las nociones básicas para que pueda comenzar a usar su XDVD236BT. Visite www.dualav.com/support/manuals.php para descargar el manual completo o llame a atención al cliente al teléfono 1-866-382-5476 (Lunes-Viernes, 9AM-5PM EST)



Número de servicio al cliente: 1-866-382-5476.

La nantalla de DVD de la unidad que está en el tablero no funcionará mientras el vehículo está en movimiento. Esta es una medida de seguridad para evitar que el conductor se distraiga. Las funciones del tablero del DVD solo funcionarán cuando el vehículo esté en Estacionamiento y el freno de mano esté activado. En la mayoría de los estados es ilegal que el conductor mire videos mientras el vehículo está en movimiento.

Instalación





Diagrama de Cableado - Entradas/Salidas



Ubicación de Controles



1. Carte MicroSD 2 Micrófono 3 Expulsar

4. Modo

- 6 Sintonizar/nista arriba
- 7 Encendido / Volumen / Mudo
- 8 Sintonizar/nista ahain 9. Ranura de USB
 - 10. Entrada AV

19. Root

25 Detener

17. EQ / Intensidad / Finilizar 18 Teclas numéricas

20. Visualización en pantalla

22. Sintonizar / Pista Abaio

21. Local / Aleatorio

23. AS/PS / Repetir

24. Estéreo / Programa

1. Encendido 15. Audio 16. Go to

Control Remoto

- 2. Modo 3. Reproducir/Pausa
- 4 Mudo
- 5. Título 6. Subtítulo
- 7. Configuración 8. Anaulo
- 9 Lento 10. Volumen arriba
- 11. Zoom 12. Seleccionar / Hablar
- 26. Entrar 13, Sintonizar / pista arriba 27. Banda
- 14. Volumen abaio

0000 000 00

Menú Principal

En el Menú, presione el ícono deseado para ingresar al modo correspondiente: Radio, Disco (CD / DVD), USB, Carte SD, BT Teléfono, BT Música, entrada auxiliar, entrada AV y



Control de Audio

Presione VOL para seleccionar entre Volumen, Bajo, Agudos, Balance y Fader. Se puede ajustar el nivel para cada opción de audio girando el botón giratorio a la izquierda y derecha.



Funcionamiento del Sintonizador

Seleccione el icono del sintonizador de la pantalla del menú principal, o pulse el botón MODE de unidad se selecciona el


- 1. Indicador del modo actual
- 2. Pantalla de información
- 3. Sintonizar arriba
- 4 Pantalla emisora memorizada
- 5. Menú anterior
- 6 Esteren
- 7. Intensidad
- 8. Local / Distancia
- 9. Menú siguiente
- 10. Sintonizar abaio 11 Mudo
- 12. Configuración de audio
- 13. AS/PS
- 14 Banda



Funcionamiento del DVD

Inserte un DVD en la ranura para el disco

- 1 Mudo
- 2. Anterior
- 3. Reproducir/Pausa 4. Pista siguiente
- 5. Volver
- 6. Avanzar
- 7. Menú siguiente
- 8. Aleatorio
- 9. Repetir
- 10. Audio
- 11. Hablar
- 12. Menú 13 Esteren
- 14. Go to
- 15 Subtitle
- 16 Título
- 17. Menú anterior



Funcionamiento del Disco

Inserte un CD, y la unidad leerá el mismo

- 1. Menú anterior
- 2. Mudo
- 3. Audio
- 4. Volver
- 5. Avanzar
- 6. Menú siguiente
- 7 Detener



Funcionamiento General

Setup para entrar en el menú de configuración Los primeros 7 opciones de configuración se mostrarán en la pantalla.



Funcionamiento de Bluetooth


Micrófono Bluetooth

El micrófono está integrado en el receptor

Vinculación v conexión

Antes de noder utilizar un dispositivo Bluetooth, dehe vincularse y conectarse. La multimedia emite la señal de vinculación constantemente cuando no hay dispositivos conectados.

Completar la secuencia de vinculación desde el dispositivo Bluetooth. El nombre del dispositivo es "Dual BT". Cuando se le solicite, introduzca la contraseña "0000" en su dispositivo Una vez que esté completa la vinculación, la mayoría de los Bluetooth se conectarán automáticamente si el dispositivo está



Presionar III para mostrar el teclado numérico y

Realizar y finalizar una llamada

Presionar nara realizar una llamada, y presionar para

Acceder a la Lista de llamadas recientes

Pulse sucre para ver la lista de llamadas recientes y ver o seleccionar los números de las llamadas Marcadas, Recibido o

Transferir audio

Presionar G para transferir audio entre la unidad principal y el teléfono móvil.

Presionar MI para reproducir o pausar la música.

Presionar | para saltar a la pista anterior.

Presionar | para avanzar a la pista siguiente.

Garantía limitada de un año

Esta garantía le otorga derechos legales específicos. Puede también tener otros derechos que varían de un estado a otro. Dual Electronics Corp. garantiza al comprador original que este producto está libre de defectos en material y mano de obra por un período de un año a partir de la

Dual Electronics Corp. acuerda, a nuestra opción, durante el período de garantía, reparar cualquier defecto en material o mano de obra o suministrar un producto igualmente nuevo. renovado o similar (cualquiera que se considere necesario) sin cargo. Cualquier reemplazo subsiguiente está garantizado para equilibrar el período de garantía original.

¿Quién está cubierto? Esta garantía se extiende al comprador minorista original para compras realizadas a un distribuidor autorizado.

¿Qué se cubre? Esta garantía cubre todos los defectos de material y mano de obra en este Producto. No se cubre lo siguiente: software, costos de instalación/remoción, daño causado por un accidente, mal uso abuso, negligencia, modificación del producto, instalación no apropiada, línea de voltaje innaturente. ocurrido durante el transporte de devolución del producto. Se pueden encontrar las condiciones específicas de licencia y avisos de derechos de propiedad para el software en www.dualav.com

- 1. Antes de llamar al servicio técnico, controle la guía de resolución de problemas del manual. Un pequeño ajuste de algún control puede ahorrarle un llamado al servicio técnico.
- 2. Si necesita servicio técnico durante el período de garantía, debe empacar cuidadosamente el producto (preferentemente en el empague original) y enviarlo mediante transporte pre pago a un centro técnico autorizado, con copia del recibo original.
- 3. Describa el problema por escrito y con su envío incluya su nombre, una dirección de envío UPS (no aceptamos apartado de correos), y un teléfono diurno
- Para obtener más información sobre la ubicación del servicio técnico más cercano:
 Llame gratuitamente al teléfono 1-866-382-5476 (Lunes-Viernes, 9AM-5PM, hora del este) Envíe un correo electrónico a cs@dualav.com

Exclusión de ciertos daños: Esta garantía es exclusiva y en lugar de cualquiera y todas las otras garantías, expresas o implícitas, incluyendo sin limitación las garantías implícitas de comerciabilidad y aptitud para un fin particular y cualquier obligación, responsabilidad, derecho, reclamo o recurso en contrato o perjuicio, haya o no surgido de la negligencia de la compañía, real o imputada. Ninguna persona o representante está autorizado a asumir por la compañía cualquier otra responsabilidad en conexión con la venta de este producto. Bajo ninguna circunstancia será responsable la compañía por daños indirectos, incidentales o resultantes

> www.dualay.com © 2016 Dual Flectronics Corn



XDVD236BT

QUICK START GUIDE

Multimedia DVD Receiver with Bluetooth featuring a 6.2" digital TFT LCD

This Quick Start Guide gives you the basics to start using your XDVD236BT. Please visit www.dualav.com/support/manuals.php to download a complete owner's manual or call customer service at 1-866-382-5476 (Monday-Friday, 9AM-5PM EST).




Customer Service Toll Free: 1-866-382-5476

Safety Notes

The DVD video display of the in-dash unit will not operate while the vehicle is moving. This is a safety feature to prevent driver distraction. In-dash DVD video functions will only operate when vehicle is in Park and the parking brake is engaged. It is illegal in most states for the driver to view video while the vehicle is in motion

Installation




TYPICAL FRONT-LOAD DIN MOUNTING METHOD

Copyright and Trademark Notes

This product incorporates copyright protection technology that is protected by method claims of certain U.S. patents and other intellectual property rights owned by Macrovision Corporation and other rights owners. Use of this copyright protection technology must be authorized by Macrovision Corporation, and is intended for home and other limited viewing uses only unless otherwise authorized by Macrovision Corporation. Reverse engineering or dissessembly is prohibited. Manufactured under license from Doby Laboratories. Doby and the double-D symbol are trademarks of Doby Laboratories. DVD Logo is a trademark of DVD Format/Logo Licensing Corporation registered in the U.S., Japan and other countries SD Logo is a trademark of SD-3C, LLC. IPod and IPhone are trademarks of Apple Inc., registered in the U.S. and other countries. Dual Electronics Corporation is not affiliated with Apple, Inc. Other trademarks and trade names are those of their respective owners.

Wiring Diagram - Inputs/Outputs



Control Locations



1. microSD Card 6. Tune/Track Up 2. Mic 7. Power/Volume/Mute 3. Eiect - Press to eiect disc Tune/Track Down 4. Reset 9. USB Slot

Remote Control

5. Mode

1. Power	15. Audio	(1	2	3	4	
2. Mode	16. Goto					
3. Play/Pause	17. EQ/Loud/End call					
4. Mute	18. Number keys		9	۰	0	—(5)
5. Title	19. Root	ව ම		-		
6. Sub Title	20. OSD		-	•	3	
7. Setup	(On Screen Display)	28 -		-	-	—ŏ
•	21. Local/Random	<u> </u>	-	dis.	-	− @
8. Angle	22. Seek Down/	2	_	м	541	
9. Slow	Prevous Track	20	. 0	0	6	— <u>i</u> i
10. Volume UP	23. AS/PS/Repeat	<u> </u>		0	=	-6
11. Zoom	24. Stereo/Program		0	0	•	
12. Select/Talk	25. Stop	® E	0	0	0	
13. Seek UP/Next Track	26. Enter	6	0	0		(6)
14. Volume Down	27. Band		Date		-	

10. AV Input

Audio Control

Tap VOL to select between Volume, Bass, Treble, Balance and Fader. You can adjust the level for each audio option by turning the rotary left and riaht.



Main Menu

In the Menu mode, press the desired icon to enter the corresponding mode: Tuner, Disc, USB, SD Card, BT Phone, BT Music, Aux In, AV In, Setup.



Setup Menu

General Operation

From the Main Menu screen, press Setup to enter the Setup Menu. The first 7 setup options will be displayed on the screen.



Tuner Operation

Select the Tuner icon from the Main Menu screen or press MODE unit Tuner is selected.

- 1. Current Mode Indicator
- 2. Information Display
- 3. Tune Up
- 4. Preset Station Display
- 5. Previous Menu
- 6 Stereo
- 7 Loud
- 8. Local/Dx
- 9. Next Menu
- 10. Tune Down 11. Mute
- 12. Audio
- 13. As/Ps
- 14. Band

1. Mute

2. Previous 3. Play/Pause

4. Next Track

5. Backward

6. Forward

8. Random

9. Circulate

10 Audio

11. Dial

12. Menu

13 Stereo

15 Subtitle 16. Title 17. Previous Menu

14. Goto

7. Next Menu

DVD Operations

Insert a DVD in the disc slot for playback

11 12 13 14

.

Bluetooth Operation

Bluetooth Microphone

The microphone is built-in to the receiver

Pairing and Connecting

Before you can use a Bluetooth device, it must be paired and connected. The Multi Media broadcasts the pairing signal constantly when no devices are currently connected. Complete the pairing sequence from your Bluetooth device. The device name is "Dual BT". The Bluetooth passcode "0000". Once pairing is complete, most Bluetooth will connect automatically if the device is in range when the unit is powered-on.

Dialing a Number

Press iii to display keypad and dial a number.

Making and Ending a Call

Press 🕻 to connect a call, and press 🦰 to end a call.

Accessing Recent Call List

Press to access the recent call list and view/select numbers from recent Received, Dialed or Missed calls.

Transfering Audio

Press to transfer audio between the head unit and mobile phone.

Streaming Audio

Press II to play or pause the music.

Press | to skip to the previous track.

Press I to advance to the next track.





One-Year Limited Warranty

This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

Dual Electronics Corp. warrants this product to the original purchaser to be free from defects in material and workmanship for a period of one year from the date of the original purchase.

Dual Electronics Corp. agrees, at our option, during the warranty period, to repair any defect in material or workmanship or to furnish an equal new, renewed or comparable product (whichever is deemed necessary) in exchange without charges, subject to verification of the defect or malfunction and proof of the date of purchase. Subsequent replacement products are warranted for the balance of the original warranty period.

Who is covered? This warranty is extended to the original retail purchaser for products purchased from an authorized Dual dealer and used in the U.S.A.

What is covered? This warranty covers all defects in material and workmanship in this product. The following are not overect software, installation/removal costs, damage resulting from accident, missue, abuse, neglect, product modification, improper installation, incorrect line voltage, unsubnrized repair or failure to follow instructions supplied with the product, or damage occurring during return shipment of the product. Specific itemse conditions and copyright notices for the software can be found via waw.dualar.com.

1. Before you call for service, check the troubleshooting guide in your owner's manual. A slight adjustment of any custom controls may save you a service call.

2. If you require service during the warranty period, you must carefully pack the product (preferably in the original package) and ship it by prepaid transportation with a copy of the original receipt from the retailer to authorized service center.

3. Please describe your problem in writing and include your name, a return UPS shipping address (P.O. Box not acceptable), and a daytime phone number with your shipmen

4. For more information and for the location of the nearest authorized service center please contact us by one of the

Call us toll-free at 1-866-382-5476

(Monday-Friday, 9:00 a.m. to 5:00 p.m. EST)

E-mail us at cs@dualav.com

Exclusion of Certain Damages: This warranty is exclusive and in lieu of any and all other warranties, expressed or replact, including without initiation the impliest warranties of merchantability and fitness for a particular purpose and you obligation, initiation, and interest to remedy in contract or tort, whether or not arising from the company's negligance, actual or imputed. No person or representative is authorized to assume for the company any other liability in connection with the sale of this product. In no event shall the company be liable for indirect, incidental or consequential

CD Operations

Insert a CD in the disc slot, and the unit will read the disc.

- 1. Previous Menu
- 2 Mute
- 3. Audio 4 Backward
- 5. Forward
- 6. Next Menu
- 7. Stop





14 15 16





FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.