

-Reorient or relocate the receiving antenna.

-Increase the separation between the product and receiver.

-Consult the dealer or an experienced radio/TV technician for help.

-Connect the product into an outlet on a circuit different from that to which the receiver is connected.